

9 TROUBLESHOOTING

This chapter describes how to resolve problems with the machine. If the recommended action fails to clear the problem contact your distributor or the Ishida Customer Service department.

WARNING

- **Do not touch or come into contact with any charged electrical components.**
 - **Electrical work should only be performed by a qualified electrician.**
 - **Before performing inspection or maintenance work, always switch off the main isolator unless otherwise instructed in this manual.**
 - **After turning off the power switch, wait at least 3 minutes before servicing the weigher.**
 - **Before starting inspection or maintenance post a clearly written sign indicating that such work is in progress to prevent other personnel from accidentally powering up the equipment.**
 - **When performing maintenance and inspection work on equipment at height, a suitable and sufficient means of access to the place of work must be provided and used.**
-

9.1 Error Message Handling

When an error occurs, the message will appear on the display screen of the RCU. If the message is displayed, follow this procedure.

1. Press the [Exit] key.
2. Take corrective actions, referring to "Table 9-1".
3. Press the [Start] key to restart operation.

Table 9-1

Error No.	Error Message	Causes	Action
101-00	[Auto Zero Error] Occurs when the weigh data during zero adjustment is outside the zero adjustment range.	Something is on or making contact with the weigh conveyor.	Remove products or remaining items on the conveyor if any, and perform the zero adjustment again. (Refer to "5.3.2 Zero Adjustment")
		Air from the air conditioner is exposed to the conveyor.	Change the wind direction or shield the wind with a wind shield, and perform the zero adjustment again. (Refer to "5.3.2 Zero Adjustment")
102-00	[Feed Conveyor overload error] Occurs when infeed conveyor does not rotate correctly.	Each conveyor is overloaded or the conveyor belt is tensioned too much.	Turn off the power switch. Make sure that no adherents, damaged areas, and jamming are found on each conveyor. Adjust the tension of each conveyor belt. Apply the power again after 30 seconds.
103-00	[Feed Con. OP Motor Error (Over Ld)] Occurs when the fore stage conveyor does not rotate correctly.		
104-00	[Weigh Conveyor overload error] Occurs when weigh conveyor does not rotate correctly.		
105-00	[Rejection Conveyor overload error] Occurs when the reject conveyor does not rotate correctly.		
106-00	[R. RE Error (Over Ld)]	Each rejection part is overloaded.	Turn off the power switch. Make sure that no adherents and damaged areas are found on each rejection part. Apply the power again after 30 seconds.
107-00	[L. RE Error (Over Ld)]		
108-00	[Feed Conveyor abnormal pulse error] Occurs when the conveyer does not operate at the set speed.	Each conveyor is overloaded. The conveyor belt is tensioned too much.	Turn off the power switch. Make sure that no adherents, damaged areas, and jamming are found on each conveyor. Adjust the tension of each conveyor belt. Apply the power again after 30 seconds.
109-00	[Weigh Conveyor abnormal pulse error] Occurs when the conveyer does not operate at the set speed.		
110-00	[Rej Conveyor abnormal pulse error] Occurs when the conveyer does not operate at the set speed.		

Table 9-1

Error No.	Error Message	Causes	Action
111-00	[OP Motor Error (Pls NG)] Occurs when the conveyor does not operate at the set motor speed.	The spare motor is overloaded or the conveyor belt is tensioned too much.	Turn off the power switch. Make sure that no adherents and damaged areas are found on the spare motor. Adjust the tension of the conveyor belt. Apply the power again after 30 seconds.
113-00	[Power Error (DRV)]	Power failure in each board. Power is momentary interrupted in the board.	Turn off the power switch and check the power supply line. Apply the power again after 30 seconds.
114-00	[Power Error (REJ)]		
115-00	[Power Error (ADC)]		
116-00	[Power Error (IO)]		
117-00	[R. RE Error (SU TimeOut)] Occurs when load is applied on the right side of the rejecter device.	The rejection part is overloaded. Product is caught in the rejection part.	Turn off the power switch to make sure that no adherents, damaged areas, and jamming are found. Apply the power again after 30 seconds.
118-00	[R. RE Error (Comp.TimeOut)] Occurs when load is applied on the right side of the rejecter device.		
120-00	[L. RE Error (SU TimeOut)] Occurs when the operation of the left side of the rejecter device failed to be completed within the time.	The rejection part is overloaded. Product is caught in the rejection part.	Turn off the power switch to make sure that no adherents, damaged areas, and jamming are found. Apply the power again after 30 seconds.
121-00	[L. RE Error (Comp.TimeOut)] Occurs when the operation of the left side of the rejecter device failed to be completed within the time.		
122-00	[L. RE Error (Noncomp.)] Occurs when the capacity may be exceeded in the rejection part.	The product infedding pitch is narrow.	Check the pitch that product are infed.
		The setting of the reject ON time or reject speed is wrong.	Set the reject ON time shorter. (Refer to "6.4.12 Timing Setting")
132-00	[Photo Sensor Error (Weigh)] Occurs during production if the light interrupt interval of the photoelectric switch is longer than the prescribed time.	Sender and receptor photo elements are not properly aligned.	Adjust the alignment of the photo cells.
		An object is blocking the light between the sender and receptor photo elements.	Check for interference and remove any obstructions on the weigh conveyor.

Table 9-1

Error No.	Error Message	Causes	Action
135-00	[Air Low stop] Occurs when air pressure of the rejecter device is lowering.	The air pressure setting is wrong.	Check the regulator setting.
		The amount of the air supplied is insufficient.	Check the air source.
136-00	[Metal Ready Off] Occurs when a ready signal for the metal detector is not input.	The power to the metal detector is not applied.	Check the power to the metal detector.
		The metal detector detected an error.	Check the metal detector.
149-00	[External E-Stop signal Error]	An interlock signal is input.	Clear the External E-Stop signal and release the interlock signal.
152-00	[Communication Error (DRV)]	A communication error occurs between the boards.	Turn off the power switch and check the communication line. Apply the power again after 30 seconds.
153-00	[Communication Error (REJ)]		
154-00	[Communication Error (ADC)]		
155-00	[Communication Error (IO)]		
301-01	[Zero Error] Occurs when the weight data is out of the zero adjustment range when adjusting the zero point.	Something is on or making contact with the weigh conveyor.	Remove the cause if any and adjust the zero point again. (Refer to "5.3.2 Zero Adjustment")
302-00	[Span Error] Occurs when the weight data is out of the span range when adjusting the span.	The zero point is far from the range.	After adjusting the zero, adjust the span. (Refer to "6.5.5 Span Adjustment")
		The span was adjusted with the wrong span weight.	Place the weights as displayed in the display part, and adjust the span again. (Refer to "6.5.5 Span Adjustment")
		The span weight is not placed correctly on the weigh conveyor.	Place the span weight in the middle of the weigh conveyor, perform the span adjustment again. (Refer to "6.5.5 Span Adjustment")
		Something is on or making contact with the weigh conveyor.	Remove the cause if any, and adjust the zero point again. (Refer to "5.3.2 Zero Adjustment")

Table 9-1

Error No.	Error Message	Causes	Action
303-01 to 303-12	[Preset Data Error]	The setting of total weight for the Reference Weight, Upper Limit, and Preset Tare exceeds the Capacity.	Check the setting value and reset. (Refer to "6.4 Preset Setting")
		The reference weight is set below the lower limit.	Check the setting value and reset. (Refer to "6.4.3 Reference Weight", "6.4.4 Upper Limit+", "6.4.5 Lower Limit-" and "6.4.7 Preset Tare")
		Reference Weight is outside of the upper and lower limits.	
		Product length is 0 mm.	Check the setting value and reset. (Refer to "6.4.8 Product Length")
		The upper limit exceeds 25% of the reference weight.	Check the setting value and reset. (Refer to "6.4.4 Upper Limit+")
	[Span Not Adjust.]	The span has not been adjusted.	Perform the span adjustment. (Refer to "6.5.5 Span Adjustment")
	[Linear Not Adjust.]	The linear has not been corrected.	Perform the linear correction. (Refer to "6.5.6 Linear correction")
310-00	[Access Denied.]	Weight does not fall within $\pm 10\%$ of the reference weight range.	Perform the dynamic calibration again. (Refer to "6.4.20 Dynamic Calibration")
501-00	[USB memory diagnosis.] Occurs when the USB memory diagnosis fails.	USB memory is not inserted.	Insert USB memory.
		The USB memory is broken.	Format the USB memory.
		The USB memory is full of data.	Remove the data from the USB memory. Check the free space of the USB memory with a PC.
		The USB memory is other than specified by Ishida.	Check that the USB memory specified by Ishida is used.

Table 9-1

Error No.	Error Message	Causes	Action
901-00	[Printer Error] Occurs when printer is not functioning normally.	A printer is not connected.	Check the printer connection.
		Printer paper is run out.	Replace the printer paper. (Refer to "8.5 Replacing Printer Paper")
		Printer head remains opened.	Pull down the printer head.
		Printer mechanism malfunctions.	Check the printer.

9.2 Failure and Malfunction of DACS-GN

When an error occurs, the message will appear on the display screen of the RCU.

If the message is displayed, follow this procedure.

Table 9-2

Status	Cause	Countermeasure
The initial screen is not displayed when the power switch is turned ON.	The board malfunction or fault in wiring inside the remote control unit.	Contact the distributor or Ishida support center.
	The breaker has tripped. The fuse is blown.	Confirm the safety for the electric component and turn ON the breaker, or replace the fuse.
The screen is not switched after the initial screen is displayed.	The board malfunction or fault in wiring inside the main body.	Contact the distributor or Ishida support center.