

INDEX

A

All Lot Totals	5-16
All Preset Setting Output	5-16
Always Metal M Output	6-62
Arm Rejector Speed	6-23
Auto Calculation	6-24
Auto Logged-Out Time	6-97

B

Batch Analysis	6-58
Batch Total Count	6-61

C

Cancel	5-16
Charge Mixing Weight Deviation	6-22, 6-78
Check Mode	6-8
Clear All Totals	5-16
Clear Batch Totals, Clear All Totals	6-64
Clear Logs	5-16
Common Setting Output	5-16
Continuous N/G Count	6-35
Continuous N/G Stop	6-36
Conveyor Mode	6-26
Current Log Total	5-16

D

Date	6-84
Date and Time setting	6-84
Date Setting	6-84
Default Rej. Dir.	6-28
Default Reject Time	6-23
Description of Test Mode Screen	6-12
Display Access Log	5-24
Display access logs	5-16
Display Panel	4-3
Drive Power Shutdown and Indication	1-10

Drive Weigh Standby Time	6-23
Dynamic Calibration	6-37, 6-74

E

Each Time Output	5-16, 5-18
Each Time Output Contents	6-63
Error Message Handling	9-1, 9-6
Ext. 1 Rej. Direction	6-28
Ext.2 Rej. Direction	6-28

F

FBC INDIRECT FEEDBACK CONTROL (CONTROL AMOUNT OUTPUT)	10-36
FBC INDIRECT FEEDBACK CONTROL (PULSE OUTPUT)	10-26
FBC INDIRECT FEEDBACK CONTROL (TREND OUTPUT)	10-17
Foreign Obj. Rej. Dir.	6-28
Function Dialog Menu	5-15

G

General Precautions	1-2
---------------------------	-----

H

Histogram Base	6-45
Histogram Display	5-13
Histogram Gap	6-45

I

ID52 "maintenance engineer"	6-98
Infeed Conveyor	2-2
Infeed Conveyor Speed	6-23
Input Signal Port Setting	6-79
Input Signal Setting	6-80

Inspection During Production	5-9
Installation Procedure	3-2
INTRODUCTION	2-1

L

Last 20 Weight Data Display	5-13
Level 1&2&3 Passcodes Setting	6-85
Linear correction	6-67
Log In	6-91
Log Out	6-94
Log Output	5-16
Lower Limit	6-18

M

Main Components	2-2
MAINTENANCE AND INSPECTION	8-1
MD NG Input Delay Time	6-23
Metal Detect Rej. Dir.	6-28
Model Specifications	11-1

N

N/G Stop Setting	6-35
------------------------	------

O

OK-over Rej. Dir.	6-28
OK-under Rej. Dir.	6-28
Operation of Filter Simulation Screen	6-39
Operation Outline	2-4
Output	5-16
Output Destination	5-16
Output Signal 32 Delay (XT101)	6-23
Output Signal 35 Delay (XT101)	6-24
Output Signal 38 Delay (XT101)	6-24
Output Signal 41 Delay (XT101)	6-24
Over Wt. Rej. Dir.	6-28
Overweight	2-1

P

Packer	2-1
Passcode Change	6-96
Passcode Unlock	6-93
Photo Switch	2-2
Pitch Error Rej. Dir.	6-28
Power Switch	2-3
Preset Copy	6-83
Preset Information	5-13
Preset Number Change on PresetScreen ..	6-46
Preset Number Memorizing	6-75
Preset Setting Change in StandbyMenu ..	6-47
Preset Setting CSV Output / Input	6-52
Preset Setting Output	5-16
Preset Tare	6-20
Pre-start Checkup	5-3
Printer	6-71
Product	2-1
Product Code	6-24
Product Image	6-25
Product Length	6-20
Product Length Error Rej. Dir.	6-28
Product Name	6-15
Proper	2-1
Proper Count	10-10
Proper Count Clear	10-8
Proper Feed	5-16
Proper Reject Setting	10-11
Proper Wt. Rej. Dir.	6-28
Properweight Count	10-7

R

Read Preset Setting	6-51
Reference Weight	6-17
Register ID	6-94
Regular Inspection	8-3
Reject Conveyor Speed	6-23
Reject Direction Setting	6-29
Reject ON Time	6-23
Reject Setting	6-27, 6-71
Reject Start Time	6-23
Rejector Device (option)	2-3
Replacing Battery for Memory Backup	8-4

S

Screen Capture	6-87
Set. chg. during driving	6-41
Span Adjustment	6-66
Special Precautions	1-6
Speed	6-21
Standby Display Preference	6-82
Starting the Production	5-8
Startup Check	6-81
Statistics & Output Setting	6-55
Switching to the Operator Level	6-5
Switching to the Site Engineer Level	6-6
System Configuration	6-69

T

Tare Subtraction	6-73
Terminology	2-1
Test Mode	6-12, 6-81
Test Production	6-8
Time	6-85
Time Setting	6-85
Timing Setting	6-23
Total Auto Output	6-57
Total Count Zoom	5-13
Total Items	6-57
Total Output Time	6-61
TROUBLESHOOTING	9-1

U

Under	2-1
Under Wt. Rej. Dir.	6-28
Upper Limit	6-17
User Log In	6-89

W

Warning Indications-Types and Definit	1-1
Warning Label Handling	1-9
Warning Label Location	1-9
Warning Labels	1-9

Washing and Sterilization	7-2
Weigh Conveyor	2-2
Weigh Conveyor Speed	6-23
Weighing Capacity	6-16
Weight Data Output	10-52
Weight Display	6-70
Weight Log	6-78
Weight Log Output	5-16
Weight Value Zoom	5-13
Weight Zone (3 Zone / 5 Zone)	6-77
Wind Cover	7-10

X

X-Bar Chart	5-13
X-bar Ref.	6-43
X-bar Sample Count	6-42
X-bar Upper Limit	6-43

Z

Zero Adjustment	5-5
Zero Error Reject Dir.	6-28

MODIFICATION HISTORY

Version	Date	Part Number	Changes
1	2017 - 03		



ISHIDA CO., LTD.

44 SANNO-CHO SHOGON SAKYO-KU,
KYOTO 606-8392 JAPAN
TEL/+81 75-771-4141
FAX/+81 75-751-1634

www.ishida.co.jp

