

REPLACING PARTS

NOTE: BEFORE WORKING, CLEANING OR MAINTAINING THE EQUIPMENT, IT IS HIGHLY IMPORTANT TO LOCK OUT ALL OF THE ENERGY SOURCES ACCORDING TO OSHA (OR LOCAL SAFETY) REGULATIONS. ONLY PEOPLE WITH THE PROPER QUALIFICATIONS, TRAINING, AND AUTHORITY FROM THE MANAGEMENT SHALL WORK OR MAINTAIN THIS EQUIPMENT.

BEFORE ATTEMPTING TO DO ANY WORK, CLEANING OR MAINTAINING THE EQUIPMENT, BE CERTAIN TO SHUT THE POWER OFF BY SWITCHING THE MAIN POWER SUPPLY CIRCUIT BREAKER TO THE OFF POSITION. THE MAIN DISCONNECT SWITCH MUST THEN BE LOCKED OUT AND TAGGED ACCORDING TO OSHA (OR LOCAL SAFETY) REGULATIONS. ONLY PEOPLE WITH THE PROPER QUALIFICATIONS, TRAINING, AND AUTHORITY FROM THE MANAGEMENT SHALL WORK OR MAINTAIN THIS EQUIPMENT.

REPLACEMENTS

An important part to maintaining your machine to its upmost efficiency is by detecting damaged or worn parts. When following the Maintenance Schedule you have set for your machines, you will be able to inspect specific parts (if not all) of your machines for damage and wear. Do not continue to run machines with worn or damaged parts. Replace faulty parts before a bigger problem occurs.

BEFORE ATTEMPTING TO DO ANY WORK, CLEANING OR MAINTAINING THE EQUIPMENT, BE CERTAIN TO SHUT THE POWER OFF BY SWITCHING THE MAIN POWER SUPPLY CIRCUIT BREAKER TO THE OFF POSITION. THE MAIN DISCONNECT SWITCH MUST THEN BE LOCKED OUT AND TAGGED ACCORDING TO OSHA (OR LOCAL SAFETY) REGULATIONS. ONLY PEOPLE WITH THE PROPER QUALIFICATIONS, TRAINING, AND AUTHORITY FROM THE MANAGEMENT SHALL WORK OR MAINTAIN THIS EQUIPMENT.

BALANCE WEAVE BELT (Assembly Instructions)

Installing Belt

- * The is no top or bottom side to belt. Either side can face up.
- * Direction of travel— ensure the spiral leads the crimped connector to which it is welded.
- * If replacing an old belt, splice the leading spiral of the new belt to trailing spiral of old belt. *See Splicing belt ends together.*
- * If there is no old belt on the conveyor, pull the belt through the conveyor while maintaining even tension across the belt's width. This will help decrease the chances of a bent wire or crease.
- * Before applying tension, ensure all spirals are seated into the connectors and lie flat.

Splicing Belt ends Together

1. Bring the two ends together with the belt edges in line.
2. Mesh the end spirals together permitting insertion of crimped connecting wires. Insure spirals being joined are of opposite weave—one right hand, the other left hand.
3. Insert crimped connector and cut the connector such that approximately 1/16 inch [1.6mm] overhangs the end spirals.
4. Apply a simple tack weld to fasten connector to end spirals.

BEFORE ATTEMPTING TO DO ANY WORK, CLEANING OR MAINTAINING THE EQUIPMENT, BE CERTAIN TO SHUT THE POWER OFF BY SWITCHING THE MAIN POWER SUPPLY CIRCUIT BREAKER TO THE OFF POSITION. THE MAIN DISCONNECT SWITCH MUST THEN BE LOCKED OUT AND TAGGED ACCORDING TO OSHA (OR LOCAL SAFETY) REGULATIONS. ONLY PEOPLE WITH THE PROPER QUALIFICATIONS, TRAINING, AND AUTHORITY FROM THE MANAGEMENT SHALL WORK OR MAINTAIN THIS EQUIPMENT.

BALANCE WEAVE BELT (Assembly Instructions)

Removing Stretch from Belts

1. Belt length will need to be removed when the take-up mechanism is near its maximum stroke.
2. Identify a section of the belt to be removed. Insure end spirals of section to be removed are of opposite weave.
3. Remove as much belt as possible, however insure enough belt remains to easily splice ends together.
4. On one belt edge, cut at the weld junction leaving the weld on the crimped connector. On other belt edge, cut at the weld junction leaving the weld on the end spiral. Remove the connector, pulling on the connector's end containing the weld.
5. See "Splicing Belt Ends Together" to reattach belt.

