

TROUBLESHOOTING

NOTE: BEFORE WORKING, CLEANING OR MAINTAINING THE EQUIPMENT, IT IS HIGHLY IMPORTANT TO LOCK OUT ALL OF THE ENERGY SOURCES ACCORDING TO OSHA (OR LOCAL SAFETY) REGULATIONS. ONLY PEOPLE WITH THE PROPER QUALIFICATIONS, TRAINING, AND AUTHORITY FROM THE MANAGEMENT SHALL WORK OR MAINTAIN THIS EQUIPMENT.

BEFORE ATTEMPTING TO DO ANY WORK, CLEANING OR MAINTAINING THE EQUIPMENT, BE CERTAIN TO SHUT THE POWER OFF BY SWITCHING THE MAIN POWER SUPPLY CIRCUIT BREAKER TO THE OFF POSITION. THE MAIN DISCONNECT SWITCH MUST THEN BE LOCKED OUT AND TAGGED ACCORDING TO OSHA (OR LOCAL SAFETY) REGULATIONS. ONLY PEOPLE WITH THE PROPER QUALIFICATIONS, TRAINING, AND AUTHORITY FROM THE MANAGEMENT SHALL WORK OR MAINTAIN THIS EQUIPMENT.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
Machine will not Start. NO power	Main Power circuit breaker, open.	Reset main circuit breaker to the ON position.
Unit will not come on when "Safety System Reset" button is pressed.	One of the emergency stop buttons is activated in the "Off" position, breaking the control circuit.	Check emergency button. Pull up on buttons to assure they are in the N.C. position.
	Loose wire on contacts.	Check the wiring on contacts.
	Control transformer circuit breaker is tripped.	Reset circuit breaker and monitor amp load. Look for excessive load upon start-up.
	Main service disconnect is tripped.	Reset main disconnect. Look for excessive load upon start-up.
	Power supply to panel not present.	Verify that there is power on the top of main service disconnect if not locate power source failure.
Conveyor does not move when switched "On"	Inverter fault.	Verify that inverter is not faulted. If faulted reset according to instructions provided in inverter manual.
	No power to inverter.	Check circuit breaker to inverter reset if tripped.
	Defective motor	Verify that motor is receiving full voltage on all three phases. If correct power is indicated at motor then replace motor, using safe lock out tag out procedures.
	Safety system not Reset.	Reset safety system.
Discharge conveyor will not run when switched to the "On" position.	Drive chain disconnected.	Connect drive chain.
	Follow thru the same steps troubleshooting steps previously outlined for main conveyor with identical problem.	

BEFORE ATTEMPTING TO DO ANY WORK, CLEANING OR MAINTAINING THE EQUIPMENT, BE CERTAIN TO SHUT THE POWER OFF BY SWITCHING THE MAIN POWER SUPPLY CIRCUIT BREAKER TO THE OFF POSITION. THE MAIN DISCONNECT SWITCH MUST THEN BE LOCKED OUT AND TAGGED ACCORDING TO OSHA (OR LOCAL SAFETY) REGULATIONS. ONLY PEOPLE WITH THE PROPER QUALIFICATIONS, TRAINING, AND AUTHORITY FROM THE MANAGEMENT SHALL WORK OR MAINTAIN THIS EQUIPMENT.

TROUBLESHOOTING (continued)

PROBLEM	POSSIBLE CAUSE	REMEDY
Conveyor does not move when switched to the "On" position.	Emergency button in the "Off" position.	Pull emergency button(s) up to the N.C. position and reset the safety system.
	Drive chain not connected.	Connect conveyor drive chain.
	Circuit breakers at control box open. (Transformer circuit breakers)	Make sure all breakers are reset to the "On" position at control box.
	Bad inverter.	If voltage into inverter is correct and inverter is not faulted but does not function, check inverter settings and replace inverter if necessary.
Unit will not come on line when main power switched to "On".	One of the emergency buttons is activated in the "Off" position breaking the circuit.	Check emergency buttons. Pull up on buttons to assure they are in the N.C. position.
	One of the transformer circuit breakers is tripped in the "Off" position.	Reset transformer circuit breakers.
Conveyor does not move when switched to the "On" position.	Disconnect circuit breaker tripped off.	Reset disconnect circuit breaker.
	Tripped or defective circuit breaker to magnetic starter.	Reset circuit breaker.
	Defective motor.	Check power voltage to motor. If power is indicated present at motor then it is faulty, replace.
	Main power switch is in the "Off" position.	Turn main power switch to the "On" position.

BEFORE ATTEMPTING TO DO ANY WORK, CLEANING OR MAINTAINING THE EQUIPMENT, BE CERTAIN TO SHUT THE POWER OFF BY SWITCHING THE MAIN POWER SUPPLY CIRCUIT BREAKER TO THE OFF POSITION. THE MAIN DISCONNECT SWITCH MUST THEN BE LOCKED OUT AND TAGGED ACCORDING TO OSHA (OR LOCAL SAFETY) REGULATIONS. ONLY PEOPLE WITH THE PROPER QUALIFICATIONS, TRAINING, AND AUTHORITY FROM THE MANAGEMENT SHALL WORK OR MAINTAIN THIS EQUIPMENT.

TROUBLESHOOTING (continued)

PROBLEM	POSSIBLE CAUSE	REMEDY
Kettle oil level erratic	Blocked probe tip Low air pressure to tank valve Cut or hole in probe hose Low air pressure to level switch	Remove probe, clean tip Verify pressure at tank Repair or replace hose Verify pressure at switch box
Circulating pump not running	Motor overload Drive fault Failed shaft coupling to motor	Check pump overloads in panel Check pump drive for faults Check the pump coupling, replace
Erratic temperature readings on all or some displays	Failed thermocouple Thermocouple wire loose Not mounted in thermowell	Test thermocouple Check wires on thermocouple and all connections to it. Insert deeper in thermowell
Cooking oil temperature not rising after start up	Thermofluid temperature too low Circulating pumps not running Boiler valves closed down	Raise Thermofluid temperature higher Turn on pumps Fully open boiler valves
Cooking oil over fill kettle	Auto fill system not working High level float stuck Storage tank valve stuck open Storage tank valve manual open	Check autofill system for function Clean float shaft and float Check air supply to valve Turn off manual control
Low oil flow at kettle infeed	Gate valve closed down Pump not pumping Low oil in system	Open infeed gate valve Check pump coupling for slip Check oil level, check auto fill