

CD30/35 QUICK START ADDENDUM

1 – SETUP WIRING

- **Incoming power (230v)**
 - In enclosure: L1=35, L2=36, GND=38
 - Open chassis: L1=31, L2=32, GND=38
- **Outgoing power:** L1=41, L2=42, GND=43
- **PPM feedback sensor:** black=1, red=3, white=12, Large black=16
- **Manual run jumper** between 5 & 6

2 – INITIAL SETTING SETUP

- **Set C127, EnS=1** (Unhide the service menu)
- From the defaults change the following parameters:
 - **Menu C038**
 - **I=100**
 - **A=0**
 - **P=10**
 - **Menu C040**
 - **SPE=0**
 - **APS=1**
- **Set C051=25**
 - Change by adjusting the sensor position
 - This setting can be ignored if using the blue sensor

3 – TEACH THE NATURAL OPERATING FREQUENCY

- **Push the green ON button** (start the controller)
- **Go to C038, AFS, press up arrow** (to start the frequency search)
- *NOTE: When successful screen will return to the root menu.*

4 – SET OPERATING CHARACTERISTICS (A & P)

Set A & P so that the maximum conveyor stroke is achieved when A=100

- **Push the red OFF button** (stop the controller)
- **In C038 set A=100 & P=10**
- **Push the green ON button** (start the controller)
- **Gradually increase P** (until the required maximum amplitude of the feeder is reached)
- **Once P is set, A can be used to adjust the amplitude to control capacity throughput**

5 – SAVE USER SETTINGS & HIDE MENUS

After setting up the controller: hide C038 & C040, save user settings

- **Set C127, EnS=0** (hides the C040 service menu)
- **Go to C143, PUSH, press up arrow** (saves all settings under the user settings memory)