

9 TROUBLESHOOTING

9.1 Summary

This chapter describes how to determine the causes of equipment malfunction and to restore proper function.

If the suggested countermeasures are ineffective, please contact an Ishida Service representative.



DANGER

- Do not touch or come into contact with any charged electrical components.
- Electrical work should only be performed by a qualified electrician.



WARNING

- Before performing inspection or maintenance on components not specifically described in this manual, be sure to turn off the main power switch.
- After turning off the power switch, wait at least 3 minutes before servicing the equipment.
- If maintenance or inspection work is to be performed with the main power switch ON, clearly indicate this situation by posting a sign in the work area. This is to prevent other personnel from accidentally starting up the equipment.
- When performing maintenance and inspection work on the upper part of the seal checker, use a sturdy ladder or foothold to avoid a hazardous fall.

9.2 Error Message Handling

When an error occurs, the message will appear on the display screen of the RCU.

1. Press the [EXIT] key.
2. Carry out the countermeasure recommended below.
3. Press the [START] key to restart operation.

NOTE

- The "No." in the table means the error number.

Table 9-1 Error Displays

No.	Error Indication	Cause	Measures
1	Emergency switch was pushed	Emergency switch was pushed.	Check the safety around the system and turn the emergency switch for resetting.
3	Seal checker door open	Seal checker cover was opened.	Check the safety around the system and close the seal checker cover.
4	Bag stabilizer is pulled out	Bag stabilizer is pulled out.	Put the stabilizer unit to back to original position.
5	Servo1 alarm detected	Seal checker servo motor is faulty or may fail.	Ask the distributor you purchased or our company for repairs.
8	SEAL-CHECKER arc-net error	Communication status error due to disconnection of communication line, poor contact, faulty board or noise.	Ask the distributor you purchased or our company for repairs.
9	Jam up at seal checker	Bags are jammed up at the photoelectric sensor and continuously shading the sensor. Optical axis of photoelectric sensor is out of position. Photoelectric sensor is faulty or sensor cable is broken.	Check the safety around the system and remove the jammed bags. Adjust the mounting position of photoelectric sensor. Ask the distributor you purchased or our company for repairs.
10	Jam up at Pre-Rejector		
11	Air pressure is low	Air is not supplied to specifications.	Supply normal air quantity.
22	Error stop by Leak bag	Air leak reject direction is set to STOP and air leak bag was detected.	Open the cover and remove the bag on the conveyor.
23	Error stop by Flat bag	Flat bag reject direction is set to STOP and flat bag was detected.	Open the cover and remove the bag on the conveyor.
24	Error stop by Thick bag	Thick bag reject direction is set to STOP and thick bag was detected.	Open the cover and remove the bag on the conveyor.
27	Error stop by Double bag	Double bag reject direction is set to STOP and double bag was detected.	Open the cover and remove the bag on the conveyor.
28	Error stop by Ext.1 N/G bag	Ext. 1 N/G bag reject direction is set to STOP and Ext.1 N/G bag was detected.	Open the cover and remove the bag on the conveyor.
29	Error stop by Ext.2 N/G bag	Ext. 2 N/G bag reject direction is set to STOP and Ext.2 N/G bag was detected.	Open the cover and remove the bag on the conveyor.

Table 9-1 Error Displays (Continued)

No.	Error Indication	Cause	Measures
31	Error stop by Continuous N/G	Continuous N/G reject direction is set to STOP and continuous N/G bag was detected.	Open the cover and remove the bag on the conveyor.
37	Seal Check conveyor overload	Driver for conveyor drive motor detected overload.	•If the gap between transfer belt and top plate of conveyor is stained, clean. •If timing belt and transfer belt tension is too strong, adjust it. This error also occurs if roller or bearing is damaged or motor cable is broken. If cleaning and adjustment do not still solve the problem, ask the distributor you purchased or our company for repairs.
38	Conditioner overload		
39	Infeed conveyor overload		
40	Bag Stabilizer[F] overload		
41	J-Belt conveyor overload		
42	Reject conveyor overload		
43	Seal Check conveyor speed error	Conveyor speed is excessively slow.	•If the gap between transfer belt and top plate of conveyor is stained, clean. •If timing belt and transfer belt tension is too strong, adjust it. This error also occurs if roller or bearing is damaged or motor cable is broken. If cleaning and adjustment do not still solve the problem, ask the distributor you purchased or our company for repairs.
44	Conditioner speed error		
45	Infeed conveyor speed error		
46	Bag Stabilizer[F] speed error		
47	J-Belt conveyor speed error		
48	Reject conveyor speed error		
49	Operation enable signal off	Error stopped due to operation enable signal OFF.	Set ON the operation enable signal.
50	Operation disable signal on	Error stopped due to operation disable signal ON.	Set OFF the operation disable signal.
51	Seal check task overflow	Because a long bag or bags were carried in the seal checker at too short intervals, simultaneous start maximum quantity for seal check task was exceeded.	Avoid carrying in of a long bag or bags at too short intervals.
52	Reject delay timer overflow	Reject delay timer setting was too great.	Decrease the reject delay timer setting.
53	Signal delay timer overflow	Output signal delay timer setting was too great.	Decrease the output signal delay timer setting.
54	Pre-Rej. Delay timer overflow	Pre-rejector delay timer setting was too great.	Decrease the pre-rejector delay timer setting.
55	Bag Stabilizer[R] overload	Driver for conveyor drive motor detected overload.	•If the gap between transfer belt and top plate of conveyor is stained, clean. •If timing belt and transfer belt tension is too strong, adjust it. This error also occurs if roller or bearing is damaged or motor cable is broken. If cleaning and adjustment do not still solve the problem, ask the distributor you purchased or our company for repairs.

Table 9-1 Error Displays (Continued)

No.	Error Indication	Cause	Measures
60	Upper sensor detected.	Sensor detected upper limit of the infeed conveyor when the conveyor is moving up for height adjustment.	Put the stabilizer unit to back to original position.
61	Lower sensor detected.	Sensor detected lower limit of the infeed conveyor when the conveyor is moving down for height adjustment.	Check the motor for the height adjustment of the infeed conveyor.
62	Up motion error.	Infeed conveyor cannot move up correctly in automated adjustment.	Check the motor for the height adjustment of the infeed conveyor.
63	Down motion error.	Infeed conveyor cannot move down correctly in automated adjustment.	Check the motor for the height adjustment of the infeed conveyor.
64	Narrow sensor detected.	Sensor detected narrow limit of the stabilizer brushes when brushes are moving for width adjustment.	Check the motor for the width adjustment of the stabilizer brushes.
65	Wide sensor detected.	Sensor detected wide limit of the stabilizer brushes when brushes are moving for width adjustment.	Check the motor for the width adjustment of the stabilizer brushes.
66	Narrow motion error.	Stabilizer brushes cannot be adjusted correctly in narrowing the brush width.	Check the motor for the width adjustment of the stabilizer brushes.
67	Wide motion error.	Stabilizer brushes cannot be adjusted correctly in widening the brush width.	Check the motor for the width adjustment of the stabilizer brushes.

NOTE

- The newly added errors (error code 4, and through 60 to 67) all results in servo off when occurs. Errors through # 60 to 67 are ones for automated adjustment unit.

9.3 System Error / Failure

If the system shows an error without error indication, take corrective actions according to "Table 9-2 Error / Failure Table".

Table 9-2 Error / Failure Table

Status	Cause	Measures
When power switch is ON, Initial screen is not displayed on the display section.	Board in the remote control unit is faulty or poor wiring.	Ask the distributor you purchased or our company for repairs.
Initial screen is displayed on the display section, but cannot be switched to other screen.	Board in the main body is faulty or poor wiring.	Ask the distributor you purchased or our company for repairs.
Pre-rejector / N/G reject device works despite no product is running.	Optical axis of photoelectric sensor is out of position.	Adjust the position of photoelectric sensor mounting bracket.

9.4 Warning Messages

Table 9-3 Warning Messages

Error Indication	Cause	Measures
Product length was changed. Please set bagger speed again.	The product length set was too long for the line speed, thus the bagger speed was automatically changed slower than before the product length change.	Set the bagger speed based on total line speed.
Product length and checking mode were changed. Please set bagger speed again.	The product length set is too long for the inspection mode selected, and the inspection mode was changed automatically. As a result, the bagger speed was also changed slower than before the product length change.	Set the bagger speed based on total line speed.
Checking mode was changed. Please set bagger speed again.	Inspection mode was changed, and the theoretical maximum speed was also changed referring the inspection mode, and the bagger speed was changed based on the inspection mode selected.	Set the bagger speed based on total line speed.
Standby height was changed. Please set bagger speed again.	Standby height was changed, and inspection timing was auto calculated based on the standby height. After this auto calculation bagger speed changed slower than before standby height change referring the height change.	Set the bagger speed based on total line speed.
Pause time was changed. Please set bagger speed again.	In pose mode inspection, the pose time was changed. Referring this, theoretical maximum speed was changed as well, and bagger speed was changed based on the pose time.	Set the bagger speed based on total line speed.
No data in Master Memory	There is no Master data in DMU.	Conduct a backup to master data in Initialization/Copy screen.
Can not access Master Data!	No CF card inserted in DMU.	Insert CF card and restart the machine if there remain CF card that was inserted at the time of installation.