

A

Adjustment of Jack Bolt	3-3
Advanced Setting	5-51
Air pressure is low	9-2
ATA Sampling	5-69
Automated Adjustment Unit	5-68

B

Backlight Saver	5-16
Basic Setting Screen	5-45
BL Saver On Time	5-16
BS key (keyboard)	4-7
BS key (ten-key)	4-6

C

CANCEL key	4-6, 4-7
CAPS key	4-7
Characters	5-16
Cleaning and Sterilization	7-2
Cleaning and Sterilization Methods	7-3
Cleaning and Sterilization of Each Part	7-4
Cleaning of Cleaning Brush	7-7
Cleaning of Conditioning Brush	7-9
Cleaning of Conveyor Belt	7-5
CLEANUP PROCEDURES	7-1
CLR key (keyboard)	4-7
CLR key (ten-key)	4-6
Compact flash	5-19
Components and Functions of the Remote Control Unit (RCU)	4-2
Conditioner overload	9-3
Conditioner speed error	9-3
Configuration of the System	2-5
Control Panel	5-14
Control panel key	5-4

Copy all	5-34
Copying Selected Preset	5-32
Correction after Data Entry and Setting	4-8
CRITERIA	5-46

D

Daily Inspection	8-2
Data entry	4-5
DATE & TIME key	5-4
Destination ID	5-17

E

Electrical Power Shutdown and Indication	1-7
Emergency Stop and Restart	6-2
Emergency stop method by EMERGENCY STOP button	6-3
Emergency stop method by power switch	6-2
Emergency switch was pushed	9-2
End Production	6-8
Entering a numeral value	4-6
Entering an alphabet, number, or symbol	4-7
Entry display	4-6
Entry guide	4-6
ERROR LOG Screen	5-61
Error Message Handling	9-2
Error stop by Continuous N/G	9-3
Error stop by Double bag	9-2
Error stop by Ext.1 N/G bag	9-2
Error stop by Ext.2 N/G bag	9-2
Error stop by Flat bag	9-2
Error stop by Leak bag	9-2
Error stop by Thick bag	9-2

F

Bag Stabilizer	9-3
----------------------	-----

FUNCTIONS AND OPERATIONS OF RCU ... 5-1

G

General Precautions to be Observed 1-3

GENERAL SETTING 5-48, 5-50

H

H COMPE. 5-28

Height Adjustment of Brush Conditioner 3-5

Height Compensation of Seal Check Conveyor . 8-7

Help function 5-22

Help key 5-4

I

Infeed Conveyor (For the specification
of all-in-one height-adjustable conveyor) 7-7

Infeed conveyor overload 9-3

Infeed conveyor speed error 9-3

Information Display key 5-4

Information Screen 5-58

Initialization of all 5-37

Inspection / adjustment of conveyor belt 8-11

Inspection during Production 8-2

INSTALLATION 3-1

Installation Location x26 Environment 3-2

Installation Location x26 Power Source
Connection 3-2

INTRODUCTION 2-1

J

J-Belt conveyor overload 9-3

J-Belt conveyor speed error 9-3

Jam up at Pre-Rejector 9-2

Jam up at seal tester 9-2

K

keyboard 4-5

L

Language select key 5-4

Language Selection Setting 5-16

Left Tab 5-26

List Display 5-30

M

MACHINE PARAMETER 5-51

MAIN MENU Screen 5-23

Maintenance and Inspection Procedures 8-3

Measurement Result Graph Screen 5-64

Measurement Result Log Screen 5-63

Menu keys 4-3

Message Board Screen 5-5

MODE/SPEED SETTING 5-47

N

NAMES AND FUNCTIONS OF RCU 4-1

O

Operation check of photoelectric sensor 8-5

Operation disable signal on 9-3

Operation enable signal off 9-3

Operation Outline 2-7

Operation Panel and Data Entry 4-2

Operation panel view 4-3

Operational level select key 5-4

Outline of Production Sequence 6-4

Output selection	5-39
Output Signal Setting	5-53
overload	9-3
Overview	8-1

P

Password Set	5-16
PERIODIC MAINTENANCE	8-1
Photo Display	5-29
Photo Electric Sensor	7-7
Poroduction Screen	5-66
Power Source Connection	3-2
Pre-Production Procedure	6-5
Pre-Rej. Delay timer overflow	9-3
Pre-Startup Inspection	8-2
PRESET COPY Screen	5-31
PRESET LIST Screen	5-29
Printer Paper Replacement	8-3
Preset Parameter	5-41
Product Setting Screen	5-42
PRODUCTION	6-1
Production Procedure	6-5
Program Number	5-56

R

Bag Stabilizer	9-3
RCU Cleaning	7-4
Reject conveyor overload	9-3
Reject conveyor speed error	9-3
Reject delay timer overflow	9-3
Reject Setting	5-54
Result	5-26
Return key (keyboard)	4-7

Return key (ten-key)	4-6
----------------------------	-----

S

SAFETY CONSIDERATION AND SANITARY	1-1
Screen Configuration Chart	5-1
Screen Control	5-15
Seal Check Conveyor	7-8
Seal Check conveyor overload	9-3
Seal Check conveyor speed error	9-3
Seal test task overflow	9-3
Seal tester door open	9-2
SEAL-TESTER arc-net error	9-2
Selecting a Language	5-9
Selecting an Operation Level	5-10
Selection and Initialization of Preset	5-36
Servo1 alarm detected	9-2
Set item display field	4-6
Setting the Date & Time	5-20
SHIFT key	4-7
Signal delay timer overflow	9-3
Slant Adjustment of Infeed Conveyor Belt	3-3
Space key	4-7
Special Safety Precautions	1-5
Specifications	2-3
speed error	9-3
Stabilizer Unit	7-9
Startup Assistant key	5-4
STATISTICS Screen	5-59
Status displays	4-3
Switching to the Installation Level	5-12
Switching to the Operator Level	5-11
Switching to the Site Engineer Level	5-11
System Config.	5-56

System Error / Failure 9-5

T

Taking photos of product 5-43

ten-key pad 4-5

Terminology 2-2

Timing Auto Calculation 5-50

Timing belt tension adjustment 8-9

Timing belt tension adjustment and visual
check for scratch 8-5

Top setting keys 4-3

TROUBLE SHOOTING 9-1

Tune1 5-27

Tune2 5-27

U

Upper Setting Bar 5-4

W

Wallpaper 5-16

Warning Indications / Types and Definitions 1-2

Warning Label Handling 1-6

Warning Label Location 1-6

Warning Labels 1-6

Warning Messages 1-6

WORST ERROR 10 Screen 5-62

Z

ZOOM CHANGEOVER 5-25

MODIFICATION HISTORY

Version	Date	Part Number	Changes
First edition	Feb. 2009		



ISHIDA CO.,LTD.

44 SANNO-CHO, SHOGOIN, SAKYO-KU,
KYOTO, 606-8392 JAPAN
PHONE: (075)771-4141
FACSIMILE: (075)751-1634
URL: <http://www.ishidajapan.com>

