



Installation

Machine Unpacking

WARNING

Prepare the installation site and clearly designate it! All unauthorized personnel must be restricted from the installation area. Only trained logistics specialists are to be permitted in the installation area.



WARNING

When the nature of a task is such that it cannot be performed at floor level and a ladder or other suitable means is required, such means must not be used in contravention to prescribed safety practices.



After the palletized machine is placed near the installation site (reference the layout drawing for correct placement), unpack the machine as follows:

1. Remove any wooden crating (if applicable).
2. Remove any shrink wrap or packing films. Be careful not to damage the machine surface finishes.
3. Inspect the machine and incidental items for damage that may have occurred during transport. Report all damage to the manufacturer or to the manufacturer's agent immediately.
4. Create a list of the parts present in the packing and compare it with the packing-list. Report all missing items to the **BluePrint** Automation or to **BluePrint** Automation's agent immediately.
5. Remove all of the shipping braces that constrain motion of swinging parts and/or that secure the machine to the shipping pallet.
6. Remove all incidental items shipped with the machine.
7. Remove the machine from the pallet with a forklift. Be sure that the lift levers are long enough to extend past the barycentric axis of the machine.

WARNING

Never lift unbalanced loads. Never lift loads heavier than that for which the device is rated. Never lift loads while persons are moving in the area below. Never use the device for tasks such as pulling, dragging fastened loads, extracting guided elements, etc. Never position the balance plate vertically or on the side during the transport, movement, storage, and measurement phases. It is forbidden for personnel to ride on the transported load or to attempt mounting the transport equipment while it is in use or once the load has been applied. Never use the lifting device to lift and transport persons or objects other than the loads for which the device was designed. Use of undersized lifting equipment could result in damage to the machine or personal injury.



8. Position the machine at the intended installation site.
9. With the forklift bearing the load of the machine, adjust the levelling feet so that the machine is level.
10. Lower the fork and verify that the machine is level; adjust as necessary.
11. Dispose of all packaging material in accordance with applicable regulations.

Packing materials may vary:

Stretch wrap Linear low-density polyethylene

Underlay Polyethylene sheet

Space and Clearance

The minimum floor space and clearances required to operate comfortably on and around the machine are indicated on the layout drawing. Make sure space is allowed for opening panels and for accessibility.

Electrical Installation

The main electrical cabinet is designed to work in standard indoor industrial operating environments, not exposed to the weather.

The following conditions are required for correct installation and operation:

- **+5...+32 °C with cooling fans installed in the main electrical cabinet**
- **+5...+45 °C with optional air conditioners in the main electrical cabinet**
- **20...70% relative humidity, without condensation effect.**

Electrical Service Connection

Reference the electrical schematics. In addition, any machine groups shipped loose will require restoration of their service connections. The following tasks must be performed under the direction of a qualified electrical technician. In making these connections, observe the following:

- Delegate appropriate personnel. Ensure these personnel are qualified for the task and are coordinated by an electrical engineer.
- Arrange the necessary ladders and ensure that they are in compliance with the relevant safety laws in force. The ladders must be free standing, have an adequate work platform to permit the technician to work freely with both hands, and must not under any circumstance rest against the equipment.
- Verify that all machine movement areas are clear of cables or electrical wires.
- Synchronize the work of the whole team for every operation.
- Take appropriate precautionary measures in those tasks that may be dangerous.
- The ends of the cables are marked with different codes. Use the components list and layout diagrams to match these codes on the machine and in the cabinet.
- While connecting and disconnecting the receptacles and plugs, keep the plugs aligned radially and axially with respect to the receptacles to avoid damaging the contacts.



Only qualified persons shall be permitted to make the main electrical connection.



The end user's main power switch for the power lines to be installed must be switched off and locked out in accordance with the regulations in force in the user's country prior to making the electrical connections in the main cabinet.



Electrical Supply: Because our clients have different requirements, gland access holes for installation of the main electrical power are not provided. Be certain wire gauge, cable gland fittings, and insulation meet all applicable code requirements. The power source must have a breaker in a lockable enclosure.

This connection is made at the terminals of the main switch in the cabinet. Use proper tools when passing the cable through the cable gland. A cable of cross-section suitable to the installed power (see the electrical drawings) must be employed. Make sure that the values of the machine power, frequency, and voltage (see the plate on the main cabinet) correspond to the values of the electrical grid. The cable must enter through the cable gland fitting and must be connected to the main switch situated on the inside of the cabinet. The connection is to be effected at the three terminals **L1-L2-L3** for the three-phase line and at the **PE** terminal for the external ground conductor. In case the neutral conductor is present, it should be connected to the special terminal marked **N**.

Once these connections are made, the cabinet becomes operative and the normal safety regulations are in effect:

- Admittance to the machinery is restricted to authorized personnel only.
- The doors must remain closed, except for maintenance or repairs with the main switch off and locked.



THIS PAGE INTENTIONALLY LEFT BLANK