



# Index

|                                                |       |                                          |    |       |
|------------------------------------------------|-------|------------------------------------------|----|-------|
|                                                | INDEX | Conveyor Belt Tension                    | 68 | Index |
| 24-Hour Emergency Hotline                      | 5     | Conveyor Belt Tracking                   | 68 |       |
| About This Manual                              | 6     | Conveyor Safety                          | 19 |       |
| Adjusting the Exit Conveyor Side Guide         | 39    | Count Belt                               | 45 |       |
| Adjusting the Internal Product Guides          | 38    | Count Belt Maintenance                   | 72 |       |
| Adjustments                                    | 30    | Daily Inspection                         | 62 |       |
| A - Rotary Actuated                            | 21    | Description                              | 8  |       |
| Asynchronous Gearmotor Maintenance             | 83    | Dismounting instructions                 | 79 |       |
| At the Beginning of Each Shift:                | 58    | Electrical Disconnect Switch             | 48 |       |
| Bag Jam Fault                                  | 55    | Electrical Installation                  | 27 |       |
| Belt Installation                              | 76    | Electrical Panels                        | 16 |       |
| Belt Removal                                   | 76    | Electrical Safety                        | 16 |       |
| Belt Replacement                               | 75    | Electrical Service Connection            | 27 |       |
| Belt Speed Manual Adjustments Screen           | 50    | Electrical Supply                        | 16 |       |
| Belt Tension                                   | 75    | Emergency Stop Pushbutton                | 16 |       |
| B - Lever Actuated                             | 21    | Emergency Stop Pushbutton                | 48 |       |
| Blue Arrow                                     | 50    | Energy Lockout                           | 21 |       |
| Blue Arrow                                     | 51    | Estop Pressed                            | 55 |       |
| Blue Arrow                                     | 52    | Exit Conveyor                            | 47 |       |
| Blue Arrow                                     | 53    | Fault Messages                           | 55 |       |
| Blue Home Icon                                 | 50    | Full Load Amperage                       | 52 |       |
| Blue Home Icon                                 | 51    | Gearhead Replacement                     | 95 |       |
| Blue Home Icon                                 | 52    | General Cleaning Recommendations         | 63 |       |
| Blue Home Icon                                 | 53    | General Safety Precautions               | 13 |       |
| Blue Home Icon                                 | 54    | General Setup Procedures                 | 30 |       |
| Blue Information Icon                          | 49    | Glossary                                 | 9  |       |
| Blue Power Pushbutton                          | 49    | Home Screen                              | 49 |       |
| BluePrint Automation Warranty                  | 2     | Housed Bearing Maintenance               | 79 |       |
| Blue Toolkit Icon                              | 49    | Human/Machine Interface                  | 48 |       |
| Changeover                                     | 30    | Infeed and Exit Belts Maintenance        | 69 |       |
| Changing the Collator Wheel                    | 32    | Infeed Belt Speed                        | 50 |       |
| Changing the Collator Wheel Plates             | 34    | Infeed Tunnel Guard Adjustment           | 31 |       |
| Changing The Oil                               | 83    | Infeed Tunnel Guarding                   | 44 |       |
| Checking The Oil Level                         | 83    | Installing Lockout Devices               | 23 |       |
| Circuit Breaker Tripped                        | 55    | Jam Detection Photoelectric Sensor       | 44 |       |
| Class 1 Lasers                                 | 24    | Job Number                               | 52 |       |
| Cleaning machinery and conveyor belts          | 65    | Large Collator Wheel                     | 32 |       |
| Cleaning or Replacing the Vent Screw           | 95    | Largest Motor Amperage                   | 52 |       |
| Cleaning Procedure for Large Areas             | 67    | Laser Safety                             | 24 |       |
| Cleaning Procedure for Small Areas             | 67    | Laser Specifications                     | 24 |       |
| Clean The Laser Sensors                        | 82    | Lockable Main Power Switch (lever type)  | 22 |       |
| Collator Belt Speed                            | 50    | Lockable Main Power Switch (rotary type) | 22 |       |
| Collator Wheel                                 | 46    | Lubrication                              | 78 |       |
| Collator Wheel Fault                           | 55    | Lubrication                              | 79 |       |
| Collator Wheel Speed                           | 51    | Machine Elements with Lockout Provision  | 21 |       |
| Collator Wheel Speed Manual Adjustments Screen | 51    | Machine Maintenance                      | 60 |       |
| Contact Information                            | 53    | Machine Technical Information Screen     | 52 |       |
| Conveyor Belt Installation                     | 68    | Machine Technical Information Screen     | 53 |       |
| Conveyor Belt Maintenance                      | 68    | Machine Unpacking                        | 26 |       |

|                                     |     |                                     |    |       |
|-------------------------------------|-----|-------------------------------------|----|-------|
| Main Power                          | 21  | SCCR                                | 52 | Index |
| Maintenance Personnel               | 6   | Sensor Replacement                  | 81 |       |
| Maintenance Safety                  | 18  | Sensor Replacement                  | 82 |       |
| Manual Release & Revised Dates      | 3   | Sequence of Operation               | 42 |       |
| Manufacture Date                    | 53  | Serial Number                       | 52 |       |
| Mechanical                          | 15  | Shutdown Procedure                  | 57 |       |
| Mechanical Installation Inspection  | 17  | Signal Word Panels                  | 14 |       |
| Mechanical Safety                   | 15  | Small Collator Wheel                | 33 |       |
| Mechanical Safety                   | 15  | Space and Clearance                 | 26 |       |
| Minor Maintenance                   | 15  | Spare Parts Group                   | 5  |       |
| Mounting instructions               | 79  | Startup Procedure                   | 57 |       |
| Need Help?                          | 5   | Synchronous Belt Drives Maintenance | 75 |       |
| Oil Plug Type Locator Drawings      | 84  | Synchronous Drive Belts Maintenance | 77 |       |
| Operator Cleaning Procedures        | 58  | Top Guard Door                      | 46 |       |
| Operator Controls                   | 48  | Troubleshooting                     | 98 |       |
| Operator Guards                     | 15  | Troubleshooting Table               | 99 |       |
| Operators                           | 6   | Using the manual                    | 6  |       |
| Package Count Photoelectric Sensor  | 45  | VFD Fault                           | 55 |       |
| Photoelectric Sensors Maintenance   | 81  | Voltage                             | 52 |       |
| Physical Contact                    | 15  | Warranty Information                | 2  |       |
| Polycarbonate cleaning              | 67  | Weekly Cleaning:                    | 58 |       |
| Pre-startup Procedures              | 56  | Wheel Delay                         | 51 |       |
| Product Count Laser Setup Procedure | 31  | Wheel Stop Photoelectric Sensor     | 46 |       |
| Product Infeed Chute                | 43  | Yellow Warning Icon                 | 49 |       |
| Product Infeed Conveyor             | 44  |                                     |    |       |
| Product Infeed Conveyor Adjustment  | 30  |                                     |    |       |
| Product Infeed Guides Adjustment    | 31  |                                     |    |       |
| Production Data                     | 54  |                                     |    |       |
| Production Data Screen              | 54  |                                     |    |       |
| Pulley alignment                    | 75  |                                     |    |       |
| Purpose                             | 6   |                                     |    |       |
| Quality Trained Personnel           | 5   |                                     |    |       |
| Recommended Cleaning Agents         | 65  |                                     |    |       |
| Recommended Spare Parts List        | 105 |                                     |    |       |
| Red Data Storage Icon               | 49  |                                     |    |       |
| Relubricating the Bearings          | 95  |                                     |    |       |
| Removing Lockout Devices            | 23  |                                     |    |       |
| Replacement                         | 78  |                                     |    |       |
| Replacement Parts                   | 104 |                                     |    |       |
| Replacing the Shaft Sealing Ring    | 95  |                                     |    |       |
| Reprinting This Manual              | 3   |                                     |    |       |
| Reset Output                        | 54  |                                     |    |       |
| Response Time                       | 5   |                                     |    |       |
| Rolling Bearing Maintenance         | 78  |                                     |    |       |
| Routine Cleaning                    | 62  |                                     |    |       |
| Routine Inspection                  | 62  |                                     |    |       |
| Safety During Maintenance           | 18  |                                     |    |       |
| Safety Signs                        | 14  |                                     |    |       |
| Safety Switches                     | 16  |                                     |    |       |



BluePrint Automation  
16037 Innovation Drive  
South Chesterfield, VA 23834-5951  
001 804 520 5400  
[www.blueprintautomation.com](http://www.blueprintautomation.com)

Be sure to follow, like us and subscribe to our social media outlets.

