



OPERATION & SERVICE MANUAL

65-11-7

BEL 505 / BEL 505S

SEMI-AUTOMATIC CASE FORMER
AND PACKING STATION



Wexxar Packaging Inc. a division of Pro Mach 
Phone (604) 270-0811 • Fax (604) 270-7897
E-mail: sales@wexxar.com



SAFETY CAUTION



Although the BEL 505 & 505 'S' packing stations can be used in conjunction with competitive case taper/sealers, BELCOR cannot assume responsibility for safety issues resulting from these applications. **We specifically do not recommend using these packing stations in close proximity with conventional back flap “kickers” and three-flap folders.**

Be sure that:

- the main on/off valve at the air connection is shut off and that the red emergency stop button is pushed down before connecting an air supply to the machine.
- the machine is disconnected from the air source before undertaking any maintenance or service procedures. This is to avoid inadvertent machine actuation that could result in personal injury.

Never leave the machine unattended with the air switch on.

Only qualified personnel must operate the machine!

BEL 505**SEMI-AUTOMATIC CASE FORMER AND PACKING STATION**

Standard Case Size Range:

	Length	Width	Height
Minimum	8" (203mm)	6" (152mm)	3.5" (89mm)
Maximum	26.5" (673mm)	16" (406)	Unlimited
Machine Size	37.5 (953mm)	25 (635mm)	18.5" (470mm) [min]

Case Infeed/Outfeed Height:

- **UHMW Pads:** 21.5" (546mm) [min] 28.5" (724mm) [max]
- **Castors:** 25" (635mm) [min] 32" (813mm) [max]

Power Requirements (standard):

- **Compressed Air:** 80-90 PSI ; 0.1 CF/Cycle

BEL 505 'S'**SEMI-AUTOMATIC CASE FORMER AND PACKING STATION**

Standard Case Size Range

	Length	Width	Height
Minimum	8" (203mm)	5" (127mm)	3.5" (89mm)
Maximum	16" (406mm)	15" (381mm)	Unlimited
Machine Size	27.5" (700mm)	25" (635mm)	22 (560)

Case Infeed/Outfeed Height:

- **UHMW Pads:** 21.5" (546mm) 28.5" (724mm)
- **Castors:** 25" (635mm) 32" (813mm)

Power Requirements (standard):

- **Compressed Air:** 80-90 PSI ; 0.1 CF/Cycle

TABLE OF CONTENTS

INTRODUCTION.....	5
ABOUT THIS MANUAL.....	5
INSTALLATION PROCEDURES	6
INSTALLING THE BEL 505 & 505 ‘S’	6
LEVELLING THE MACHINE	6
AIR CONNECTION	7
OPERATION & ADJUSTMENT PROCEDURES.....	8
MACHINE SET-UP ADJUSTMENTS.....	8
CASE WIDTH	8
CASE LENGTH	9
MAJOR FLAP FOLDER ROLLER PLATES	10
MACHINE OPERATION.....	11
STARTING THE MACHINE	11
ERECTING A CASE.....	11
MACHINE OPERATING CYCLE	12
TROUBLESHOOTING GUIDE	14