

How to Set Driver Parameters on TSC-RS-120

Press .

dp . SPd

Press .

PA . 00.

Select the required parameters with  and .

PA . 10.

Press .

50.

Change the value with ,  and .

100.

Press .

PA . 10.

Set the following parameters that are in the manual,

Servo Amp Parameter

No	Abbreviation	Set up of parameter	Default	Unit	Remarks
02	---	Control mode	0002		Uses in the torque control mode
21	---	Meal time auto tuning set up	0		Ineffective
14	---	1st torque filter time constant	1000	0.01ms	Sets to 10msec
56	---	4th speed setting	6000	r/min	Speed control value
5C	---	Torque command input gain	66	0.1V/100%	Torque reaches 150% in 10 (0.0)V
5E	---	1st torque limit	150	%	
44	---	Numerator of output pulseratio	1500	pulse	Impulses per turn
46	---	Pulse output logic inversion	1		

How to Save Parameters to EEPROM TSC-RS-120

8) Press **M** (MODE).

EE.SET

9) Press **S** (SET).

EEP -.

10) Keep pressing **▲** (for approx.5 sec), then the bars increases as the right Fig. shows.

EEP - -.

- - - - -.

Writing starts.

(displays for only a moment)

StArt

Writing finishes

Fin,Sh.

rESEt.

Error.

Writing completes

Writing error occurs.

If you get **Finish/Reset**, cycle power on the TSC.

If you get **Error**, write the files again and cycle power.