

2.2.6 Motor rotation direction setting

Setting the dip-sw SW1 on control board P-5530* (I³ 3.4 P-5530), the direction of the conveyor drive motor can be changed.
Dip-sw SW2 on control board P-5530* must be set according to each specifications like switching Right/Left.

Table 2-5 DIP-SW SW1 Function

SW1	Conveyor	R type	L type
SW1-1	Seal check Conveyor	ON	OFF
SW1-2	Brush conditioner	ON	OFF
SW1-3	Infeed conveyor	ON	OFF
SW1-4	Bag stabilizer front	ON	OFF
SW1-5	J-belt conveyor	ON	OFF
SW1-6	Reject conveyor	OFF	ON

Table 2-6 DIP-SW SW2 Function

SW2	Status	R type	L type	Remarks
SW2-1	Bag stabilizer rear	ON	OFF	—
SW2-2	Downstream Interlock1	OFF	ON	Refer to 5.2
SW2-3	Downstream Interlock2	ON	OFF	Refer to 5.2
SW2-4	L type			Set On when L type