

# INDEX

## Numerics

|                           |       |
|---------------------------|-------|
| 485 Board (P-5457*) ..... | 13-39 |
| 485 board (P-5457*) ..... | 13-36 |

## A

|                                                 |              |
|-------------------------------------------------|--------------|
| Access address setting procedure .....          | 6-25         |
| Action Over Upper Limit radio button .....      | 8-4          |
| Action Under Lower Limit radio button .....     | 8-4          |
| Active head Tab Screen .....                    | 6-130        |
| ADC Board (P-5576*) .....                       | 13-32, 13-36 |
| ADC board (P-5576*) .....                       | 13-36        |
| ADC firmware error .....                        | 11-14        |
| AFD control stop DF weight<br>lower limit ..... | 6-90, 6-93   |
| AFD Ctroll Mode .....                           | 6-88         |
| AFD Range Setting .....                         | 6-93         |
| AFD Setting Tab Screen .....                    | 6-131        |
| AFV .....                                       | 2-5          |
| AFV COMPENSATION ERROR .....                    | 11-13        |
| AFV Monitor Tab Screen .....                    | 6-103        |
| AFV OUTPUT ERROR .....                          | 11-13        |
| AFV OVERFLOW ERROR .....                        | 11-13        |
| AFV PARAMETER ERROR .....                       | 11-13        |
| AFV Preamp Board (P-5488*) .....                | 13-20        |
| AFV Unit .....                                  | 13-20        |
| AFV ZERO ERROR .....                            | 11-13        |
| Air Dryer .....                                 | 2-7          |
| air dryer .....                                 | 10-5         |
| Air Pressure Adjustment .....                   | 4-5          |
| AMP .....                                       | 6-93         |
| AMP lower limit .....                           | 6-93         |
| AMP upper limit .....                           | 6-93         |
| APPENDIX .....                                  | 13-1         |
| Auto settings of Target Count .....             | 8-11         |
| Auto zero adjustment .....                      | 2-5          |
| AUTO ZERO ERROR .....                           | 11-10        |

## B

|                               |              |
|-------------------------------|--------------|
| Bag On Demand mode .....      | 2-5          |
| Base Unit Feeder .....        | 13-19        |
| Bird's-eye view .....         | 6-84         |
| BLOCK DIAGRAM .....           | 13-45, 13-46 |
| Bonus Adding .....            | 8-3          |
| BS key .....                  | 3-9          |
| BS key (numeric keypad) ..... | 3-8          |

## C

|                                                          |          |
|----------------------------------------------------------|----------|
| CAL Unit .....                                           | 13-31    |
| CAL Unit (CCW-RV-214W-S/05, 08) .....                    | 13-35    |
| Cam Sensor Board (P-5207*) .....                         | 13-28    |
| Camera .....                                             | 3-2      |
| Can not access Master Data! .....                        | 11-15    |
| CANCEL key .....                                         | 3-8, 3-9 |
| CAPS key .....                                           | 3-9      |
| Carrying in and Installing the<br>Weighing Machine ..... | 12-8     |
| CAUSES AND ACTIONS FOR<br>ERRORS AND FAILURES .....      | 11-1     |
| Changing the Operation Level .....                       | 12-20    |
| Check and<br>Adjustment After Installation .....         | 12-17    |
| Check Items at Installation .....                        | 12-25    |
| Checking Assembly Condition of<br>Each Unit .....        | 12-18    |
| Checking Weighing Machine .....                          | 12-8     |
| Cleaning the Unremovable Unit .....                      | 9-13     |
| CLEANUP PROCEDURES .....                                 | 9-1      |
| CLR key .....                                            | 3-9      |
| CLR key (numeric keypad) .....                           | 3-8      |
| Collection chute .....                                   | 2-6      |
| Collection Chute (Cleaning) .....                        | 9-11     |
| Combi. Calcltn Tab Screen .....                          | 6-102    |
| Combination .....                                        | 2-5      |
| Combination Display key<br>(Count display) .....         | 8-16     |
| Combination Display key<br>(Weight display) .....        | 8-15     |

|                                                            |       |
|------------------------------------------------------------|-------|
| Combination Set Tab Screen .....                           | 6-128 |
| Combination Tab Screen .....                               | 6-35  |
| COMMUNICATION ERROR .....                                  | 11-10 |
| Components of the Device .....                             | 2-6   |
| Confirming the dew-point checker of the<br>air dryer ..... | 10-4  |
| Connecting Power Cable and<br>Remote Control Unit .....    | 12-9  |
| Connecting TH Signal Wire .....                            | 12-11 |
| Connecting to Interlocking Device .....                    | 12-14 |
| Connection Diagram .....                                   | 13-45 |
| Connection Diagram<br>(CCW-RV-214W-S/05, 08) .....         | 13-46 |
| Content enter key .....                                    | 3-4   |
| Control Panel Screen .....                                 | 6-20  |
| COPY / Initialize error .....                              | 11-13 |
| Copying All Machine Setting Items .....                    | 6-122 |
| Copying All Preset .....                                   | 6-115 |
| Copying and<br>Editing Registered Product Data .....       | 7-2   |
| Correcting Confirmed Contents .....                        | 3-10  |
| Count Range .....                                          | 6-74  |
| Count Set Weighing .....                                   | 8-9   |
| Current Total Output .....                                 | 4-26  |
| Current Total Screen .....                                 | 6-73  |
| CYCLE OVERLAP ERROR .....                                  | 11-12 |

## D

|                                   |       |
|-----------------------------------|-------|
| Daily Inspection .....            | 10-2  |
| Data Input .....                  | 3-7   |
| Date & Time Setting Screen .....  | 6-27  |
| DDU Board (P-5439*) .....         | 13-28 |
| Destination ID Tab Screen .....   | 6-24  |
| DETACHED HEAD .....               | 11-10 |
| Device Check Tab Screen .....     | 6-105 |
| DF .....                          | 2-6   |
| DF AMP lower limit .....          | 6-90  |
| DF AMP upper limit .....          | 6-90  |
| DF time lower limit .....         | 6-90  |
| DF time upper limit .....         | 6-90  |
| DF weight upper limit .....       | 6-90  |
| Discharge chute .....             | 2-6   |
| Discharge Chute (Cleaning) .....  | 9-12  |
| Discharge completion signal ..... | 2-4   |

|                                              |              |
|----------------------------------------------|--------------|
| Discharging the Products .....               | 4-18         |
| Dispersion feeder .....                      | 2-6          |
| Dispersion Portion .....                     | 9-14         |
| Dispersion table .....                       | 2-6          |
| Dispersion Table (Cleaning) .....            | 9-8          |
| Display & Data Manager Screen .....          | 6-111        |
| Display area .....                           | 3-8          |
| Display During the Operation .....           | 4-20         |
| DivertingTimingHppr Index Screen .....       | 6-136        |
| DMU Board (P-5562*) .....                    | 13-34, 13-38 |
| Drain .....                                  | 2-4          |
| Drain Screen .....                           | 6-40         |
| DRIVE PARAMETER NON-RECEPTION<br>ERROR ..... | 11-12        |
| DRIVE PATTERN CALC ERROR .....               | 11-11        |
| Drive Unit .....                             | 9-14         |
| Drop-down key .....                          | 3-4          |
| DS .....                                     | 2-4          |
| DUC Board (P-5428*) .....                    | 13-26        |
| DUC Board (P-5524*) .....                    | 13-43        |
| DUC Board (P-5579*) .....                    | 13-44        |
| DUC Connector Board (P-5536*) .....          | 13-30        |
| DUC Unit (CCW-RV-214W-S/05, 08) ...          | 13-42        |

## E

|                                                                |             |
|----------------------------------------------------------------|-------------|
| Electrical Unit Layout Drawing .....                           | 13-2        |
| Electrical Unit Layout Drawing<br>(CCW-RV-214W-S/05, 08) ..... | 13-5        |
| element .....                                                  | 10-5, 10-16 |
| Emergency Stop and Restart .....                               | 4-2         |
| Entry guide display area .....                                 | 3-8         |
| Error Clear and Action .....                                   | 11-15       |
| Error Display and Action .....                                 | 11-2        |
| Every Combination Output .....                                 | 4-24        |
| EXC Board (P-5426*) .....                                      | 13-22       |
| Expansion Display key .....                                    | 8-16        |

## F

|                                                          |              |
|----------------------------------------------------------|--------------|
| Failure and Malfunction of the<br>Weighing Machine ..... | 11-17        |
| FDC Board (P-5423*) .....                                | 13-16, 13-18 |
| FDRV Board (P-5424*) .....                               | 13-15, 13-18 |

|                                         |            |
|-----------------------------------------|------------|
| FDRV ERROR .....                        | 11-9       |
| Features of the Device .....            | 2-2        |
| Feeder Adjust Tab Screen .....          | 6-37, 6-45 |
| Feeder Adjustment Index Screen .....    | 6-60       |
| Feeder Adjustment Screen .....          | 6-81       |
| FILE TRANSFER ERROR .....               | 11-14      |
| Finish Prdct Setting Index Screen ..... | 6-50       |
| FPS Board (P-5580*) .....               | 13-41      |
| Full Open Lock Operation .....          | 6-44       |
| Full Open Lock Screen .....             | 6-42       |
| Full scale .....                        | 2-5        |
| FUNCTIONS OF THE OPERATION              |            |
| SCREENS .....                           | 6-1        |

## G

|                           |     |
|---------------------------|-----|
| General Precautions ..... | 1-3 |
|---------------------------|-----|

## H

|                                          |       |
|------------------------------------------|-------|
| Handling Drive Unit .....                | 4-30  |
| Head .....                               | 2-4   |
| Help Function .....                      | 6-29  |
| Hierarchic structure of the screen ..... | 3-6   |
| Hopper Error .....                       | 11-22 |
| HUB Board (P-5425*/P-5535*) .....        | 13-14 |

## I

|                                                        |       |
|--------------------------------------------------------|-------|
| In/Output Signal Tab Screen .....                      | 6-106 |
| Increase/Decrease key (100ms) .....                    | 6-4   |
| Infeed control .....                                   | 2-4   |
| Infeeder .....                                         | 2-4   |
| Infeeder Cntl Set Tab Screen .....                     | 6-137 |
| Initializing All Machine Setting Items ...             | 6-125 |
| Initializing All Preset .....                          | 6-118 |
| Inlet chute .....                                      | 2-6   |
| Inlet Chute (Cleaning) .....                           | 9-8   |
| Input/output signal display .....                      | 6-106 |
| Inputting Alphanumeric Characters and<br>Symbols ..... | 3-9   |
| Inputting Figures .....                                | 3-8   |
| Inspection for Cracks .....                            | 10-13 |

|                                                             |       |
|-------------------------------------------------------------|-------|
| Inspection of Amplitude Strength for<br>Radial Feeder ..... | 10-12 |
| Inspection of Open/Close for<br>Hopper Gate .....           | 10-11 |
| Inspection of Open/Close Roller for<br>Hopper .....         | 10-12 |
| Inspection of Rubber Cover .....                            | 10-14 |
| Inspection of Span (Monthly) .....                          | 10-5  |
| INSTALLATION .....                                          | 12-1  |
| Installation Condition .....                                | 12-2  |
| Installation Procedure .....                                | 12-7  |
| Installing Collection Chute .....                           | 12-12 |
| Installing Discharge Chute .....                            | 12-12 |
| Installing Dispersion Table .....                           | 12-13 |
| Installing Pool Hopper .....                                | 12-14 |
| Installing Radial Trough .....                              | 12-12 |
| Installing Timing Hopper .....                              | 12-11 |
| Installing Timing Hopper Frame .....                        | 12-11 |
| Installing Weigh Hopper .....                               | 12-13 |
| Intended Use of the Device .....                            | 2-2   |
| Interlock signal .....                                      | 2-4   |
| INTRODUCTION .....                                          | 2-1   |
| IS .....                                                    | 2-4   |
| IS-WH .....                                                 | 6-96  |
| Item Tab Screen .....                                       | 6-56  |
| Items and Functions of<br>Remote Control Unit .....         | 3-2   |

## K

|                       |     |
|-----------------------|-----|
| Keyboard screen ..... | 3-7 |
|-----------------------|-----|

## L

|                                                  |       |
|--------------------------------------------------|-------|
| Lamp key .....                                   | 3-4   |
| Layout Drawing for<br>CCW-RV-214W-S/15 .....     | 13-3  |
| Layout Drawing for<br>CCW-RV-214W-S/20, 30 ..... | 13-2  |
| Layout Drawing for<br>CCW-RV-214W-S/50, 70 ..... | 13-4  |
| Layout Setting Tab Screen .....                  | 6-111 |
| Lifting Procedure .....                          | 12-6  |
| List Display .....                               | 6-47  |
| Loading the Printer Paper .....                  | 4-28  |

|                             |      |
|-----------------------------|------|
| LOW PRODUCT .....           | 11-9 |
| Low Product Time .....      | 6-76 |
| Lower Count Limit key ..... | 8-9  |
| Lower Weight Limit .....    | 6-65 |
| Lower weight limit .....    | 2-4  |

**M**

|                                                      |          |
|------------------------------------------------------|----------|
| Machine Set Mngr Tab Screen .....                    | 6-119    |
| Machine Set Pop-up Menu .....                        | 6-97     |
| Machine Tab Screen .....                             | 6-54     |
| Main Body .....                                      | 9-14     |
| Main Electrical Unit .....                           | 13-13    |
| Main Electrical Unit<br>(CCW-RV-214W-S/05, 08) ..... | 13-17    |
| Main Menu Screen .....                               | 6-30     |
| Main power switch .....                              | 2-7, 3-2 |
| MAINTENANCE AND<br>INSPECTION .....                  | 10-1     |
| Manual Adjustment Screen .....                       | 6-98     |
| Master mode .....                                    | 2-4      |
| MAX Count .....                                      | 6-74     |
| MAX Piece Weight .....                               | 6-75     |
| MAX Weight .....                                     | 6-74     |
| Mean Count .....                                     | 6-74     |
| Mean Piece Weight .....                              | 6-74     |
| Mean Weight .....                                    | 6-74     |
| Menu key .....                                       | 3-3      |
| Message Board .....                                  | 6-10     |
| Metal Detect .....                                   | 6-75     |
| MIN Count .....                                      | 6-74     |
| MIN Piece Weight .....                               | 6-75     |
| MIN Weight .....                                     | 6-74     |
| Module Set .....                                     | 10-17    |
| module set .....                                     | 10-5     |
| MPS Board (P-5436*) .....                            | 13-15    |
| Multiple dump weighing .....                         | 2-5      |

**N**

|                                                                    |       |
|--------------------------------------------------------------------|-------|
| Network Analyze Tab Screen .....                                   | 6-107 |
| NETWORK ERROR .....                                                | 11-8  |
| New Product Registration by<br>Using Registered Product Data ..... | 7-2   |

|                                |             |
|--------------------------------|-------------|
| No data in Master Memory ..... | 11-15       |
| No Paper .....                 | 4-28        |
| NO RESPONSE .....              | 11-9, 11-21 |
| NO TRANSMISSION .....          | 11-9, 11-21 |
| Numeric Keypad screen .....    | 3-7         |

**O**

|                                                       |             |
|-------------------------------------------------------|-------------|
| OPERATING PANELS .....                                | 3-1         |
| Operation Environment .....                           | 2-2         |
| Operation Keys and Operation Levels .....             | 6-2         |
| Operation Log Screen .....                            | 6-80        |
| Operation Outline .....                               | 2-8         |
| Operation Panel .....                                 | 3-2, 3-3    |
| Operation Panel and Data Input .....                  | 3-3         |
| OPERATION PROCEDURES .....                            | 4-1         |
| Optimum feeder value range .....                      | 6-84        |
| OPTIONAL FUNCTIONS .....                              | 8-1         |
| Others Tab Screen .....                               | 6-59        |
| Outline of the Production .....                       | 4-3         |
| Outline of the Registration .....                     | 5-5         |
| Output destination setting procedure .....            | 6-25        |
| Output During Count Set Production .....              | 8-17        |
| Outputting the Operational Status .....               | 4-24        |
| Outside Dimension .....                               | 2-2         |
| Over Scale .....                                      | 6-75        |
| Over Weight .....                                     | 6-75        |
| Overall Block Diagram .....                           | 13-6        |
| Overall Block Diagram<br>(CCW-RV-214W-S/05, 08) ..... | 13-7        |
| OVERSCALE .....                                       | 11-10       |
| Overscale .....                                       | 2-4         |
| OVERSCALE ERROR .....                                 | 11-5, 11-22 |
| Overweight .....                                      | 2-4         |
| OVERWEIGHT ERROR .....                                | 11-4, 11-10 |

**P**

|                         |      |
|-------------------------|------|
| Packer .....            | 2-4  |
| Page display keys ..... | 3-4  |
| Parent 1 Total Wt ..... | 6-75 |
| Parent 2 Total Wt ..... | 6-75 |
| Parent 3 Total Wt ..... | 6-75 |
| Parent 4 Total Wt ..... | 6-75 |

|                                             |           |
|---------------------------------------------|-----------|
| Parent and Child Mix Weighing .....         | 8-2       |
| Parent and Child radio button .....         | 8-3       |
| Parent and Child Weighing .....             | 8-2       |
| Parent Dump Mode radio button .....         | 8-4       |
| Parent Hd. Participation radio button ..... | 8-3       |
| Parent Head Count radio button .....        | 8-3       |
| Parent Head No. key .....                   | 8-5       |
| Parent Head Setting index .....             | 8-        |
| Parent Infeed Delay key .....               | 8-6       |
| Parent Lower Weight key .....               | 8-5       |
| Parent RF Drive radio button .....          | 8-6       |
| Parent Upper Weight key .....               | 8-5       |
| Parent Zero Adjust key .....                | 8-4       |
| Password .....                              | 6-16      |
| Password Set/LangSlct Set Tab Screen ....   | 6-23      |
| Pattern 1 .....                             | 11-3      |
| Pattern 2 .....                             | 11-7      |
| Pattern 3 .....                             | 11-9      |
| Pattern 4 .....                             | 11-12     |
| Pattern 5 .....                             | 11-13     |
| Pattern 6 .....                             | 11-14     |
| Pattern 7 .....                             | 11-14     |
| Pattern 8 .....                             | 11-14     |
| Pckr Intrlck Set Index Screen .....         | 6-133     |
| Pckr Intrlck Set Tab Screen .....           | 6-132     |
| Periodical Inspection .....                 | 10-5      |
| Peripheral Equipment Setting Screen ....    | 6-131     |
| PH .....                                    | 2-6       |
| PH ON .....                                 | 6-96      |
| Photo Display .....                         | 6-46      |
| Photo Sensor Board (P-5207*) .....          | 13-31     |
| PH-RF .....                                 | 6-96      |
| PIECE WEIGHT ERROR .....                    | 11-7      |
| Piece Weight key .....                      | 8-9, 8-16 |
| Piece Weight Revision .....                 | 8-12      |
| Piece Weight Revision radio button .....    | 8-10      |
| Pool Hopper .....                           | 9-9       |
| Pool hopper .....                           | 2-6       |
| Pop-up key .....                            | 3-4       |
| POWER ERROR .....                           | 11-11     |
| Power Supply Shut Off and Indication ....   | 1-10      |
| Preamp Board (P-5435*) .....                | 13-19     |
| Preamp Board (P-5527*) .....                | 13-30     |
| Precaution for Lifting .....                | 12-4      |
| Precaution for Transporting .....           | 12-3      |

|                                                         |           |
|---------------------------------------------------------|-----------|
| Preset .....                                            | 2-5, 5-2  |
| Preset Change Operation .....                           | 6-67      |
| Preset Management .....                                 | 5-18      |
| Preset Manager Tab Screen .....                         | 6-112     |
| Preset Output .....                                     | 6-70      |
| Preset Procedures .....                                 | 5-6       |
| Preset Screen .....                                     | 6-48      |
| Preset Selection .....                                  | 4-10      |
| Pre-start Inspection .....                              | 4-4, 10-2 |
| Printer .....                                           | 2-7, 3-2  |
| PRN Board .....                                         | 13-11     |
| Product flow outline .....                              | 2-8       |
| Product Off Time .....                                  | 6-76      |
| Product On Time .....                                   | 6-75      |
| Product Photo Taking Procedures .....                   | 6-52      |
| Product Tab Screen .....                                | 6-51      |
| Production Procedures .....                             | 4-4       |
| Production Screen .....                                 | 6-33      |
| Production Screen of Parent and<br>Child Weighing ..... | 8-8       |
| Production Speed .....                                  | 6-74      |
| Products .....                                          | 2-4       |
| Program Number Tab Screen .....                         | 6-108     |
| Proper .....                                            | 6-74      |
| Proper weight .....                                     | 2-4, 8-17 |
| PS FEEDER Unit .....                                    | 13-40     |
| PS-0 Unit .....                                         | 13-24     |
| PS-2 Unit .....                                         | 13-25     |

**Q**

Quantity per \* mark ..... 8-18

## R

|                                            |      |
|--------------------------------------------|------|
| Radar chart .....                          | 6-84 |
| Radar chart display switching arrow key .. | 6-2  |
| Radial feeder .....                        | 2-6  |
| Radial trough .....                        | 2-6  |
| Radial Trough(cleaning) .....              | 9-9  |
| Radio button .....                         | 3-4  |
| Range .....                                | 2-5  |
| RCU .....                                  | 2-7  |
| RCU Board .....                            | 13-9 |

|                                                      |              |
|------------------------------------------------------|--------------|
| RCU fan stopped. Contact to<br>factory service. .... | 11-10, 11-15 |
| RECHECK ERROR .....                                  | 11-8, 11-11  |
| Recheck Error .....                                  | 6-75         |
| Reducing Product Change Time .....                   | 7-5          |
| REGISTERING OF PRODUCTS .....                        | 5-1          |
| Registration Details .....                           | 5-2          |
| Relay Board (P-5506*) .....                          | 13-22        |
| Relay Unit .....                                     | 13-21        |
| Remote Control BOX Unit .....                        | 13-8         |
| Remote control unit .....                            | 2-7          |
| Remote Control Unit (Cleaning) .....                 | 9-15         |
| Replacement of Fuses .....                           | 10-15        |
| Replacement of<br>Memory Backup Battery .....        | 10-15        |
| Replacement of the<br>Air Dryer Element .....        | 10-16        |
| Replacement of the<br>Air Dryer Module Set .....     | 10-17        |
| Restarting .....                                     | 4-23         |
| Return key .....                                     | 3-9          |
| Return key (numeric keypad) .....                    | 3-8          |
| RF .....                                             | 2-6          |
| RF AMP lower limit .....                             | 6-90         |
| RF AMP upper limit .....                             | 6-90         |
| RF time lower limit .....                            | 6-90         |
| RF time upper limit .....                            | 6-90         |
| RingShutter Index Screen .....                       | 6-134        |

## S

|                                                           |             |
|-----------------------------------------------------------|-------------|
| S.D. Count .....                                          | 6-74        |
| S.D. Piece Weight .....                                   | 6-75        |
| S.D. Weight .....                                         | 6-74        |
| SAFETY .....                                              | 1-1         |
| Screen Control Tab Screen .....                           | 6-21        |
| Scroll bar .....                                          | 3-5         |
| Scroll key .....                                          | 3-5         |
| Scrolling the screen .....                                | 3-5         |
| Section .....                                             | 2-4         |
| Sectioning Set Tab Screen .....                           | 6-129       |
| Select Display Menu<br>(Production Screen) .....          | 4-22        |
| Select Display Menu in<br>Production Screen .....         | 4-22        |
| Select Display Pop-up Menu .....                          | 6-36        |
| Select Display Pop-up Menu<br>(Count Set Weighing) .....  | 8-15        |
| Select Preset Screen .....                                | 6-46        |
| Select Total Pop-up Menu .....                            | 6-72        |
| Selecting and<br>Copying Machine Setting Items .....      | 6-121       |
| Selecting and Copying Preset .....                        | 6-113       |
| Selecting and<br>Initializing Machine Setting Items ..... | 6-124       |
| Selecting and Initializing Preset .....                   | 6-117       |
| Selecting the photo .....                                 | 5-14        |
| Selecting the preset number directly .....                | 4-12        |
| Self-diagnosis Screen .....                               | 6-104       |
| Set item display area .....                               | 3-8         |
| Setting .....                                             | 5-15        |
| Setting Items of Count Set Weighing .....                 | 8-9         |
| Setting Items of Parent and<br>Child Weighing .....       | 8-3         |
| Setting Procedures of<br>Count Set Weighing .....         | 8-13        |
| Setting Procedures of Parent and<br>Child Weighing .....  | 8-6         |
| Setting the Product .....                                 | 5-11        |
| Setting the Speed .....                                   | 5-15        |
| Setting the Speed (Preset) .....                          | 5-15        |
| Setting the Weight Value .....                            | 5-16        |
| SHIFT key .....                                           | 3-9         |
| Shutter Drive radio button .....                          | 6-4         |
| Slave mode .....                                          | 2-4         |
| Space key .....                                           | 3-9         |
| Span .....                                                | 2-4         |
| Span Adjustment .....                                     | 10-8, 12-23 |
| SPAN ERROR .....                                          | 11-8, 11-21 |
| Special Precautions .....                                 | 1-7         |
| Specifications of the Device .....                        | 2-2         |
| STAGGER .....                                             | 6-96        |
| Stagger .....                                             | 2-4         |
| Standard Specifications .....                             | 2-2         |
| Start Time .....                                          | 6-73        |
| Starting the Production .....                             | 4-16        |
| Start-Up Assistant .....                                  | 6-14        |
| Status display .....                                      | 3-3         |
| STEPPING MOTOR DRIVE ERROR ..                             | 11-11       |
| Stop Time .....                                           | 6-73        |
| Stopping the Production .....                             | 4-17        |

|                                                                |      |
|----------------------------------------------------------------|------|
| Stroke On Demand mode .....                                    | 2-4  |
| Switching Display in<br>Feeder Adjust Screen .....             | 6-86 |
| Switching the display for the<br>Preset Selection Screen ..... | 4-11 |
| Switching to Installation Level .....                          | 6-19 |
| Switching to Operator Level .....                              | 6-17 |
| Switching to Site Engineer Level .....                         | 6-18 |

## T

|                                                   |              |
|---------------------------------------------------|--------------|
| Target Count key .....                            | 8-9          |
| Target Weight .....                               | 6-64         |
| Target weight .....                               | 2-4          |
| Temporary Stop and Restart .....                  | 4-23         |
| Temporary Stopping .....                          | 4-23         |
| Term Description .....                            | 2-4          |
| Test Drive Tab Screen .....                       | 6-109        |
| TH .....                                          | 2-7          |
| Time .....                                        | 6-93         |
| Time lower limit .....                            | 6-93         |
| Time upper limit .....                            | 6-93         |
| Timing Adjustment Index Screen .....              | 6-62         |
| Timing Adjustment Screen .....                    | 6-95         |
| Timing Adjustment Tab Screen .....                | 6-37         |
| Timing hopper .....                               | 2-7          |
| Timing Hopper (Cleaning) .....                    | 9-12         |
| Timing hopper drive unit .....                    | 2-7          |
| TimingHopper Index Screen .....                   | 6-136        |
| Total Count .....                                 | 6-74         |
| Total Data Tab Screen .....                       | 6-38         |
| TOTAL DIAGRAM .....                               | 13-45, 13-46 |
| Total Overflow .....                              | 11-14        |
| Total Setting Screen .....                        | 6-79         |
| Total value .....                                 | 8-17         |
| Total Weight .....                                | 6-74, 6-75   |
| TP-I/F Board (P-5573*) .....                      | 13-11        |
| Transportation and Lifting .....                  | 12-3         |
| Troubleshooting .....                             | 11-21        |
| Turning the<br>Control Unit Power Switch ON ..... | 4-6          |
| Turning the<br>Device Power Switch OFF .....      | 4-19         |
| Turning the Device Power Switch ON .....          | 4-6          |
| Turning the Power ON .....                        | 12-19        |

|                                          |     |
|------------------------------------------|-----|
| Types of Parent and Child Weighing ..... | 8-2 |
|------------------------------------------|-----|

## U

|                                                    |      |
|----------------------------------------------------|------|
| Under .....                                        | 6-75 |
| Underweight .....                                  | 2-4  |
| Unpacking Procedure .....                          | 12-8 |
| Upper Count Limit key .....                        | 8-9  |
| Upper setting bar .....                            | 3-3  |
| Upper Weight Limit .....                           | 6-64 |
| Upper weight limit .....                           | 2-4  |
| USB .....                                          | 6-26 |
| USEFUL FUNCTIONS .....                             | 7-1  |
| Using Feeder Adjustment of<br>Drain Function ..... | 7-5  |
| Using Full Open Lock Function .....                | 7-7  |

## V

|                                        |       |
|----------------------------------------|-------|
| Various Parameter Setting Screen ..... | 6-126 |
|----------------------------------------|-------|

## W

|                                                  |              |
|--------------------------------------------------|--------------|
| Warning Label .....                              | 1-9          |
| Warning Label Handling .....                     | 1-9          |
| Warning Terms and Meaning .....                  | 1-2          |
| Washing and Sterilization .....                  | 9-2          |
| Washing and Sterilization Methods .....          | 9-4          |
| Washing and Sterilizing of Components .....      | 9-7          |
| Washing Removable Unit .....                     | 9-7          |
| WCU Board (P-5561*) .....                        | 13-33, 13-37 |
| WDU .....                                        | 2-6          |
| Weigh Drive Unit .....                           | 13-26        |
| Weigh drive unit .....                           | 2-6          |
| Weigh Drive Unit<br>(CCW-RV-214W-S/05, 08) ..... | 13-29        |
| Weigh Hopper .....                               | 9-9          |
| Weigh hopper .....                               | 2-6          |
| Weigh Spec Set Tab Screen .....                  | 6-127        |
| Weighed value .....                              | 2-4          |
| Weigher Setting Screen .....                     | 6-130        |
| Weigher Speed .....                              | 6-74         |
| Weigherxd5 s Transitional Data Screen .....      | 6-77         |
| Weighing Adjst Tab Screen .....                  | 6-98         |

|                                                              |                         |
|--------------------------------------------------------------|-------------------------|
| Weight .....                                                 | 6-93                    |
| Weight Display Tab Screen .....                              | 6-39                    |
| Weight of Device, Center of Gravity, and<br>Dimensions ..... | 12-5                    |
| Weight Range .....                                           | 6-74                    |
| Weight range .....                                           | 8-18                    |
| Weight Setting Index Screen .....                            | 6-63                    |
| WH .....                                                     | 2-6                     |
| WH ON .....                                                  | 6-96                    |
| WH-DS .....                                                  | 6-96                    |
| WH-PH .....                                                  | 6-96                    |
| WP specification ...                                         | 4-5, 10-4, 10-16, 10-17 |

## **X**

|                          |      |
|--------------------------|------|
| X-bar Chart Screen ..... | 6-76 |
|--------------------------|------|

## **Z**

|                              |                   |
|------------------------------|-------------------|
| Zero Adjustment .....        | 4-12, 12-21       |
| Zero Adjustment Screen ..... | 6-32              |
| ZERO ERROR .....             | 11-3, 11-7, 11-21 |



# MODIFICATION HISTORY

| Version | Date      | Part Number     | Changes                                                                                    |
|---------|-----------|-----------------|--------------------------------------------------------------------------------------------|
| 1       | 2012 - 12 |                 |                                                                                            |
| 2       | 2013 - 05 | 000-143-9007-10 | Device plate is replaced.                                                                  |
| 3       | 2013 - 10 | 000-143-9007-29 | Revised according to software update.<br>(Software set version: 4.06)                      |
| 4       | 2014 - 02 | 000-143-9007-38 | Preset screen is changed.                                                                  |
| 5       | 2015 - 06 | 000-143-9007-39 | Replace Fig.6-27, 29, 30<br>Replaced the block diagram,<br>000-107-2454-00, in chapter 13. |





**ISHIDA CO., LTD.**

---

44 SANNO-CHO SHOGON SAKYO-KU,  
KYOTO 606-8392 JAPAN  
TEL/+81 75-771-4141  
FAX/+81 75-751-1634

---

[www.ishida.co.jp](http://www.ishida.co.jp)

