



## 2 INTRODUCTION

RAUMAK MÁQUINAS Ltda. is a family company founded in 1981, located in the city of Jaraguá do Sul / Santa Catarina / Brazil.

In the beginning, its main activity was the manufacture of semi-automatic packaging machines. Always attentive to the needs of the market and in search of development, in 1984 began to manufacture automated equipment.

Currently the company is dedicated to produce solutions and equipment for conditioning and handling of products, offering the market a large portfolio of equipment. Its technology is employed in several sectors of the national industry and exports its technology to 35 countries, becoming a world reference.

RAUMAK prioritizes the development of new products, being always in search of the most recent technological innovations in the sector. For that, it counts on a team of designers, engineers and specialized technicians reaching the best results and equipment efficiency.

Considering the development of the packaging market in general, we, RAUMAK MACHINERY, developed the MULTI BAG G, a modern and functional equipment, which brings the latest technology applied in the area along with a bold design.

This conception is the result of constant improvements in our department of product engineering and research, always seeking the total satisfaction of our customers.

Congratulations on purchasing RAUMAK products. We know that at the time of this acquisition, our relationship does not end, but begins.

*The Management.*



### 3 GENERAL INFORMATION

This manual contains detailed information regarding the correct installation, operation and maintenance routines for the MULTI BAG G. Read carefully all the instructions before operating the equipment, only this way will guarantee the best performance and useful life of the equipment, as well as your own safety.

In case of spare or replacement parts orders, below you will find instructions and identified drawings which make the consultation and request quick and simplified, saving time and money of your company.

During the use of this equipment, a good discernment of the information and extreme care is necessary on the part of all the operators. The dimensions and specifications of parts and accessories mentioned in this manual are subject to change without notice.

We will be at your disposal for any clarifications that may be necessary.

#### 3.1 Equipment Nameplate

There is an identification plate located on the bottom of the equipment. It can identify important and vital characteristics for the equipment.



1. Equipment model;
2. Year of manufacture;
3. MULTI BAG G voltage;
4. Serial number of the MULTI BAG G;
5. Frequency of the MULTI BAG G;
6. Net weight of the MULTI BAG G;
7. Power of the MULTI BAG G.



## 3.2 Receipt and Inspection

All RAUMAK equipment, besides being manufactured with high quality components and materials, are carefully tested and inspected before leaving the factory.

On receipt, check that:

1. All the components have reached good condition.
2. The nameplate of the MULTI BAG G corresponds to the type of equipment purchased.

If any component with problems is detected, the following actions should be taken:

- Inform the driver of any damaged parts. If the transport is hired or performed by RAUMAK, the parts will be replaced in guarantee. If it is hired or executed by the client, the damage will be the responsibility of the client.
- Formalize the claim describing the damage, attach photos and send to RAUMAK containing the driver's signature and responsible for receiving (customer). Raumak will assess on a case-by-case basis and give an opinion as to whether the problem will be covered by the warranty or not.
- During transportation or unloading, if it is necessary to lift the equipment, use suspension eyebolts that are located in the four corners of the machine's roof.



**Under no circumstances should the equipment be unpacked or installed without the presence of an authorized Raumak representative. Authorized personnel should only do transport and unloading of the machine and only they should be in the travel area.**



**Failure to comply with the specifications described in this section will result in loss of warranty. Raumak points out that it is exempt from any damage caused by improper transportation or storage if it is not a contracting party to the transportation or performs the unloading without the presence of an authorized responsible person.**