



7 INSTALLATION

This chapter describes the electrical, pneumatic, and mechanical installation procedures of the MULTI BAG G. The guidelines and suggestions must be followed aiming at the safety of people, equipment and the correct operation of the MULTI BAG G.

7.1 Mechanical Installation

7.1.1 Environmental conditions

Avoid

- Direct exposure to sunlight, rain, excessive moisture or sea breeze;
- Excessive vibration;
- Corrosive or explosive gases or liquids;
- Dust, oil or metal particles suspended in the air.

Conditions for installation

- Ambient temperature: 0 °C to 50 °C - rated conditions (measured around the equipment)
- Location defined and available for installation (layout defined in purchase);
- The floor must be correctly levelled;
- Packaging (box) according to sample or specification.

7.1.2 Leveling

It is the responsibility of the customer that the place where the machine will be installed is leveled, however, in practice it is often observed the misalignment of the floor. To check the leveling of the machine, use a professional water level under the roof of the equipment in the longitudinal and transverse direction at various points. To adjust possible irregularities, adjust the column shoes (example below).

7.2 Pneumatic Installation



Caution: Make sure that the pneumatic power supply is disconnected before starting the connections.



Attention: Check the compressed air network, which must be dry and free of water condensation and ensure stable pressure of 6 - 7 Bar at a flow rate of up to 800 l/min.

The quality of the compressed air is directly linked to the proper functioning of the pneumatic system of the equipment, therefore, it is necessary that the compressed air supplied to the machine is clean, free of water, oil, and other impurities coming from the compressor and the pneumatic system. It is also necessary that the system is sized, capable of producing the necessary quantity to supply the consumption of the machine (check technical specifications).

In order to ensure the integrity of the equipment, Raumak establishes that the compressed air supplied to the equipment is clean and dry. We recommend the use of compressors with lung and the installation of a safety record on the line for possible maintenance stops.

Ensuring these conditions, the equipment will have an extended useful life and maximum use and productivity. Non-compliance with these specifications, in case of damage, will not be covered by the Warranty Certificate.

This machine is equipped with pneumatic components that are used to move mechanical parts at high speed, therefore all care must be taken.

To perform any manual procedure safely, it is necessary to depressurize or interrupt the pneumatic supply.

Raumak recommends that the operator and maintainers familiarize themselves with the diagram and the pneumatic components installed in the equipment before commencing operation.

Maintenance and repairs should only be performed by qualified or appropriately trained personnel.

7.3 Electrical Installation



Danger: Make sure that the power supply is disconnected before starting connections.



Caution: Check the electrical power grid, which must correspond to the voltage and frequency defined at the time of purchase, respecting the maximum oscillation tolerance of 5%.

The equipment should be properly installed and powered only by an authorized Raumak technician. Before powering up the equipment, it is vital that the unit is properly grounded.

The equipment requires a three-phase power line as specified on the machine nameplate. The power cables of Raumak equipment are the responsibility of the customer, i.e., the machines have only the input power connectors to avoid splicing. For electrical connections and installation, always use certified cables that meet the requirements of NR 10 and NBR5410 standards.

The equipment has a general grounding system, located and identified inside the electrical panel. This must be connected to the appropriate grounding system and must guarantee a low impedance. Electrical grounding is for human and equipment protection, being the responsibility of the customer. Raumak recommends consultation with a qualified professional in this area.

Before powering up the machine, check the following points:

- Machine voltage according to customer voltage;
- Electrical conductors properly fastened;
- Doors properly closed;
- General switch in off position (0).

Maintenance and repairs must be carried out only by qualified persons or with appropriate training and before any procedure (cleaning, repairs, adjustments or replacement work) is carried out by the operator, he must be certain that the equipment is completely safe.