

TSC-RS System Diagnosis Testing

Manually Run Motors

POWER button must be OFF to perform

Go into Maintenance Level

Step 1. Press MACHINE Tab

Step 2. System Diagnosis

GPIO Tab

a. Toggle GPO-01 (KM2 Starter)

Corresponding Toggle Switch

SS10

BL-MOTOR Tab

a. Toggle BLM * -RUN (specific motor that you want to view)

b. Input BLM * -DA (speed value, probably about 100)

List of Motors & Descriptive

BLM-0 Seal Check Conveyor (Upper & Lower)

SS11

BLM-1 Brush Conditioner Conveyor

SS13

BLM-2 Infeed Conveyor

SS12

BLM-3 Bag Stabilizer Front (Only on Atlas)

SS14

BLM-4 J-Belt Conveyor

SS15

BLM-5 Reject Conveyor

SS21

BLM-6 Bag Stabilizer Rear (Only on Atlas)

SS16

Manually Check Inputs or Outputs

Go into Maintenance Level

Step 1. Machine Parameter

Step 2. System Diagnosis

GPIO Tab

a. Toggle GPO-13 (Reject Air Jet SV Right)

b. Toggle GPO-14 (Reject SV Up/Down Cylinder)

c. Toggle GPO-15 (Reject Air Jet SV Left)

