

12 Further information

12.1 Modbus RTU Serial Communications

Refer to Honeywell document 51-52-25-66 Modbus RTU Serial Communications User Manual.

12.2 Modbus Messaging on TCP/IP

Refer to Honeywell document 51-52-25-121 MODBUS Messaging on TCP/IP Implementation Guide.

12.3 How to Apply Digital Instrumentation in Severe Electrical Noise Environments

Refer to Honeywell document 51-52-05-01 How to Apply Digital Instrumentation in Severe Electrical Noise Environments.

13 Index

A

Aborting Accutune	115
Accutune Error Codes	115
Accutune III.....	4, 109
Accutune Set Up Group	48
Alarm Blocking	91
Alarm Hysteresis	90
Alarm Outputs	13
Alarm Relay Output Failure	165
Alarm Relays	17
Alarm Setpoints	118
Alarm Setpoints Display.....	119
Alarms	3
Alarms Set Up Group	87
Algorithm Set Up Group	50
Analog Input Signal Failure Operation	12
Analog Inputs	2, 12
Annunciators	100
Application Related Problems	154
Approval Body Options	4
Auto Bias.....	73
Auto/Manual Key	99
Automatic With Local Setpoint.....	105
Automatic With Remote Setpoint.....	105
Autotune Is Complete.....	116
Auxiliary Output	78
Auxiliary Output	3
Auxiliary Output Calibration.....	146
Auxiliary Output Connections.....	34
Auxiliary Output Failure	169
Auxiliary Output Range	79

B

Background Tests	157
Baud Rate	84
Bias	65, 69
Burnout Protection	66, 69

C

Calibration Mode.....	142, 151
Calibration Steps	133
Carbon Potential.....	57
Carbon Potential Selections.....	55
CE Conformity (Europe)	8
CE Mark	4
Changing Control Modes	106
Changing The Local Setpoints	107
Communications.....	3
Communications Failure	167
Communications Group	84
Communications Selection.....	84

Composite Wiring Diagram.....	24
Computer Setpoint.....	190
Configuration.....	36
Configuration Data	185
Configuration Parameters	192
Configuration Procedure	39
Configuration Prompt Hierarchy	37
Configuration Record Sheet	94
Control Algorithm	50
Control And Alarm Relay Contact Information	17
Control Mode Definitions.....	105
Control Modes	105
Control Relays	17
Control Set Up Group.....	71
Control/Alarm Circuit Wiring	20
Controller Dropoff Value	75
Controller Failure Symptoms	159
Controller Grounding	20
Controller Output Types.....	13
Current Duplex	61
Current Output.....	31
Current Output.....	63
Current Output 2.....	78
Current Output Failure Symptoms.....	161
Current Outputs	13
Current Proportional Output Calibration	144
Current Simplex.....	60
Current/Time Duplex.....	61
Current/Time Or Time/Current Proportional Output Failure.....	164
Customer Support.....	155
Cycle Number.....	188
Cycle Time (Cool).....	42
Cycle Time (Heat)	42
Cycles Remaining.....	188

D

Data Security	4
Data Transfer	185
Deadband.....	75
Decimal Point Location	92
Declaration Of Conformity.....	9
Demand Tuning	48
Dewpoint	55
Diagnostic.....	91
Diagnostic Alarm.....	91
Diagnostic Messages	102
Diagnostic/Failsafe Outputs	4
Digital Input (Remote) Operation.....	131
Digital Input Combinations	83

Digital Input Selections	80
Digital Inputs	2, 12
Digital Inputs Option Connections	34
Digital Output Status	62
Dimensions	18
Direct Acting Control	74
Display Indicators	6
Dual Electromechanical Relay Option Output	31

E

Elapsed Time	108
Electrical Considerations	20
Electrical Noise Precautions	20
Electromechanical Relay Output	28
Electromechanical Relays	13
Emc Classification	9
Emissivity	67, 70
Enclosure Rating	9
End Segment Number	126
Environmental And Operating Conditions	14
Equipment You Will Need To Calibrate	135
Error Codes	115
Error Messages	102
Estimated Motor Position	120
Ethernet	7
Ethernet Communications Failure	168
Ethernet Tcp/Ip	221
Ethernet Tcp/Ip Communications Interface	14
Ethernet Tcp/Ip Protocol	84
External Interface Option Connections	33, 34
External Setpoint Program Reset	81
External Wiring	21

F

Factory Calibration	141, 151
Failsafe Function Prompt	121, 122
Failsafe Manual Mode	156
Failsafe Mode	76
Failsafe Mode	122
Failsafe Output Value	76
Failsafe Output Value	121
Failsafe Output Value For Restart After A Power Loss	121
Failure Modes	4
Fast Tune	4
Feedforward Multiplier	54
Feedforward Summer	53
Field Wiring	135
Filter	66, 69
Function Code 20	178
Function Code 21	182
Function Codes 20 And 21	176
Function Prompts	37
Fuzzy Logic	5
Fuzzy Overshoot Suppression	48, 116

G

Gain	40
Gain 2	41
Guaranteed Soak	127

H

Heat/Cool (Duplex Tune)	5
High Scaling Factor	56
High Select	54
Hot Start	46, 126
Hydrogen Content	57
Hysteresis (Output Relay)	75

I,J

Infrared	7
Infrared Communications	8, 14
Input 1 Actuation Type	64
Input 1 And Input 2 Wiring Terminals	135
Input 1 Calibration Procedure	140
Input 1 Connections	26
Input 1 High Range Value	65
Input 1 Low Range Value	65
Input 1 Set Up Group	64
Input 1 Set Up Wiring	136
Input 2 Actuation Type	68
Input 2 Connections	27
Input 2 Set Up Group	68
Input Calibration	132
Installation	11
Installation Category	9
Installation Related Problems	154
IR Communications Port	84
Isolation	13

K

Key Error	99
Key Lockout	43, 99
Keyboard Failure	166
Keys And Functions	6

L

Latching	122
Line Voltage Wiring	20
Local Setpoint Source	72
Lockout	42
Lockout Feature	98
Lockout Levels	98
Loop Break	88
Low Fire	83
Low Scaling Factor	56
Low Select	54
Lower Display Key Parameter Prompts	101

M

Mains Power Supply	20, 25
Manual	105
Manual Latching	83
Manual Reset	41
Mass Flow Orifice Constant (K) For Math Selections	56
Math Algorithms	53
Math Functions	2
Minimum And Maximum Range Values	133
Modbus	84
Modbus Read, Write And Override Parameters	185
Modbus RTU Exception Codes	219
Modbus RTU Function Codes	176
Model Number Interpretation	15
Moisture Protection	4
Motor Position Display	120
Motor Time	148
Motor Time	62
Mounting	18
Mounting Method	19
Mounting Procedure	19
Multiplier	54
Multiplier Divider	54
Multiplier Divider With Square Root	54
Multiplier With Square Root	54

N

Noise Immunity	4
Non-Latching	122

O

On/Off Algorithm	50
Open Collector Output	30
Open Collector Outputs	13
Operating Parameters	101
Operator Interface	5, 58, 97
Option Status	187
Output Algorithm	60
Output Calibration	143
Output Change Rate	74
Output Rate Down Value	75
Output Rate Up Value	75
Output Types	3
Overriding Controller Setpoint	190
Oxygen	55

P,Q

Parts Identification	174
Parts List	173
PD With Manual Reset	51
Permissible Wiring Bundling	21
Physical Considerations	18
PID A	51
PID B	51

Pollution Degree	9
Position Proportional Connections	32
Position Proportional Output Failure	162
Position Proportional Simplex	60
Power Consumption	14
Power Failure Symptoms	161
Power Inrush Current	14
Power Line Frequency	92
Power Outage	124, 131
Power-Up Tests	156
Pre-Installation Information	12
Process Instrument Explorer	7
Program Contents	125
Program Record Sheet	129
Program State	126
Program Termination State	126
Proportional Band	40
Proportional Band 2	41
Proportional Band Units	76
Purge	82
PV Hot Start	122

R

Ramp Time Or Rate Segments	127
Ramp/Soak Profile Example	128
Rate	40
Rate 2	41
Rate Down Value	45
Rate Up Value	45
Ratio	65, 69
Read Onlys	188
Reading Control Data	186
Recycle Number	126
Register Address Structure	177
Register Count	177
Remote Setpoint Source	73
Removing The Chassis	175
Rerun Current Segment	126
Reset	41
Reset 2	41
Reset Program To Beginning	126
Reset Units	77
Restore Factory Calibration	141, 151
Restoring Factory Configuration	170
Reverse Acting Control	74
RS 485	7
RS422/485 Modbus Rtu Communications Interface	14
RTD Inputs	137
Run/Hold Key	99
Run/Hold Key	123
Run/Monitor The Program	130

S

Security.....	4
Security Code	42
Security Code	97
Segment Time Remaining In Hours	188
Set Point Select Function Key	99
Set Up Group.....	37
Set Up Wiring Procedure For Auxiliary Output	146
Setpoint Code Selections	189
Setpoint High Limit.....	74
Setpoint Low Limit	74
Setpoint Ramp	44
Setpoint Ramp	123
Setpoint Ramp Final Setpoint.....	45
Setpoint Ramp Time.....	44
Setpoint Ramp/Soak Programming	4, 125
Setpoint Rate	45
Setpoint Rate	4, 123
Setpoint Tracking	73
Setpoints	4, 106, 189
Shed Time	85
Slowtune.....	5
Soak Segments	127
Software Type	188
Software Upgrade Part Number	172
Software Upgrades	171
Software Version	188
Software Version Number.....	155
Solid State Relay Output	29
Solid State Relays.....	13
SP Ramp Set Up Group.....	44
SP Tuning.....	48
Specifications	12
Start Segment Number	126
Start Up Procedure For Operation.....	104
Status Tests.....	156
Stray Rejection	12
Summer With Ratio And Bias	54
Suppression Devices	21
Switch Between Two Sets Via Keyboard	118
Switching Between Setpoints	107

T

Temperature Units.....	92
Test Failures	156
Thermocouple Health	2
Thermocouple Inputs Using A Thermocouple Source.....	137
Thermocouple Inputs Using An Ice Bath.....	136
Three Position Control Step Output Start-Up Mode.....	74
Three Position Step	52
Three Position Step Control	148

Three Position Step Control Algorithm.....	120
Three Position Step Control Connections	32
Three Position Step Test Failures.....	156
Time Current Duplex.....	61
Time Duplex	61
Time Proportional Output.....	60
Time Proportional Output Failure	163
Time Remaining	108
Time Simplex	60
Time-Out	109
Timer	4, 108
Timer	52
Transmitter Characterization	65, 69
Transmitter Power	3
Transmitter Power For 4-20 Ma	34, 35
Troubleshooting Aids	154
Troubleshooting Procedures.....	160
Troubleshooting/Service.....	153
Tune.....	110
Tune For Duplex (Heat/Cool)	111
Tuning	40
Tuning Constants.....	4
Tuning Indicators	109
Tuning Parameter Sets.....	71
Tuning Set Up Group	40
Two Sets Of Tuning Constants.....	116
TX Delay	85

U

Universal Output Functionality And Restrictions	22, 23
Universal Switching Power	4

V

Voltage And Resistance Equivalents For 0% And 100% Range Values.....	133
--	-----

W,X,Y,Z

Weight	14
Weighted Average Ratio	56
Wiring.....	20
Wiring Bundling.....	21
Wiring Connections For Calibrating Auxiliary Output.....	146
Wiring Connections For Calibrating Current Proportional Output.....	144
Wiring Connections For Radiamatic, Milliampere, Millivolts, Or Volts (Except 0 To 10 Volts)	138, 139
Wiring Connections For Rtd (Resistance Thermometer Device).....	137
Wiring Diagrams	22
Wiring The Controller	24
Worksheet.....	125
WS Float.....	85

14 Sales and Service

For application assistance, current specifications, pricing, or name of the nearest Authorized Distributor, contact one of the offices below.

ARGENTINA

Honeywell S.A.I.C.
Belgrano 1156
Buenos Aires
Argentina
Tel. : 54 1 383 9290

ASIA PACIFIC
Honeywell Asia
Pacific Inc.
Room 3213-3225
Sun Kung Kai Centre
N° 30 Harbour Road
Wanchai
Hong Kong
Tel. : 852 829 82 98

AUSTRALIA
Honeywell Limited
5 Thomas Holt Drive
North Ryde Sydney
Nsw Australia 2113
Tel. : 61 2 353 7000

AUSTRIA
Honeywell Austria
G.M.B.H.
Handelskai 388
A1020 Vienna
Austria
Tel. : 43 1 727 800

BELGIUM
Honeywell S.A.
3 Avenue De Bourget
B-1140 Brussels
Belgium
Tel. : 32 2 728 27 11

BRAZIL
HONEYWELL DO
Brazil
And Cia
Rua Jose Alves Da
Chunha
Lima 172
Butanta
05360.050 Sao Paulo
Sp
Brazil
Tel. : 55 11 819 3755

BULGARIA
HONEYWELL EOOD
14, Iskarsko Chausse
POB 79
BG- 1592 Sofia
BULGARIA
Tel. : 359-791512/
794027/ 792198

CANADA

Honeywell Limited
The Honeywell Centre
300 Yorkland Blvd.
Toronto, Ontario
M2j 1s1
Canada
Tel.: 800 461 0013
Fax:: 416 502 5001

CZECH REPUBLIC

HONEYWELL,
Spol.S.R.O.
Budejovicka 1
140 21 Prague 4
Czech Republic
Tel. : 42 2 6112 3434

DENMARK

HONEYWELL A/S
Automatikvej 1
DK 2860 Soeborg
DENMARK
Tel. : 45 39 55 56 58

FINLAND

HONEYWELL OY
Ruukintie 8
FIN-02320 ESPOO 32
FINLAND
Tel. : 358 0 3480101

FRANCE

HONEYWELL S.A.
Bâtiment « le Mercure »
Parc Technologique de
St
Aubin
Route de l'Orme
(CD 128)
91190 SAINT-AUBIN
FRANCE
Tel. from France:
01 60 19 80 00
From other countries:
33 1 60 19 80 00

GERMANY

HONEYWELL AG
Kaiserleistrasse 39
D-63067 OFFENBACH
GERMANY
Tel. : 49 69 80 64444

HUNGARY

HONEYWELL Kft
Gogol u 13
H-1133 BUDAPEST
HUNGARY

Tel. : 36 1 451 43 00

ICELAND

HONEYWELL
Hataekni .hf
Armuli 26
PO Box 8336
128 reykjavik
Iceland
Tel : 354 588 5000

ITALY

HONEYWELL S.p.A.
Via P. Gobetti, 2/b
20063 Cernusco Sul
Naviglio
ITALY
Tel. : 39 02 92146 1

MEXICO

HONEYWELL S.A. DE
CV
AV. CONSTITUYENTES
900
COL. LOMAS ALTAS
11950 MEXICO CITY
MEXICO
Tel : 52 5 259 1966

THE NETHERLANDS

HONEYWELL BV
Laaderhoogweg 18
1101 EA AMSTERDAM
ZO
THE NETHERLANDS
Tel : 31 20 56 56 911

NORWAY

HONEYWELL A/S
Askerveien 61
PO Box 263
N-1371 ASKER
NORWAY
Tel. : 47 66 76 20 00

POLAND

HONEYWELL Sp.z.o.o
UI Domaniewska 41
02-672 WARSAW
POLAND
Tel. : 48 22 606 09 00

PORTUGAL

HONEYWELL
PORTUGAL LDA
Edificio Suecia II
Av. do Forte nr 3 - Piso 3
2795 CARNAXIDE
PORTUGAL

Tel. : 351 1 424 50 00

REPUBLIC OF IRELAND

HONEYWELL
Unit 1
Robinhood Business
Park
Robinhood Road
DUBLIN 22
Republic of Ireland
Tel. : 353 1 4565944

REPUBLIC OF SINGAPORE

HONEYWELL PTE LTD
BLOCK 750E CHAI
CHEE ROAD
06-01 CHAI CHEE
IND.PARK
1646 SINGAPORE
REP. OF SINGAPORE
Tel. : 65 2490 100

REPUBLIC OF SOUTH AFRICA

HONEYWELL
Southern Africa
PO BOX 138
Milnerton 7435
REPUBLIC OF SOUTH
AFRICA
Tel. : 27 11 805 12 01

ROMANIA

HONEYWELL Office
Bucharest
147 Aurel Vlaicu Str.,
Sc.Z.,
Apt 61/62
R-72921 Bucharest
ROMANIA
Tel : 40-1 211 00 76/
211 79

RUSSIA

HONEYWELL INC
4 th Floor Administrative
Building of AO "Luzhniki"
Management
24 Luzhniki
119048 Moscow
RUSSIA
Tel : 7 095 796 98 00/01

SLOVAKIA

HONEYWELL Ltd
Mlynske nivy 73
PO Box 75
820 07 BRATISLAVA 27
SLOVAKIA

Tel. : 421 7 52 47
400/425

SPAIN

HONEYWELL S.A
Factory
Josefa Valcarcel, 24
28027 MADRID
SPAIN
Tel. : 34 91 31 3 61 00

SWEDEN

HONEYWELL A.B.
S-127 86 Skarholmen
STOCKHOLM
SWEDEN
Tel. : 46 8 775 55 00

SWITZERLAND

HONEYWELL A.G.
Hertistrasse 2
8304 WALLISELLEN
SWITZERLAND
Tel. : 41 1 831 02 71

TURKEY

HONEYWELL A.S.
Caryiryolu Sok No. 7
Ucgen Plaza, Kat 5-6-7
Icerenkoy 81120
Istanbul
Turkey
Tel (90-216) 575 66 00

UNITED KINGDOM

HONEYWELL
Honeywell House
Arlington Business Park
Bracknell,
Berkshire
RG12 1EB
Tel: +44 (0) 1344 656000

U.S.A.

HONEYWELL INC.
INDUSTRIAL PROCESS
CONTROLS
1100 VIRGINIA DRIVE
PA 19034-3260
FT. WASHINGTON
U.S.A.
Tel. : 1-800-343-0228

VENEZUELA

HONEYWELL CA
APARTADO 61314
1060 CARACAS
VENEZUELA
Tel. : 58 2 239 0211

Honeywell

Industrial Measurement and Control

Honeywell

1100 Virginia Drive

Fort Washington, PA 19034