

SPRAY DYNAMICS

SCARF FEEDER®

INSTALLATION

The machine is furnished fully assembled except for possible removal of components from the frame and blocking/banding to prevent movement during shipping.

- Check for shipping damage before uncrating.
- Remove all banding, blocking, and etc.



Being a balanced unit, no extra attachments of any kind may be added, nor should any part of the unit be in direct contact with other equipment except thru flexible connection. No part of the Scarf Feeder should be modified because this will affect the balance and operation.

For installation guidance, refer to installation drawings included with this manual.

Installing components onto the frame

Place the Scarf Feeder onto the frame so that the mounting holes are visible in the slots of the anti-vibration mounts. Put a bolt thru the large rectangular washer and place the washer on top of the mount. Install and tighten nyloc nut.

Locate the volumetric feeder so that it deposits seasoning no closer than 6" before the product dam in the feeder tray. Cut the transfer tube and auger(s) if required so that they deposit approximately half way across the tray.

Connect the cables from the control panel to the electromagnetic drive and the accelerometer.

Refer to drawings for installation.

Setup and Adjustment

If the Scarf Feeder is seasoning product inside a coating drum position the frame so that the curtain of seasoning falls parallel to the drum wall and near the highest point of the product bed. A good starting point is placing the bottom of the tray midway up the drum or a little above and approximatedly 7" (180 mm) from the side of the drum.

Before starting the machine for production, press the START button. The application rate is controlled by the spice feeder and **NOT** the speed of the scarf feeder.