

SPRAY DYNAMICS

SCARF FEEDER®

NORMAL OPERATION

To start the Scarf Feeder, press the START button on the control panel.

Adjust the Feeder vibration for the most consistent product flow.

After you have determined the best Scarf Feeder vibrator amplitude, note the setting for future use with the same product.

To stop the Scarf Feeder, press the STOP button on the control panel.



SANITATION

Machinery should be cleaned and sanitized on a regular schedule to prevent any microbial formations. Each facility should have its own schedule for cleaning and products used for this purpose. ZEP Superior Solutions has several products used for cleaning, degreasing, and sanitizing equipment in the food industry with offices in the United States, France, Italy, Holland, and the United Kingdom.



When cleaning/sanitizing with liquids make sure the electrical enclosure door is **CLOSED** and latches are secure.

Control panels are washdown, **NOT** high-pressure hose down.

DO NOT use High Pressure Hose on Control Panel: It is recommended that the control panel be covered with plastic or other suitable impermeable material before any wash down procedure.

SPRAY DYNAMICS

SCARF FEEDER®

MAINTENANCE

The only routine maintenance required is:



Check security of electrical components and integrity of connectors before every shift.

Check security of bolts and other fasteners after every 40 hours of operation.



Autotune the controller every 6 months due to changes in natural frequency due to wear of the fiberglass springs. (see below)

If for any reason it becomes necessary to replace parts, the set-up and tuning procedures are as follows:

- Set the air gap (between the drive and armature) to a nominal 1/8" to 5/32" space.
- Autotune the MFS268 controller by running the procedure detailed in the VIBRATORY CONTROLLER section of this manual (also reference the REOVIB MFS 268 manual)



- Ensure that the tray is empty before starting the procedure and that nothing touches the tray while running the process.