



Cleveland Equipment

CE-3000-HVE

Solid-ink Coding Continuous Sealer

Operation Manual



866-888-6327

sales@clevelandequipment.com

4403 Delp Street

Memphis, TN 38118

www.clevelandequipment.com



Contents

I.	Use	2
II.	Safety Precautions	2
III.	Main Specification	3
IV.	Performance Features.....	4
V.	Structure & Working Principle	5
	Diagram 5.1	6
	Diagram 5.2	7
VI.	Operational Use	8
	6.1. Control Panel	8
	Diagram 6.1	8
	6.2. Prepare the machine for use	8
	6.3. Sealing Belt Adjustment / Replacement	9
	Diagram 6.2	9
	6.4. Drive Wheel Block Adjustment	10
	Diagram 6.3	10
	6.5. Conveyor Belt Adjustment / Replacement.....	11
	Diagram 6.4	11
	6.6. Print Wheel Setup.....	12
	Diagram 6.6	12
	6.7. Print Wheel Typeface Setup	13
	Diagram 6.7.....	13
	6.8. Ink Roller and Print Wheel Clearance Adjustment.....	14
	Diagram 6.8.....	14
	6.9. Print Wheel and Silicone Wheel Pressure Adjustment.....	15
	Diagram 6.9.....	15
	6.10. Print Wheel and Ink Roller Temperature Adjustment	16
	6.11. Adjustment of coding position	17
	6.12. Adjustment of number of lines in printing label	17
	6.13. Starting procedure.....	18
VII.	Riser Plate Install.....	19
VIII.	CE-3000-HVE Vertical to Horizotal Guide	22
IX.	CE-3000 Stand Assembly.....	25
X.	Electrical Diagram	28
	Diagram 10.1	28
XI.	Sealing Unit Parts List.....	29
	Diagram 11.1	29
XII.	Conveyer Parts List.....	31
	Diagram 12.1	31
XIII.	Components / Printer Parts List	33
	Diagram 13.1	33
XIV.	CE-3000 HVE Parts Kit	35
XV.	Troubleshooting	36
XVI.	Helpful Links	38



I. Use

This sealer is suitable for sealing all kinds of plastic films, which is widely used in fields of food, medicine, chemicals, etc. It is the best sealing equipment for packing batch products from factories and shops.

II. Safety Precautions

2.1. Make sure the adopted power supply is correct.

The machine adopts AC 110V. The yellow and green wire is the ground wire and cannot be removed.

2.2. After the power is connected, do not touch any electrical parts.

2.3. .

2.4. When the machine is on, do not touch any moving parts.

2.5. When the machine is on, do not touch heating blocks or ink roller heating block.

2.6. Do not operate the machine in a corrosive environment.

2.7. Do not change any parts of the machine.

2.8. Keep the machine clean (both inside and outside), and clear of dirt from sealing belt.

2.9. Oil the gear and sprocket with semiliquid gear oil. Fill and exchange oil in worm-gear box regularly.

2.10. Turn off the power when not use. Allow the machine to run long enough to cool down.

2.11. Keep this manual near the machine, for easy reference.