



XV. Troubleshooting

Problem	Reason	Solution
Sealing belt is off-track.	The Driving wheel shaft is not parallel to the driven wheel shaft.	Adjust two adjusting screws on driven wheel seat.
Sealing belt is easy to break.	1. Too much tension on sealing belt. 2. Sealing belt is off track. 3. Crease on sealing belt. 4. Adhesive film or other dirt attached to sealing belt surface. 5. Sealing belt is easy to burn.	1. Adjust the vertical adjusting screw on driven wheel seat, to loosen sealing belt. 2. (see the point above) 3. No crease on sealing belt. 4. Clean sealing belt surface. 5. Clearance between two heating blocks is too small or temperature is too high.
Embossing is not clear	1. Embossing wheel is worn out. 2. Pressing spring on embossing wheel is not tightened enough.	1. Replace embossing wheel 2. Adjust the embossing wheel's tightening spring
There is resistance when the sealing belt is conveying.	The clearance between heating blocks or cooling blocks is too small, the friction is too much.	Adjust the clearance between sealing belts properly, which should be about the thickness of the packing bag in one layer, to ensure strong sealing and clear printing, and prevent sealing ends from extending too long.
There is a block or fold phenomenon when the packing bag is conveyed to the pressing wheel or embossing wheel.	Too much pressure is caused by the pressing wheel or embossing wheel.	1. Adjust the pressing wheel or embossing wheel to the proper pressure, which should be about the thickness of the packing bag in one layer, to ensure strong sealing and clear printing, and prevent sealing ends from extending too long. 2. Adjust the limiting screw after adjusting clearance.
Conveyor belt is off-track.	The driving roller shaft is not parallel to the driven roller shaft.	Adjust the two adjusting screws of the driven roller shaft (rear shaft) on conveyor.
Conveyor belt and sealing belt don't move synchronously.	Tension on conveyor belt is loose.	1. Tighten the chain of driving roller shaft (front shaft) and middle shaft properly. 2. Tighten the conveyor belt properly.
Ink roller printing mechanism doesn't work.	1. The power supply is not connected. 2. Main control PC board is not inserted in place or poor contact. 3. Main control PC board is damaged.	1. Check whether the power line is connected and indicating light is on. 2. Check whether plug for PC board is inserted in place or wire end falls off. 3. Check and replace PC board.
Printing wheel doesn't work.	1. Start sensor's touching head is blocked. 2. Start sensor is not clean, whose hole is blocked by dust. 3. Main control PC board has been damaged 4. Round pin on clutch falls off or is damaged. 5. Electromagnetic clutch's wire is broken.	1. Clean the obstacle. 2. Clean the dust on sensor's surface. 3. Check and replace PC board. 4. Repair round pin. 5. Repair clutch.
Printing wheel doesn't stop.	1. Sensor (groove sensor) is damaged, moved, or its surface covered by dust. 2. Main control PC board is damaged.	1. Replace or correct position of sensor or clean its surface. 2. Check PC board and replace it.

CE-3000-HVE Band Sealer



Problem	Reason	Solution
No heat for ink roller heating block or printing.	1. Heating pipe or wire is damaged 2. Heating PC board is damaged 3. The potentiometer on knob is damaged 4. Carbon brush seat is not in place. 5. Carbon brush is damaged	1. Replace heating pipe. 2. Replace PC board. 3. Replace potentiometer. 4. Adjust and tighten nut then. 5. Replace.
The temperature of heating block for ink roller printing mechanism is out of control.	The relay for temperature control PC board is damaged.	Check and replace temperature control PC board.
The printing position is out of control.	1. Tightening screw on printing wheel is loose. 2. Main control PC board is damaged.	1. Tighten the screw. 2. Check and replace PC board.