

Maintenance

The Eastey TT Series Rotary Accumulation Table will provide many hours of maintenance free operation. There are a few items that may require attention from time to time.

Shut off power and disconnect electrical connections before cleaning or performing maintenance tasks.

Preventative Maintenance

- ☐ Check and clean the motor to turntable drive chain and sprockets. Clean and lubricate the drive sprockets and chain as required. Check chain tension and adjust as needed.
- ☐ Check the condition of the turntable and sidewall. Check for material stuck onto surfaces or lodged in between turntable and sidewall. Clean or repair and replace as necessary.
- ☐ Check operation of the turntable. It should not wobble and should rotate smoothly and level. Check to make sure the base is level and check to make sure the turntable remains level as it rotates. Check the condition of the support wheels directly under the turntable. Clean the turntable support wheels and remove any accretion and lubricate wheel bearings if necessary. Repair or replace worn or damaged wheels as necessary and adjust to level. See instructions for Turntable Leveling Adjustment in the Adjustments section of this User Guide.
- ☐ Check that you are able to vary the rotational speed. If not, refer to the Adjustments section of this User Guide for instruction. If the turntable rotates in the wrong direction, refer to the Operation section of this User Guide.
- ☐ Check condition of the power cord for wear, especially if it is exposed to traffic.
- ☐ Check for overall wear and repair or replace as necessary.
- ☐ Check for loose fasteners. Tighten as necessary.
- ☐ Check the condition of all warning and instruction labels. Replace as necessary.

Cleaning the Table Top Surface and Sidewall

Make sure the rotating table top and sidewall stay clean and grease free. If either requires a more thorough cleaning, use a soft, lint-free cloth with a mild detergent and water and let dry. **Never use harsh or abrasive cleaners or chemical agents when cleaning any part of the machine.**