

Introduction

Welcome to Hapman,

Where our design and manufacturing of the best material handling equipment is driven by your specific application needs and supported by unparalleled design expertise. For over 70 years, We have been designing and manufacturing the highest in quality and leading-edge technology from our manufacturing facilities in the U.S. and Europe. Hapman products are found in practically every industry worldwide and are relied upon for improving safety, efficiency, maximizing production, and reducing labor costs.

Every piece of equipment we make is backed by our Hapman Performantee. Our Performantee is a 100% operational guarantee that pledges you will be fully satisfied with the performance results of our bulk material handling equipment, and that it will achieve the specific results for which it was designed and manufactured.

From our global headquarters in Kalamazoo, Michigan to our offices around the world, Hapman is here to help. Our sales representatives, service team, engineering experts and product specialists are available to assist you.

Thank you for choosing Hapman for your material handling needs.

Sincerely,

The Hapman Team



1.0: General Information

This manual provides instructions of how to install, operate and maintain the Helix conveyor supplied by Hapman. Assistance on part orders or service calls may be obtained by contacting **Hapman at (800) 427-6260, parts@hapman.com, or service@hapman.com**. This contact information can also be found on the last page of this manual. When calling or emailing for parts or service, please reference the equipment job/serial number. This number can be found on the Hapman nameplate affixed to each piece of equipment.

Since 2020 our equipment has included a QR code on the Hapman nameplate. By viewing the QR code through your smartphone camera function you can gain access to the digital system manual specific to your equipment. The Hapman nameplate can be found on the control cabinet or mounted on the conveyor itself.

Below is an example of what our Hapman nameplates look like.



2.0: Warranty

Equipment manufactured by Hapman is warranted to be free of defective material and workmanship under the use and service quoted for a period of one year after date of shipment. This warranty is void if serviced by anyone other than Hapman service personnel.

Hapman agrees to replace or repair any defective parts it has manufactured as covered under this warranty. F.O.B. our plant, subject to inspection of the part in question by Hapman's personnel. No article may be returned to Hapman without Hapman's written consent.

Parts supplied but not manufactured by Hapman are subject to the warranties extended to Hapman by its suppliers. Hapman's liability is limited to such adjustment as the respective manufacturer makes to the seller.

In no event shall Hapman be liable for costs incurred due to equipment malfunction such as consequential damages, lost production or the expenses or losses incurred due to geographical location or fault of the product, difficulty of access to the product as installed, or time urgency on the part of the user and/or buyer of the equipment.

For any warranty questions or claims contact Hapman Service at **(800) 427-6260** or service@hapman.com

3.0: Safety Symbols



DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or severe injury.



WARNING indicates a potentially hazardous situation which, if not avoided, will result in death or severe injury.



CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor/moderate injury and/or damage to equipment.



NOTICE indicates information considered important but not hazard related.

All owners and operators should read this manual and/or be instructed on safe operating and maintenance procedures before attempting to uncrate, install, operate, adjust, or service this equipment.



**BEFORE INSTALLING, OPERATING OR MAINTAINING ANY EQUIPMENT, THE
CONTENTS OF THIS MANUAL SHOULD BE THOROUGHLY REVIEWED AND
UNDERSTOOD**

Statements and instructions set forth herein are based upon the best information and practices known to HAPMAN, but this may not be construed to suggest that every conceivable safety precaution is contained herein.

As a matter of practicality, HAPMAN cannot guarantee that actions in accordance with such statements and instructions will result in the complete elimination of all hazards and thus assumes no liability for accidents which may occur.

While all information in this manual has been checked for accuracy, changes in design or specifications may occur at any time in HAPMAN's continuing program of product improvement. HAPMAN cannot assume responsibility for errors in the production of this manual, or for unsafe operating practices of those employing HAPMAN equipment.

4.0: Safety Instructions

	1.	Do not attempt to install, connect power to, operate or service a Helix™ Conveyor without proper instructions, and until you have been thoroughly trained in its use by your employer.
	2.	Do not attempt to work on, clean, service, or remove any protective cover, guard, grate or maintenance panel until the POWER has been turned off, LOCKED OUT , and the conveyor has come to a complete stop.
	3.	Do not manually override or electrically by-pass any protective device.
	4.	Do not connect power to or operate the Helix™ unless all moving parts are covered and all covers, guards, grates, and maintenance panels are in place and securely fastened.
	5.	Do not abuse, overload, mistreat or misuse the Helix™, or attempt to operate the Helix™ if it needs service, lubrication, maintenance or repair.
	6.	Never place any part of your body under or near rotating components of the Helix™.
	7.	The Helix™ can be installed and wired to start automatically or from remote control locations. Always keep clear of all moving parts.
	8.	It is the owner's responsibility to adequately train the employee-operator in the proper and safe use of conveyors. Written safety programs and formal instructions are essential. All new employees must be made aware of company policies and operating rules, especially the established safety and health procedures. Refresher training of experienced employees in potential hazards on the job is important. Up to date training records must be maintained at the job site.

4.0: Safety Instructions-Continued

	11.	Never allow any kind of foreign objects to enter the Helix™ while in operation.
	12.	All Helix™ inlet bar grates, top covers, or top cover with doors should be completely installed to prevent human access when the machine is running. These items should always be in place until POWER IS TURNED OFF AND LOCKED OUT . Keep away from moving parts of the Helix™ during operation.
	13.	High voltage and rotating parts can cause serious or fatal injury. Installation, operation and maintenance of electrical machinery must be performed only by qualified, trained and experience personnel. Make sure motor is effectively grounded in accordance with OSHA safety and health standards, the National Electric Code and local codes.
	14.	All protective covers, guards, grates, switches and warning tags must be kept in place and in good condition. Any equipment with damaged, malfunctioning, defective, or missing protective devices must be taken out of service until protective device can be repaired or replaced.
	15.	Any equipment used in processing of explosive materials in hazardous environments requires evaluation on the part of the user and operator for proper and adequate equipment enclosures. Do not use your equipment in hazardous environments unless it has been properly equipped for that hazard.
	16.	It is ultimately the operator's responsibility to implement all above listed precautions and insure proper use of the equipment, maintenance and lubrication. Always keep these instructions and list of warnings with your machine. WORK SAFELY AT ALL TIMES.