

Maintenance - Daily or Before AM Shift**! WARNING !**

Compressed air and electrical lines to be disconnected prior to servicing unit.

! WARNING !

Guard eyes from air connection and nozzles before connecting and disconnecting compressed air service.

- ☐ Visually inspect mechanical components for wear and or stress (replace as needed).
- ☐ Visually inspect Red belt tension (adjust or replace as needed).
- ☐ Visually inspect infeed belt tension (adjust as needed).
- ☐ Visually inspect conveyor belt tension (adjust as needed).
- ☐ Visually inspect count photo sensors and proximity sensors to ensure proper function (adjust / clean as needed).
- ☐ Visually inspect air prep filter, drain if needed.
The filter that removes debris from the air is located in the air filter module. To clean this filter remove the housing. Pull down the black release, turn the housing so that the two notches line up and then pull the housing off. Unscrew the black cap that holds the filter on. Wash the filter in soap and water and replace it in its original position. To put the housing back on, line up the notches then push in and turn until the black release snaps into position.
- ☐ Visually inspect all servo motor ground cables. Repair or replace as needed.
- ☐ Check Emergency Stop Operation. Repair or replace as needed.
- ☐ Check Guard Door switch operation. Repair or replace as needed.
- ☐ Clean Machine.
- ☐ Clean Servo System.

Maintenance Procedures should be performed by Trained Personnel Only.
Maintenance PPE - Safety Shoes, Bump Caps, Safety Glasses

Maintenance - Weekly

! WARNING !

Compressed air and electrical lines to be disconnected prior to servicing unit.

! WARNING !

Guard eyes from air connection and nozzles before connecting and disconnecting compressed air service.

- ☐ Check vibration area (if equipped) for loose/broke fasteners.
- ☐ Manually operate all air driven devices (interrupt forks). Check for proper operation and speed.
To manually operate each valve push the small blue switch up to override the electrical signal. This causes the plunger to open and direct air to the air-driven device.
Note: Once the switch is pushed up it must be manually pushed back down to accept the electrical signal again.
- ☐ Grease all component bearings.
- ☐ Replace worn or over-stretched red urethane belts.
Belt cut length:
Counter stacker discharge belts: 100¾ inches.
- ☐ Tighten all bearing set screws.
- ☐ Check all motors and bearings for excessive heat, replace as needed.
- ☐ Inspect servo motors and cables. Repair or replace if needed.

Maintenance Procedures should be performed by Trained Personnel Only.
Maintenance PPE - Safety Shoes, Bump Caps, Safety Glasses

Maintenance - Monthly

! WARNING !

Compressed air and electrical lines to be disconnected prior to servicing unit.

! WARNING !

Guard eyes from air connection and nozzles before connecting and disconnecting compressed air service.

- ☐ Check all conveyor belt for proper tension, adjust as needed.
- ☐ Check all fasteners (tighten as needed).
- ☐ Inspect pneumatic system, check all fittings and air lines for leaks, repair as needed.
The air filter regulator is a group of modules sealed by O-rings. See page 51 for picture and operation of each module. Each module can be removed by releasing the brackets that hold the modules together. If air is leaking between the modules, replace the O-rings.
- ☐ Check main drive gear box oil level (fill as needed)
- ☐ Check amp draw on all motors and full load amp draw at main power.
- ☐ Inspect all electrical terminals for secure connections.
- ☐ Inspect air chute blower motor and clean intake if needed.
- ☐ Remove air chute back and vacuum all dust from air chute.

Maintenance Procedures should be performed by Trained Personnel Only.
Maintenance PPE - Safety Shoes, Bump Caps, Safety Glasses

Maintenance - Semi Annual (6 Month)

! WARNING !

Compressed air and electrical lines to be disconnected prior to servicing unit.

! WARNING !

Guard eyes from air connection and nozzles before connecting and disconnecting compressed air service.

- ☐ Inspect grip top infeed conveyor belt, if worn remove and re-install in reverse direction of travel.
- ☐ Remove interrupt fork assembly cover, inspect rod end and cylinder jam-nuts for tightness. Check cylinder nose bushing for wear / blow-by, replace as needed.
- ☐ Inspect all electrical cables, cords, conduit, conduit fittings, conduit boxes and conduit compression fittings for damage. Replace as needed.

Maintenance Procedures should be performed by Trained Personnel Only.
Maintenance PPE - Safety Shoes, Bump Caps, Safety Glasses

Spare Parts Kit

Suggested Spare Parts list for a Genesis Counter Stacker.

Arr-Tech Part# SPK-A17028 includes the following parts.

<u>Part#</u>	<u>Qty.</u>	<u>Description</u>
315-5	4	M Bumper Vib Isolator Ball
493-1	1	Non-Reflective Photo Eye / Short Range Keyence Brand
314-7B	1	1 x 13 Air Cylinder Festo Brand
522-4	1	E Sw Sensaguard 18mm Assured Sensing Distance (Use Cable 1326-18)
1326-18	1	E Cable Straight 8-pin, PVC Cable, DC Micro (M12) 5 Meter
1465-2	1	A Valve/Slice 24V (Single SOL) Festo Brand
7709-4A	1	E Prox DC QD Micro (5mm Dist) SICK Brand
1326	1	E Cable Straight M12 4 Pin QD 10 Meter (Micro DC Style)
710	2	Cross Block WN600 w/2 Handles
81B449	2	Cross Block Shield (Nut Keeper)
10086	100 Ft.	Urethane Drive Belt, 1/4"
556-2H	2 Ft	40in Wide 1/2P Habasit Belt (1016.66mm/40.03in)
428A	2	Q-Dump w/Flow Control; 1/8 NPT - 1/4 Tube SMC
7111	1	Static Control Brush, Carbon Fiber, 24in length - 0.75 Bristles McMaster
668	1	Static Isolator; 1/4-20 Studs Both Ends
670	1	Limont Top Dust Cover (Stacking Tower)
700SS	1	E Stator (PS01-37x240-C) w/IP67 Connector Linmot Brand
412-1	1	E Slider 11in Stroke Linmot Brand
C1100PS	1	Linmot Drive - Programmed
C1100-CABLE-7	1	Linmot Motor Cable for C1100 Drive 7ft Long

Urethane Drive Belt (Part# 10086) must be cut into 100³/₄ inch lengths for the counter stacker discharge.