
Appendix B - Drawings and Diagrams

Includes:

Dimensional Drawing

Electrical Schematic



Some screens on the display require a password for access.

Passwords 4000, 4300

Admin (can not be changed) 7734

Changing Passwords

1. On the Overview screen, press Login and enter the Administrator Password (7734).
2. On the Overview screen, press Settings.
3. On the Settings Menu screen, press Maint.
4. On the Maintenance screen, press Passwords.
5. Adjust the passwords as needed. There are six password slots, 3 Operators and 3 Maintenance. All changes are immediate.
7. Press the Home button to return to the Overview screen.
8. On the Overview screen, press Logout.

Important Note: The Administrator Password cannot be changed. Store this page in a secure location to prevent unauthorized access.

**To prevent unauthorized access to password protected information, please
remove this page from your manual and store it in a safe place.**

