

Troubleshooting

Problem	Solution
Case releases, all flaps drop, during folding or packing cycle.	Check that width adjustment is correct. If it is too wide, the wheeled “switch roller” that contacts the side of the case will reset and cause the machine to return to the start position. Shaking the box to level the contents can cause the body switch to reset. Check that the body switch is correctly adjusted and secured in the frame for proper box contact and that the contact wheel is firmly attached.
Minor flaps fail to fold fully and return to home position and may try to fold again.	Check that the actuator arms attached to the floor switches (mounted on floor plates) are not out of position or loose. Both of them should be in a position to be pushed down fully by the bottom flaps of the open box.
Major flaps have difficulty folding and cause inner edges of minor flaps to be folded over.	Check that the air pressure is adequate and that the air pressure does not drop during the cycle. Check that the flow controls on the small major flap opening cylinders are set so that they will momentarily open the major flaps wider and allow the minor flaps to clear the inside of the major flaps before releasing.
Back or front case collapses inward during minor flap folding.	Be sure that the case width setting does not hold the box too tightly. Check the air pressure and volume. Check that the scoring on the box is adequate and promotes folding. Check that the flow controls on the minor flap folding cylinders are set for a fast enough speed of the minor flap folders. Excessive speed, however, can cause damage of the folder arms.
Packed case fails to transfer smoothly from packing station into case sealer.	Check the height of the rollers at the out feed end of the packing station and that the box clears the machine frame. Check that the machines are aligned accurately, i.e. that the belt surfaces line up with the insides of the packing station when in the vertical position. Use a long straight-edge to check the alignment.