



THIS PAGE INTENTIONALLY LEFT BLANK



Index

	INDEX		56	Index
			9	
About This Manual	5	Data Storage Icon	84	
Adjusting the Exit Conveyor Side Guide	43	Description	52	
Adjusting the Internal Product Guides	42	Dismounting instructions	30	
Adjustment Icon	56	Electrical Disconnect Switch	18	
Adjustments	34	Electrical Installation	18	
A - Rotary-Actuated	23	Electrical Panels	30	
Arrow	57	Electrical Safety	18	
Arrow	58	Electrical Service Connexion	18	
Arrow	59	Electrical Supply	62	
Arrow	60	Emergency Stop Pressed	18	
Asset Health and Reliability Program	4	Emergency Stop Push-button	52	
Asynchronous Gear-motor Maintenance	90	Emergency Stop Push-button	23	
At the Beginning of Each Shift	63	Energy Lockout	51	
Bag Jam Fault	62	Exit Conveyor	62	
Belt Installation	79	Fault Messages	8	
Belt Removal	79	Foreword	59	
Belt Replacement	78	Full Load Amperage	93	
Belt Speed Manual Adjustments Screen	57	Gear-head Replacement	16	
Belt Tension	78	General Safety Precautions	34	
B - Lever-Actuated	23	General Setup Procedures	10	
Cabinet Filters Maintenance	88	Glossary	4	
Changeover	34	Hands-on Classroom Learning	56	
Changing the Collator Wheel	36	HMI Screens	57	
Changing the Collator Wheel Plates	38	Home Icon	58	
Changing The Oil	90	Home Icon	59	
Checking The Oil Level	90	Home Icon	60	
Circuit Breaker Tripped	62	Home Icon	61	
Class 1 Lasers	25	Home Screen	56	
Cleaning Instructions	69	Housed Bearing Maintenance	84	
Cleaning or Replacing the Vent Screw	93	Human/Machine Interface	52	
Cleaning Procedure for Small Areas	70	Illustrations	8	
Clean The Laser Sensors	87	In-feed and Exit Belts Maintenance	72	
Collator Belt Speed	57	In-feed Belt Speed	57	
Collator Wheel	50	In-feed Tunnel Guard Adjustment	35	
Collator Wheel Fault	62	In-feed Tunnel Guarding	48	
Collator Wheel Speed	58	Information Icon	56	
Collator Wheel Speed Adjustments Screen	58	Installing Lockout Devices	22	
Complete documentation package	5	Installing/Removing Lockout/Tag-out Devices	22	
Contact Information	60	Integrated Modules	8	
Conveyor Belt Installation	71	Intended use of the machine	8	
Conveyor Belt Maintenance	71	Jam Detection Photoelectric Sensor	48	
Conveyor Belt Tension	71	Job Number	59	
Conveyor Belt Tracking	71	Large Collator Wheel	36	
Conveyor Safety	20	Largest Motor Amperage	59	
Count Belt	49	Laser Safety	25	
Count Belt Maintenance	75	Laser Specifications	25	
Customer Service and Support	4	Lead-screws Maintenance	89	
Daily Inspection	68	Lockable Main Power Switch (lever type)	24	

Lockable Main Power Switch (rotary type)	24	Replacement	83	Index
Lubrication	83	Replacement Parts	102	
Lubrication	84	Replacing the Shaft Sealing Ring	93	
Lubrication	89	Reprinting This Manual	2	
Machine Disposal	31	Required Equipment	69	
Machine Elements with Lockout Provision	23	Reset Output	61	
Machine Maintenance	66	Rolling Bearing Maintenance	83	
Machine Technical Information Screen	59	Routine Cleaning	68	
Machine Technical Information Screen	60	Routine Inspection	68	
Machine Unpacking	28	Safety Door Open	62	
Main Power	23	Safety Signs	15	
Maintenance Personnel	5	Safety Switches	18	
Maintenance Safety	19	SCCR	59	
Manual Release & Revised Dates	2	Secured Remote Support	4	
Manufacture Date	60	Sensor Replacement	86	
Mechanical Installation Inspection	19	Sensor Replacement	87	
Mechanical Safety	17	Sequence of Operation	46	
Minor Maintenance	17	Serial Number	59	
Motor Fan Cleaning	81	Service Health Check	4	
Mounting instructions	84	Shut-down Procedure	54	
Oil Plug Type Locator Drawings	91	Signal Word Panels	15	
Operator Cleaning Procedures	63	Small Collator Wheel	37	
Operator Controls	52	Space and Clearance	28	
Operator Guards	17	Standard Cleaning Method	69	
Operators	5	Start-up Procedure	54	
Other Service Department Offerings	4	Synchronous Belt Drives Maintenance	78	
Package Count Photoelectric Sensor	49	Synchronous Drive Belts Maintenance	80	
Personnel	8	Technical Support	4	
Photoelectric Sensors Maintenance	86	Top Guard Door	50	
Physical Barriers	17	Troubleshooting	96	
Physical Contact	17	Troubleshooting Table	97	
Polycarbonate cleaning	70	Turnaround Time on Replacement Parts	4	
Power Push-button	56	Typography	8	
Pre Start-up Procedures	53	Using the manual	5	
Product Count Laser Setup Procedure	35	VFD Fault	62	
Product In-feed Chute	47	Voltage	59	
Product In-feed Conveyor	48	Warning Icon	56	
Product In-feed Conveyor Adjustment	34	Warranty Information	1	
Product In-feed Guides Adjustment	35	Wear	89	
Production Data	61	Weekly Cleaning	63	
Production Data Screen	61	Wheel Delay	58	
Prolonged Storage	31	Wheel Stop Photoelectric Sensor	50	
Pulley alignment	78			
Purpose	5			
Purpose Of The Manual	8			
Recommended Spare Parts List	103			
Recovering From A Power Outage	55			
Re-lubricating the Bearings	93			
Removing Lockout Devices	22			



THIS PAGE INTENTIONALLY LEFT BLANK



BluePrint Automation
16037 Innovation Drive
South Chesterfield, VA 23834-5951
001 804 520 5400
www.blueprintautomation.com

BluePrint Automation
4093 Specialty PI A
Longmont, CO 80504-5400
001 303 682 1200
www.blueprintautomation.com

Be sure to follow, like us and subscribe to our social media outlets.

