Dante Config Editor

Quick start - offline StageFlow projects and Dante XML editing

Third-party tool, not an official Audinate product. Work on a copy and always validate the final XML by importing it into the appropriate official Dante tool before real use.

Recommended workflow

1. Open a configuration
   Choose the starting XML. DCE and StageFlow projects remain available as secondary starting points.
2. Add if needed
   Select several configurations, resolve duplicates, then add the batch. An error or cancellation leaves the current project untouched.
3. Edit
   Use Devices, Matrix, Easy patch, Rx-to-Tx list, or global actions. Lock devices that must be excluded.
4. Review
   Use Modified only and Before / after. Unknown technical changes are blocked.
5. Validate and export
   Open Validation center, then Export to Dante Controller. Fix errors, acknowledge warnings, and choose a new .xml file. Save preserves the StageFlow project.
6. Test the import
   Import the result into Dante Controller on a working copy before any field operation.

Useful features

Matrix and multicast Collapsed devices, amber diagonal/column previews, Flip, inline rename and series fill handles. Locate finds connections. Multicast creates, updates, or removes simple audio preset flows. Check the result in Dante Controller.	Local StageFlow, LIVE, and console DCE directly opens a local StageFlow project. A LIVE session joined with its code can synchronize only UUID-linked Rx channels. On Windows, the local console can open Patch, validation, or save the Dante domain, with no network command.
First launch A guided welcome separates DCE Project, Local StageFlow Project, and StageFlow LIVE Session. Reopen it from Help > Discover DCE.	Import / Export JSON/CSV, DMT XLSX/ODS, A&H CSV, and Yamaha ZIP labels are grouped. From a StageFlow project, a patch group can also name all or part of a Dante device's RX channels.
Synoptic Group devices by location, open a separate proportion-preserving preview, and export SVG or PDF without changing Dante XML.	Machine bank Review provenance and verification level, then prepare a sanitized contribution or add an independent instance.
License No code or online activation is required to use DCE for free: choose Continue with DCE, even without Internet. During the 30-day trial, no license reminder appears. Afterwards, a 5-second countdown precedes full access; a valid license removes reminder and wait.	

Labels: choose Native A&H CSV - dLive/Avantis, Native Yamaha ZIP - CL/QL, or DMT XLSX/ODS. In a StageFlow project, also use Map the StageFlow patch to RX channels. Empty cells are ignored.

Exercise: Tools > Training > Atomic Bomb. Clear categories you want to spare, turn the key, open the cover, then press ARM, LOCK, and FIRE. Export a new XML for trainees. Technical identifiers remain protected.

Remember: no real-time control, no Audinate API, and no guarantee for every XML format. Import validation in official tools remains mandatory.

Free and optional StageFlow: www.silemio.com

Manuals and downloads: Dante Config Editor - SiLeMI/O