



Dante Config Editor 2027.0.7

Quick start | macOS

1. Download the Apple Silicon or Intel DMG matching your Mac, verify its origin, and copy DCE into Applications.
2. Open Dante XML or New DCE project for standalone work. Local StageFlow project opens a .stageflow folder; StageFlow LIVE joins a coded session. Keep these workflows distinct.
3. In Devices, check the selected device, enable editing, rename, and apply supported settings. Global actions target multiple devices. The bank creates and duplicates instances.
4. In Patch > Easy patch / Matrix, select Rx on the left and Tx on the right; FLIP stays between them. A click patches the project. One Rx accepts only one source. Select several Tx channels towards the first Rx, or several Rx channels towards the first Tx, for sequential patching. Arrows find sources and destinations.
5. On Mac, use Batch rename in Devices rather than a matrix fill handle. Review the labels and subscriptions after renaming.
6. Under Import / Export, map StageFlow entries to Rx by UUID, exchange labels, and generate reports or PDF/SVG synoptics.
7. Validate before saving. Save writes the project; in StageFlow, only the Dante domain is updated. File > Export to Dante Controller produces a separate copy without changing the open project or its history. Check this deliverable in Dante Controller.

License: no reminder for 30 days, then software remains usable. Permanent license: EUR 29 including French VAT, through Stripe Managed Payments. Existing codes remain valid.

GitHub : [installateurs et notices / installers and guides](#)