



Dante Config Editor 2027.2.6

Quick start | macOS

1. Download the Apple Silicon or Intel DMG matching your Mac, verify its origin, and copy DCE into Applications.
2. Open Dante XML or New DCE project for standalone work. Local StageFlow project opens a .stageflow folder; StageFlow LIVE joins a coded session. Keep these workflows distinct.
3. In Devices, check the selected device, enable editing, rename, and apply supported settings. Global actions target multiple devices. The bank creates and duplicates instances.
4. In Patch > Easy patch / Matrix, expand devices. Drag diagonally or along a column with amber previews. Flip swaps the chosen device pair; Locate finds connections.
5. Double-click labels to rename inline and drag the fill handle to extend a series. Multicast selects audio Tx channels and creates, updates, or removes simple preset flows.
6. Under Import / Export, map StageFlow entries to Rx by UUID, exchange labels, and generate reports or PDF/SVG synoptics.
7. Validate before saving. Save writes the project; in StageFlow, only the Dante domain is updated. File > Export to Dante Controller produces a separate copy without changing the open project or its history. Check this deliverable in Dante Controller.

License: immediately dismissible reminder during the 30-day trial; after expiry, a 5-second countdown then full access. Permanent license: EUR 29 including French VAT. Existing codes remain valid.

GitHub : [installateurs et notices](#) / [installers and guides](#)