



Dante Config Editor

Quick start - offline StageFlow projects and Dante XML editing

Third-party tool, not an official Audinate product. Work on a copy and always validate the final XML by importing it into the appropriate official Dante tool before real use.

Recommended workflow

- 1** Choose the workflow
Create or open a standalone DCE XML project, open a local .stageflow folder, or explicitly join a StageFlow LIVE session.
- 2** Review alerts
Show affected devices and verify every reported item.
- 3** Edit
Use Devices, Matrix, Easy patch, Rx-to-Tx list, or global actions. Lock devices that must be excluded.
- 4** Review
Use Modified only and Before / after. Unknown technical changes are blocked.
- 5** Validate and export
Open Validation center, then Export to Dante Controller. Fix errors, acknowledge warnings, and choose a new .xml file. Save preserves the StageFlow project.
- 6** Test the import
Import the result into Dante Controller on a working copy before any field operation.

Useful features

Visual patch Every click or drag applies the patch immediately. Replacement warnings for already-patched Rx channels are enabled by default and can be cleared.	Local StageFlow, LIVE, and console DCE directly opens a local StageFlow project. A LIVE session joined with its code can synchronize only UUID-linked Rx channels. On Windows, the local console can open Patch, validation, or save the Dante domain, with no network command.
First launch A guided welcome separates DCE Project, Local StageFlow Project, and StageFlow LIVE Session. Reopen it from Help > Discover DCE.	Import / Export JSON/CSV, DMT XLSX/ODS, A&H CSV, and Yamaha ZIP labels are grouped. From a StageFlow project, a patch group can also name all or part of a Dante device's RX channels.
Synoptic Group devices by location, open a separate proportion-preserving preview, and export SVG or PDF without changing Dante XML.	Machine bank Review provenance and verification level, then prepare a sanitized contribution or add an independent instance.
License The trial lasts 30 days. DCE then remains fully accessible; a commercial or complimentary license removes the startup reminder.	

Labels: choose Native A&H CSV - dLive/Avantis, Native Yamaha ZIP - CL/QL, or DMT XLSX/ODS. In a StageFlow project, also use Map the StageFlow patch to RX channels. Empty cells are ignored.

Exercise: Tools > Training > Atomic Bomb. Clear categories you want to spare, turn the key, open the cover, then press ARM, LOCK, and FIRE. Export a new XML for trainees. Technical identifiers remain protected.

Remember: no real-time control, no Audinate API, and no guarantee for every XML format. Import validation in official tools remains mandatory.

Free and optional StageFlow: www.silemio.com

Manuals and downloads: [Dante Config Editor - SiLeMI/O](#)