Dante Config Editor

Quick start - Windows, XML projects and Dante networking

Third-party tool, not an official Audinate product. Work on a copy and always validate the final XML by importing it into the appropriate official Dante tool before real use.

Recommended workflow

1. Create or open a configuration
   Both large commands are at the same level. Create a configuration opens an empty draft: add devices from the bank. Open a configuration chooses an existing XML file. DCE and StageFlow projects remain available.
2. Add if needed
   Select several configurations, resolve duplicates, then add the batch. An error or cancellation leaves the current project untouched.
3. Edit
   Use the Patch grid, device details or global actions. Lock devices that must be excluded.
4. Review
   Use Modified only and Before / after. Unknown technical changes are blocked.
5. Validate and export
   Open Validation center, then Export to Dante Controller. Fix errors, acknowledge warnings, and choose a new .xml file. Save preserves the StageFlow project.
6. Test the import
   Import the result into Dante Controller on a working copy before any field operation.

Useful features

Offline, online, and mixed matrix Online, click to patch between two discovered devices. A grey cell stays in the project while a device is missing. When it returns, click the amber cell to apply the connection. Locate opens a list of sources or destinations.	Local StageFlow, LIVE, and console DCE directly opens a local StageFlow project (.stageflow). A LIVE session joined with its code can synchronize only UUID-linked Rx channels. On Windows, the local console can open Patch, validation, or save the Dante domain, with no network command.
First launch A guided welcome separates DCE Project, Local StageFlow Project, and StageFlow LIVE Session. Reopen it from Help > Discover DCE.	Import / Export JSON/CSV, DMT XLSX/ODS, A&H CSV, and Yamaha ZIP labels are grouped. From a StageFlow project, a patch group can also name all or part of a Dante device's RX channels.
Synoptic Group devices by location, open a separate proportion-preserving preview, and export SVG or PDF without changing Dante XML.	Machine bank Review provenance and verification level, then prepare a sanitized contribution or add an independent instance.
License If you have no valid license, the offline trial lasts 30 days from the first launch of 2027.3. A valid license is required afterwards. A permanent license costs EUR 49 including French VAT. Existing permanent licenses remain valid.	

Labels: choose Native A&H CSV - dLive/Avantis, Native Yamaha ZIP - CL/QL, or DMT XLSX/ODS. In a StageFlow project, also use Map the StageFlow patch to RX channels. Empty cells are ignored.

Exercise: Tools > Training > Atomic Bomb. Clear categories you want to spare, turn the key, open the cover, then press ARM, LOCK, and FIRE. Export a new XML for trainees. Technical identifiers remain protected.

Dante networking: open DCE Patch > Go online to try simulation. Open Replace / Synchronize devices to choose differences and direction. Green means unicast and blue means multicast. See the full guide for details.

Free and optional StageFlow: www.silemio.com

Manuals and downloads: Dante Config Editor - SiLeMI/O