



QUICK START

StageDesk v2027

Transfer labels and essential settings between audio consoles and software.

One source. One working table. One destination. StageDesk avoids retyping and adapts each transfer to the selected model.

Retrieve

Choose a displayed source mode, then open the offered project file and state.

Convert

Edit labels, colours, icons, and essential settings in one common grid.

Transfer

Use the mode and target state actually offered by the connector.

Windows x64 - macOS - Français and English - v2027 edition

SiLeMI/O by Mamat

----□--



The three-step workflow

1 Retrieve Choose the source, model, then the source mode and state actually offered.	2 Edit Review the universal table and adjust only the data that should change.	3 Send Choose the target, then one of the modes actually shown for that profile and one of its offered target states.
--	---	--

Step	Fast action
1. Retrieve	System > Model > displayed source mode > offered file or Current state > Import.
2. Edit	Exclude unused channels, edit labels, and use Copy / Paste or smart fill.
3. Send	System > Model > one of the modes shown for this profile > offered target > Export.

The table follows the imported project. Parameters actually retrieved and transferable are selected under Details; absent or unsupported fields remain unselected. Only Include is visible during normal use.

New project

- Choose the parent folder and enter the project name.
- Name the first scene or snapshot when StageDesk asks for it.
- Use only the New Project modes offered for the selected profile.
- Export. StageDesk shows the path and summary; Nuendo and Harrison add detailed opening steps.

Existing project

- Choose the target project and one of its offered states; create a new state only when that action is displayed.
- In Existing Project mode, StageDesk replaces the selected file only after confirmation and creation of a same-folder, non-timestamped backup prefixed Bckp_, then Bckp2_ if needed.



Review before use

Check	Expected
Source	Correct project and correct scene or snapshot.
Table	Coherent channel count; unused channels excluded.
Target	Exact model, sufficient capacity, correctly named destination.
Adaptation	Colours, icons, and labels replaced with compatible values.
Readback	Project opened in the official editor and representative channels reviewed.

StageDesk creates and saves its own standalone .smtshow projects or Local StageFlow .stageflow projects. A joined StageFlow LIVE session applies valid external changes immediately without recalling the snapshot; same-field conflicts keep the local value and remain flagged.

For Nuendo, use File > Import > DAWproject. Avantis and dLive feed Current or snapshots and can create a snapshot or New Project for the chosen model. For DCE, select the XML machine and its Rx side; existing Tx channels are preserved.

Before using a production console, keep the previous validated show and test the exported copy offline.

Update

Help > Check for updates offers the latest stable version for this computer. Confirm the download: StageDesk verifies SHA-256, then can reveal the file. Installation remains your choice.

Links

- [Download StageDesk v2027](#)
- [Download StageFlow - free and optional](#)
- [Download Dante Config Editor \(DCE\)](#)
- [Download StageMark](#)
- [Download StageMon](#)
- [Buy a StageDesk license - EUR 29 including tax](#)

StageDesk - Transfer labels and essential settings.
SiLeMI/O by Mamat - ----[]--



Console networking: direct connection

StageDesk communicates directly with the console on the local network, without DMT or Mixing Station. Limits depend on the family. No physical console has been validated for this release: test off-air before any production use.

- Choose the family, exact model, then Network. Use the console control IP, not its Dante card IP. The computer and console must be reachable on that network.
- Simulation opens no socket. Turn it off for a real connection. Discover opens the interface selector; scanning only begins after Detect on this network. You can also enter an IP/host.
- Detection checks the selected family and port on at most the local /24 block (253 other hosts). Use manual IP for another block, VLAN or /31-/32 interface. It does not scan the entire corporate network.
- Test checks a protocol response. Read Current imports inputs into the table. Opening a project, changing language or choosing a model never starts a connection.
- For the destination, review Include and the checkboxes under Details, then Send. StageDesk reads Current, prepares differences and backs up the readable fields as .smt with SHA-256 before final confirmation.
- Sending changes Current, not a saved scene. Review the report and console. Stop cancels subsequent commands; it does not undo earlier ones. On a small screen, scroll or fold the panels to enlarge the table.

Keep a complete vendor show before any write. The StageDesk backup contains only fields actually read, not routing, gains, phantom power, processing or scenes. It is not an automatic rollback. Isolate the control network: these protocols are neither encrypted nor authenticated.

Ports: Yamaha TCP 49280; dLive/Avantis TCP 51325, base MIDI channel 1-12 (default 12); X32/M32 UDP 10023; WING UDP 2223. On X32/M32, Import scene recalls its entire mix after confirmation; Store Current uses an empty slot only. Other snapshots use the native file.