

StageMon

Operator guide - Windows 2027.0.2

StageMon is a monitoring matrix: select sources, distribute them across your circuits and recall CUE scenes. You retain control of physical output routing. This edition describes the Windows changes; Mac instructions refer to the existing 2027.0.1 version.

Contents

1. First monitoring check: prepare and hear a source.
2. CUE, Always and LINK: choose what each circuit hears.
3. Circuits, colours and ceilings: configure A to F.
4. Outputs and audio engines: check the signal path.
5. Input tests and snapshots: test and save monitoring scenes.
6. Projects, groups and Excel: work independently or exchange with the suite.
7. Connection, alerts and Remote: distinguish LIVE from phone control.
8. EW-DX RF: read receiver information.
9. Troubleshooting and help: find the first missing link.

1. First monitoring check

StageMon selects the sources heard on separate monitoring circuits. A may feed the control position and B another listener. Circuits C to F are optional: they appear only after you configure them.

1. Open or create a StageMon project. Check each source number, name, microphone and input assignment in the matrix.
2. Select the audio driver and interface. On Mac, select a duplex CoreAudio device or an aggregate prepared in Audio MIDI Setup.
3. Open Output patch (in SETUP on Mac). Assign physical outputs for A and B. 0 or unassigned sends nothing. Mono uses the left output only.
4. Lower the circuit level and check its ceiling. Select a source using CUE A or CUE B.
5. Click Start audio and raise the level gradually. Selecting a CUE does not start the audio engine.

Input meters show the signal processed by the engine. A stopped engine provides no live audio measurement. Meters do not prove that headphones, speakers or external routing work.

Example: to check a vocal microphone on A, assign A to the physical output feeding your headphones, activate only that source's CUE A and start at a low level. B can keep a different selection. Do not raise the level to compensate for a stopped engine or an unassigned output.

2. CUE, Always and LINK

Exclusive mode keeps one CUE per circuit. A new CUE replaces the previous one on that circuit. Clicking the same CUE again turns it off. Additive or Mix Cue mode sums several CUE selections. Each circuit keeps its own selection.

Always (the infinity symbol on Mac) adds a permanent source to the circuit. It remains when the CUE changes. Turning off a source's CUE does not silence it if Always is also active: clear its permanent selection too.

LINK A/B applies subsequent CUE selection commands to both circuits. ON is visible between the A and B cards. It does not link levels or mutes; each card's Clear Cue remains individual. Circuits C to F remain independent.

Clear Cue A, Clear Cue B and the equivalent C to F controls clear the temporary CUEs on that circuit. Clear Cue above the matrix clears them on every circuit. Always sources are permanent selections: check them separately. MUTE silences a circuit without losing its selections.

Example: put an ambience microphone in Always A. In exclusive mode, change from guitar CUE to vocal CUE: only the CUE changes, while ambience remains. Clear Cue A removes the vocal, not the ambience. For immediate silence use MUTE A; to empty the selection, remove Always A as well.

MIX A/B checkboxes represent the corresponding CUE selections. Large A/B buttons provide direct access to those same selections. Always A/B is a separate permanent layer. Hiding columns with Columns does not disable their settings. Side arrows collapse panels without changing audio.

3. Circuits, colours and ceilings

On Windows, open Output patch to configure circuits. On Mac, SETUP provides the 2 to 6 circuit count, Output patch and "Circuits: name, colour, ceiling...". Stop audio before changing the number of circuits or output routing on Mac.

Each circuit has a stable letter, a name, a colour and a level ceiling. Names accept 1 to 64 characters. Choose a palette colour or enter #RRGGBB. The ceiling ranges from -80 to +12 dB. It limits the fader setting; it is not a peak limiter.

On Mac, Apply to circuit validates name, colour and ceiling together. Lowering the ceiling below the current level reduces that level immediately. Raising the ceiling does not raise the level. CUEs, Always sources, mutes and outputs are preserved. Save the project to retain settings on disk.

Overview shows all configured circuits. An individual circuit view focuses the display on that circuit; other circuits keep working. On Mac, matrix buttons then use the selected circuit's real letter. Returning to Overview changes no monitoring selection.

New C to F circuits start with no physical output assigned. Reducing the circuit count hides their controls. Check snapshots that used those circuits before recalling them.

4. Outputs and audio engines

On Windows, select the input and output driver independently: ASIO, WASAPI or WDM according to the available devices. A single ASIO interface provides the most direct path. Bridging two interfaces or drivers depends on their clocks, sample rates and capabilities; check stability and latency with your setup.

On Mac, StageMon uses CoreAudio and selects a device with both inputs and outputs. To combine two interfaces, prepare an aggregate in Audio MIDI Setup, choose its clock source and appropriate drift correction, then select the aggregate in StageMon. StageMon does not create it automatically.

Output patch numbering belongs to the selected device. Mono uses one physical output; stereo uses L and R. An unassigned output stays silent. macOS microphone and system permissions may be needed for physical inputs.

The ceiling applies to local and remote level commands. A locally set mute has priority: Remote cannot remove it. To hear output, check engine running, input signal, CUE/Always selection, level, mute, physical patch and external equipment in that order.

5. Input tests and snapshots

Input tests are available on demand in Tools on Windows and SETUP on Mac. Real inputs restores physical sources. Oscillators temporarily substitutes test signals. Music lets you select a file for the input test. On Mac, test injection is set to -30 dBFS.

Test injection passes through the matrix, CUEs, ceilings, mutes and output patch. It does not start audio automatically. Loading a file alone does not prove audible playback. Return to Real inputs after the check.

CUE snapshots save numbered, named monitoring scenes. Prepare your selections and click + Snapshot. Click a scene to recall it. Its menu can rename, replace or delete it.

A snapshot recalls the active patch, CUEs, Always sources, exclusive/additive mode and LINK. It does not recall levels, mutes or physical outputs. An incompatible snapshot is rejected entirely. Save your project: a scene not saved to disk may be lost when closing.

Exercise: select vocals on A and bass on B, then create "01 - Vocals and bass". Prepare another selection and create "02 - Ensemble". Click 01: the selections return, but levels and mutes retain their current values. Check a scene before replacing its contents; deleting a scene is not a way to silence output.

6. StageMon, local StageFlow and LIVE projects

StageMon project: a standalone .stagemon.json file. New, Open, Save and Save as work without StageFlow. The project holds monitoring settings and snapshots.

Local StageFlow project: the shared .stageflow project contains the common patch and each application's data. Opening a local project does not join a network session. StageMon saves its monitoring domain while preserving other applications' domains. Create a copy exports to a new shared project.

On Windows, Create a copy of an open StageFlow project preserves persistent files, identifiers and other applications' data. Temporary LIVE state is not copied. Choose a separate, empty destination. If another application changes the project during copying, retry after its save completes. Reopen a linked project before making its copy.

StageFlow LIVE session: a voluntary association with an active session. Its connection indicator shows the current state. An open disk project is not necessarily connected to LIVE. Check the project name and indicator before work. Leaving LIVE or losing network access does not mean the local project was deleted.

Label changes may show a before/after alert. Pausing notifications at the host and disabling their local reception are different controls. The Mac banner displays alerts and their states; this does not imply that it exposes every acknowledgement control available on Windows.

The common Excel patch imports through the Excel commands. Its template prepares sources and groups, not every application's private settings. Use a StageFlow project to exchange the suite's complete application domains.

To prepare a show entirely from StageMon, without launching StageFlow:

1. File > Native StageMon project > New (Ctrl+N): name the project and choose the number of inputs and patches.
2. File > Create Excel template: confirm the name, pair count and group count, then save the workbook. Two groups produce Commun plus two group worksheets.
3. In Excel, use the Commun sheet to fill Sources, Mic and Comments starting on row 5 (B5, C5 and D5 for the first input). Keep the numbers in column A.
4. Name groups using the coloured Commun headers on row 1: E1 for the first, G1 for the second, then I1. Enter group-specific source/microphone values in their corresponding columns. Do not rename technical worksheets or edit the hidden sheet.
5. Save in Excel, then File > Import Excel patch in StageMon. Check group names/count under Active patch, plus source and microphone labels.
6. Save the native project to retain monitoring settings. Under File > Shared StageFlow project, also save a common project if you want to open it in the other applications.

To change the group count, generate a template with the new count and transfer your visible data before importing; do not merely duplicate a worksheet. Exporting the legacy Demo workspace creates a detached StageFlow copy: StageMon stays standalone and keeps its monitoring. Explicitly open that copy to use it in LIVE.

Groups are input-patch variants, not monitoring outputs. "Stage A/B" does not impose a location or circuit A/B: these are simply group names. A group-specific value, also called an override in the shared format, replaces an inherited common-patch value. It is not an audio soundcheck. Changing groups does not select another sound card.

After a round trip through another application, compare the group count and names, plus a few reference sources: number, label, microphone and comments. StageMon does not directly edit the shared patch already opened: prepare its data in the workbook or StageFlow, then reload it. Save monitoring settings in StageMon. The workbook is not a complete backup of other applications' icons, layouts and private settings.

7. Connection, alerts and Remote

Open the connection icon at the top, select the network used by the phone, start Remote and scan the QR code. The computer and phone must reach each other over the local network. A firewall, isolated guest Wi-Fi or changed address can prevent access.

In the Windows StageFlow connection centre, choose StageFlow LIVE for the shared project or Remote for phone control. These are separate states. Return to project closes the centre without stopping audio. Check the project name and connection indicator; a ready QR code does not prove that a phone is connected.

LIVE on the same PC: open the same StageFlow project and enable LIVE following. Network LIVE: select the session advertised by StageFlow and pair using its code. The Remote QR code is not a project-pairing code. Central commands remain scoped to the active project and session; a refused command must not be treated as applied.

On Windows, change alerts arrive through both local and network LIVE. Open Alerts to see the before/after values and origin. Acknowledge dismisses a notification on this workstation; it does not undo or approve the patch change. Acknowledge all covers the displayed notifications, not new arrivals afterwards.

Disabling StageMon's alert reception does not stop data following. Notifications ignored during the pause are not replayed on resuming. Host-paused notifications differ from an unavailable journal: for the latter, check the StageFlow host's session and version. Handle an incompatible-patch warning separately from an ordinary name-change notification.

Up to 24 controllers can be associated, with individually revocable identities. Remote provides Overview and individual circuit views, CUEs, Always, levels, mutes and Clear Cue. Unconfigured circuits stay hidden. Names, colours and ceilings come from the current project.

On Mac, audio startup remains local. A connected Remote does not mean that the engine is running or that output is audible. Local mute retains priority and remote levels are bounded by the ceiling. Switching between applications from StageFlow uses a temporary association link; an old page does not replace a valid new association.

Actions are confirmed after application. If refused, check the message and workstation state. Controls are disabled offline. Reconnecting replays nothing. After a project, patch or circuit change, check the refreshed view before trying again.

StageFlow connection

Back to project

StageMon Demo 192

STAGEMON PROJECT · STANDALONE

**StageFlow LIVE**

- StageFlow: standalone

**StageMon remote**

- Stopped

Local project

A StageMon project is standalone. You can also open a local StageFlow project. Joining a StageFlow LIVE session is a separate action.

New StageMon project...

Open a StageMon project...

Open a local StageFlow project...

StageFlow LIVE

Sessions hosted by StageFlow on this PC or the local network. Select a session and enter its 6-digit code to join. Connecting starts neither audio nor the remote control.

StageFlow: standalone

Refresh

StageFlow: standalone

StageFlow connection centre - Windows 2027.0.2, standalone example. StageFlow LIVE and Remote are separate destinations; scroll the panel to reach the controls below.

8. EW-DX read-only RF monitoring

Open HF / RF - EW-DX in Tools on Windows or SETUP on Mac. This workflow is limited to EW-DX EM 2, EM 2 Dante and EM 4 Dante, firmware 4.0.0 or later, SSCv2 and an OpenAPI 1.7-compatible schema. Digital 6000 and legacy protocols are not treated as equivalent devices.

First enable secure third-party access in Sennheiser Control Cockpit. In StageMon, enter the receiver's HTTPS origin, API password and RX number (1 to 4). The battery TX is optional and selected separately. RX/TX are not audio interface input numbers. The label is an annotation, not routing.

The system normally validates the certificate. For a local certificate, you may provide its exact SHA-256 fingerprint, independently verified with the receiver administrator. A different fingerprint or expired certificate is rejected. There is no global accept-all certificate option.

Associate and read starts readings with two seconds between completed cycles. The display provides model, firmware, protocol, RSSI in dBm, quality in %, audio in dBFS and, when requested and available, battery in % and minutes. Unknown means no usable reading was received. An unlinked transmitter is not a 0% battery.

Disconnecting, removing the association or closing the window stops reads. A network, certificate, version or access error makes readings unavailable and requires a new association. Passwords and associations are not saved. The window supports up to 16 associations.

Only documented reads are sent: StageMon does not set receiver frequencies, gains, RF mutes, firmware or subscriptions. RF telemetry does not carry audio. Qualify compatibility with your hardware and firmware before production.

Shure ULX-D/Axient Digital and Wisycom have no active adapter in this delivery. The accessible documentation is insufficient to advertise complete, verified integrated telemetry for these families.

9. Installation, troubleshooting and help

Windows: x64 installer, StageMon v2027 shortcut. Mac: choose the Intel or Apple Silicon DMG for the machine. The runtime is included. macOS 12 is the declared minimum. Packages carry an ad-hoc integrity signature; Developer ID signing and Apple notarization are outside this delivery. Do not disable macOS protections globally.

If there is no sound, find the first missing link: source -> engine -> CUE/Always -> level/ceiling/mute -> output patch -> equipment. An initialization error means the engine did not start. An illuminated CUE button alone is not proof of audio.

Keep a project backup before upgrading and test with your interfaces and network outside production. Software checks do not certify physical levels, real latency or RF coverage at the venue.

If Clear Cue seems ineffective, first check the target circuit and Always checkboxes: permanent selections intentionally remain active. If names change without notifications, check local reception and the host's broadcast setting. If switching applications on the phone returns to StageFlow instead of opening StageMon, check StageMon availability in the connection centre and request a fresh Remote access link.

If the QR page does not load, check the selected network, current PC address and Wi-Fi restrictions. Firewall repair may require Windows approval. If denied or centrally managed, ask the administrator for a targeted rule. Do not disable the firewall globally. Keep the exact diagnostic message for support.

Guide in the toolbar opens this StageMon guide in the selected language. Help provides product help and a separate Suite guide entry. For support, include the version, driver and interface, project type (StageMon, local StageFlow or LIVE), affected circuit and reproduction steps. Do not share private Remote codes or links.

[StageMon](#) · [StageMon guides](#) · [Downloads](#)