Safety sheet - Kestrel K-200, K-300 and MF-1

Read before first use and keep this sheet.

- Connect only to an earthed socket, 220-240 V, 50 Hz.
- Never put the machine, the frother base or the cable in water.
- Do not use the appliance if the cable or the plug is damaged.
- The group head, the steam wand and hot water can burn. Keep hands away.
- Unplug the appliance and let it cool before cleaning or moving it.
- Keep the appliance and its cable out of reach of children under 8.
- Use the MF-1 jug only on its own base.
- Household use only. Not for offices, cafes or other commercial use.
- Repairs only by an authorised service. Do not open the appliance.
- E8 or E9 on the display: switch off, unplug and contact support.

Acme Devices, Novi Sad. support@example.com