Kettlebrook Aurora 3 Espresso Machine – User Manual

Setting up your machine

Thank you for choosing the Kettlebrook Aurora 3. Before first use, remove all packaging and rinse the water tank with warm water. The water tank holds 1.8 litres. Only fill it with cold, fresh water; never use sparkling water or milk.

Place the machine on a flat, dry surface at least 10 centimetres away from the wall, so air can move around it. Plug it in and press the round power button on the right side. The power light blinks white while the machine heats up. Preheating takes about 25 seconds. When the light stays white, the machine is ready.

Before your first coffee, run two full cups of plain water through the machine without coffee. This removes any dust from the factory.

Making an espresso

For a single espresso, use 9 grams of ground coffee; for a double espresso, use 18 grams. We recommend grind setting 4 on the built-in grinder. Press the coffee down evenly with the tamper. A good double espresso gives about 36 grams of coffee in 25 to 30 seconds. If it runs faster, choose a finer grind setting; if it runs slower, choose a coarser one.

Daily cleaning

Empty the drip tray and the coffee grounds container every day. The red float in the drip tray rises when the tray is full. Wash both parts with warm water and a little washing-up liquid. They are not dishwasher safe.

After frothing milk, always wipe the steam wand with a damp cloth and open the steam for 2 seconds to blow out any milk left inside. Milk that dries inside the wand can block it.

Descaling

Hard water leaves limescale inside the machine. Descale the Aurora 3 every 8 weeks, or after 200 cups, whichever comes first. The descaling light turns orange when it is time.

To descale, mix one sachet of Kettlebrook descaler with 1 litre of water in the water tank. Hold the power button and the steam button together for 3 seconds to start the descaling program. The program takes about 20 minutes. Afterwards, rinse the tank and run a full tank of fresh water through the machine. Never use vinegar, because it can damage the seals.

Storing the machine

If you will not use the machine for more than two weeks, empty the water tank and the drip tray, and leave the tank lid open so it can dry.

Troubleshooting

Error E4 means the water tank is empty or not pushed in properly. Fill the tank and push it in until it clicks.

Error E7 means the boiler is too hot. Switch the machine off, wait 15 minutes, and switch it on again.

Error E9 means the grinder is blocked. Unplug the machine, remove the bean container, and clear the beans with the cleaning brush. Never put your fingers into the grinder.

If coffee drips out very slowly or not at all, the grind is too fine or the machine needs descaling. If the coffee tastes sour, the grind is too coarse.

Warranty

The Aurora 3 has a 2-year warranty. If you register your machine on the Kettlebrook website within 60 days of purchase, the warranty is extended to 3 years. The warranty does not cover damage caused by limescale, so please descale regularly.

To contact customer service, call 0800 555 0142, Monday to Friday from 8:00 to 18:00. Have your serial number ready; you can find it on the sticker under the water tank.