

MAINTENANCE DEPARTMENT - TECHNICIAN SOP

Target Equipment: Pressure Relief Valve #402

Clearance Level: Technician

Step-by-Step Maintenance Instructions:

STEP 1 -> Switch off unit power supply and isolate valve.

STEP 2 -> Check oil level and inspect valve body for corrosion.

STEP 3 -> Clean accumulated sediment and replace rubber gasket.

STEP 4 -> Record final pressure rating in logbook.