

SDK Configuration


For

AVR Project Development

This material is developed by IMTSchool for educational use only All copyrights are reserved




# Open SDK, from the top menu, choose *Window* then *Preferences*






### In the left side open the arrow beside AVR then choose Paths






#### Click on AVR-GCC and press Edit






#### From the drop down menu choose *Custom*






#### Go to the SDK folder, then WinAVR, then bin and copy this folder path






Back to the SDK, paste the copied path then press **Ok** 





## Repeat the previous steps and modify the following paths:




#### Where

GNU Make	Path of SDK_Folder/WinAVR/utils/bin
AVR Header Files	Path of SDK_Folder/WinAVR/avr/include
AVRDude	Path of SDK_Folder/WinAVR/bin



Press **Apply** then **Ok** and we are Done.







www.imtschool.com



ww.facebook.com/imaketechnologyschool/

This material is developed by IMTSchool for educational use only All copyrights are reserved