




# Welcome To AVR Interfacing











Now let's walk through the eclipse environment:



The right hand side is the project browser where all your projects and files are Shawn.













#### The most important tools in this area are

- Builder (hammer shaped): used to build the selected project.
- Uploader: used to upload the generated equitable to the target hardware.







- The Info section where the state and progress of the build is Shown.
- Also the compilation error or run time errors are reported.






Programmer
Driver Installation 03





# **Programmer Driver Installation**










Project name: LedBlin	k		
✓ Use default location	n		
Location: C:\Users\Ah	med\Desktop\TempW	/orkSpaceTodelete\LedBlink	Browse
Choose file s	ystem: default 🔻		
	,	T 11	
Project type:		Toolchains:  AVR-GCC Toolchain	
Empty Project     AVR Cross Targe     Empty Project     AVR Cross Targe     Executable     Shared Library     Static Library     Makefile project			

















AVR Target Hardv	vare Properties				
Define the AVR targe					
МСИ Туре:	ATmega32			•	
MCU Frequency (Hz):	12000000				
?	< Back	Next >			

























































# Done











www.imtschool.com



www.facebook.com/imaketechnologyschool/

This material is developed by IMTSchool for educational use only

All copyrights are reserved