

BaristaPro 3000 – Quick Reference Guide

Fully automatic espresso and coffee machine · Model BP-3000

Descaling the machine

Limescale builds up over time and affects the taste of your coffee.

When the display shows DESCALE, the machine must be descaled.

1. Empty the drip tray and the coffee grounds container.
2. Remove the water filter from the water tank, if installed.
3. Pour 0.5 l of liquid descaler into the tank and fill up to the MAX mark.
4. Place a container of at least 1 l under the coffee spout and the steam wand.
5. Press and hold the CARE button for 3 seconds. The program takes about 25 minutes.
6. Rinse the water tank and fill it with fresh water when prompted.

Water hardness

Set the water hardness in the menu under SETTINGS > WATER. Use the test strip supplied. With the water filter installed, descaling is required less often.

Error messages

E1 Water tank empty or not inserted correctly

E2 Grounds container full

E4 Brewing unit blocked – remove and rinse the brewing unit under running water

E7 Temperature sensor fault – switch off and contact customer service

Warranty: 24 months from date of purchase. Keep your receipt.