



HIGH EFFICIENCY CONDENSING GAS FURNACE

PARTS REPLACEMENT INFORMATION GUIDE

CASING GROUP

Control (Outer) door
Blower access panel
Top filler plate
Bottom filler plate
Condensate trap

FILTER GROUP

Filter(s)
Filter retainer wire
Filter retainer wire latch
Filter retainer wire pivot
Media cabinet

BLOWER GROUP

Blower assembly
Blower housing
Blower motor
Blower wheel
Capacitor
Capacitor strap

ELECTRICAL GROUP

Control box
Junction box
Limit switch(es)
Circuit board
Door switch
Transformer
Wiring harness
3-Amp fuse
Over-temperature switch

GAS CONTROL GROUP

Manifold
Burner
Orifice
Flame sensor
Hot surface igniter
Gas valve
Gas valve w/ throttling valve
Combustion-air intake housing

INDUCER GROUP

Pressure switch(es)
Inducer motor
Inducer housing
Inducer motor mounting plates
Inducer wheel
Inducer motor capacitor

HEAT EXCHANGER GROUP

Primary HX cell
Primary HX cell panel
Secondary HX assembly
Limit shield
Coupling box

TO OBTAIN INFORMATION ON PARTS: Consult your installing dealer or classified section of your local telephone directory under the "Heating Equipment" or "Air Conditioning Contractors and Systems" headings for dealer listing by brand name, or contact:

CARRIER CORPORATION
Consumer Relations Department
P.O. Box 4808
Syracuse, New York 13221-4952
1-800-CARRIER

Have available the Model No., Series No., and Serial No. located on the unit rating plate to ensure correct replacement part.

Example of Model Number

<u>MODEL</u>	<u>HEATING SIZE</u>	<u>VARIATION</u>	<u>VOLTAGE</u>	<u>SERIES</u>	<u>PACKAGING</u>	<u>COOLING AIRFLOW (CFM)</u>
58MVC	060	F	1	0	1	14

WARNING: Improper installation, adjustment, alteration, service, or maintenance can cause personal injury, property damage, or death. Consult a qualified installer, service agency, or your local gas supplier for information or assistance. The qualified installer or service agency must use only factory-authorized replacement parts, kits, or accessories when modifying this product.