

ADDENDUM TO DIAGNOSTIC MANUAL 10000014636 PIN-OUT CHART

On page 113 of the diagnostic manual, J2-11 should be R2, J2-14 should be R3 and J2-15 should be R1

The wiring diagrams are correct.

J2 Connector		
Pin	Wire	Circuit Function
J2-1	395	Auxiliary Shutdown Ground
J2-2	210	Common Alarm Relay Output
J2-3	209	Common Alarm Relay Input
J2-4	14	12 VDC output for engine run condition. Fuel solenoid supply voltage.
J2-5	–	Not Used
J2-6	56	12 VDC output to starter contactor relay/ solenoid
J2-7	–	Not Used
J2-8	4A	DC (+) Field Excitation (Before Field Boost Diode)
J2-9	396	Auxiliary Shutdown: When wire 396 is grounded
J2-10	183	Not Used, Optional - 2-Wire Start (+5 VDC)
J2-11	R3	Model ID Resistor
J2-12	399B	Generator Current Sense B1
J2-13	398B	Generator Current Sense B2
J2-14	R1	Model ID Resistor (+)
J2-15	R2	Model ID Resistor (-)
J2-16	18	Ignition Shutdown: Controller grounded for shutdown; receives reference signal for speed sensing during start and run.