

ADDENDUM TO DIAGNOSTIC MANUAL 10000041488 PIN-OUT CHART

On page 252 of the diagnostic manual, J1-1 should be wire number 11S Generator Voltage Sensing J1-2 should be wire number 44S Generator Voltage Sensing.

J1-19 should be wire number 86 Low Oil Pressure and J1-20 should be wire number 85 High Temperature Shutdown.

The wiring diagrams are correct.

J1 Connector		
Pin	Wire	Circuit Function
J1-1	N1	208/240 VAC Generator Voltage Sensing
J1-2	N2	208/240 VAC Generator Voltage Sensing
J1-3	—	Not Used - UL Required Spacing
J1-4	N1	208 VAC (60hz) 190 - 208 VAC (50Hz) Utility sensing voltage
J1-5	N2	208 VAC (60hz) 190 - 208 VAC (50Hz) Utility sensing voltage
J1-6	—	Not Used - UL Required Spacing
J1-7	398A	Generator Current Sense A (+)
J1-8	399A	Generator Current Sense A (Gnd)
J1-9	194	Provides 12 VDC to the transfer relay (TR1)
J1-10	23	Switched to ground (internally) to energize the Transfer Relay
J1-11	13	12 VDC un-fused for the controller

J1-12	13	12 VDC un-fused for the controller
J1-13	0	Common Ground (DC) DC Field Excitation Ground
J1-14	819	Grounded by the controller to turn on the Maintenance (Yellow) LED
J1-15	818	Grounded by the controller to turn on Alarm (Red) LED
J1-16	817	Grounded by the controller to turn on System Ready (Green) LED
J1-17	820	Positive voltage (5VDC) for status LEDs
J1-18	178	Not Used, Optional - 2-Wire Start (return)
J1-19	85	Low oil pressure shutdown: Shutdown occurs when Wire 86 is ungrounded by loss of oil pressure in the LOP switch
J1-20	86	High temperature shutdown: Shutdown occurs when Wire 85 is ungrounded by contact opening in the oil temperature switch