

SECTION 4.3

TROUBLESHOOTING FLOW CHARTS

PART 4

DC CONTROL

Problem 18 – Engine Starts Hard and Runs Rough / Lacks Power / Backfires

