

# **SUPPLEMENTAL INSTALLATION & OPERATING INSTRUCTIONS for AEPT SERIES AIR HANDLER**



All information contained herein is subject to change without notice.

## INSTALLER

These instructions must be used in conjunction with the latest version of IO-230, which is shipped with the unit. It is important to follow both of these instructions and those in the latest version of IO-230 when installing the AEPT series of air handlers.

## THERMOSTAT CONNECTIONS

The following composite wiring diagrams detail various configurations in which the AEPT air handlers can be used. Examples include single-stage cooling and heat pump with single or two-stage electric heating. All these configurations can be applied with convenient connections to outdoor thermostat applications.

The following sections will be detailed:

- Single-Stage Cooling (GMC Thermostat Part #CHT18-60 or equivalent.)
- Heat Pump (GMC Thermostat Part #18-60 or equivalent)

Each diagram details the connections between room thermostat and AEPT air handlers, and the connections between the AEPT air handlers and the Condensing Unit (or Heat Pump) with optional connections to Outdoor Thermostats. For each

configuration, refer to the explanation of the proper jumper(s) to remove for the corresponding blower speed that will result in the programmed ECM™ motor.

**IMPORTANT:** WHEN MATCHING THE AEPT AIR HANDLERS TO A SINGLE STAGE COOLING UNIT OR HEAT PUMP, REMEMBER TO CONNECT THE "Y/Y2" THERMOSTAT CONNECTION ON THE VARIABLE SPEED BOARD (VSTB) TO THE THERMOSTAT. CONNECTING "Y1" WILL RESULT IN FIRST STAGE COOLING BLOWER SPEED AND MAY CAUSE THE CONTACTOR TO CHATTER.

An equivalent thermostat can be used in place of the Goodman thermostat part number. The GMC thermostats that listed are mercury type thermostats.




## WARNING

DISCONNECT ALL POWER SUPPLIES BEFORE SERVICING. FAILURE TO FOLLOW THIS INSTRUCTION COULD RESULT IN PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.


## SINGLE STAGE COOLING WITH SINGLE OR TWO-STAGE HEATING

### NOTES:


- 1.) Y/Y2 ENABLES HI SPD FAN COOLING
- 2.) E/W1 ENABLES LO SPD FAN HEATING  
W/W2 ENABLES HI SPD FAN HEATING
- 3.) OT1 PJ4 MUST BE CUT FOR THIS CONFIGURATION
- 4.) DIP SWITCH #4 MUST BE IN THE "ON" POSITION.
- 5.) CUT HUM PJ6 JUMPER IF USING HUMIDISTAT.  
STAT OPENS ON HUMIDITY RISE.



## COOLING ONLY - 2 STAGE HEAT THERMOSTAT




## COOLING ONLY - 2 STAGE HEAT (1st ROOM T'STAT & 2nd OT)




## COOLING ONLY - 2 STAGE HEAT (T'STAT ENABLED OT)


# HEAT PUMP WITH SINGLE OR TWO-STAGE HEATING (OPTIONS FOR EMERGENCY HEAT)




## HEATPUMP - WITH 1 STG EMHT 1 STG AUX HEAT




## HEATPUMP - 2 STG EMHT 1 STG AUX HEAT



## HEATPUMP - 2 STG EMHT 2 STG AUX - 1 OUTDOOR T'STAT



## HEATPUMP - 2 STG EMHT 2 STG AUX - 2 OUTDOOR T'STATS



NO AUX HEAT IN HEATPUMP MODE UNTIL OUTDOOR T'STAT CLOSES

**HEATPUMP - 2 STG EMHT 1 STG AUX - 1 OUTDOOR T'STAT**

## Quality Makes the Difference!

All of our systems are designed and manufactured with the same high quality standards regardless of size or efficiency. We have designed these units to significantly reduce the most frequent causes of product failure. They are simple to service and forgiving to operate. We use quality materials and components. Finally, every unit is run tested before it leaves the factory. That's why we know. . . **There's No Better Quality.**

Visit our websites at [www.goodmanmfg.com](http://www.goodmanmfg.com) or [www.amana-hac.com](http://www.amana-hac.com) for information on:

- Products
- Warranties
- Customer Services
- Parts
- Contractor Programs and Training
- Financing Options