


Installation Instructions

NOTE: Read the entire instruction manual before starting the installation.

pointSET™ U.S. Pat No. 7,415,102



A97040

**Fig. 1 - Infinity System Access Module
SYSTXCCSAM01**

TABLE OF CONTENTS

	PAGE
SAFETY CONSIDERATIONS	1
INSTALLATION CONSIDERATIONS	1
INTRODUCTION	1
INSTALLATION	2 - 3
Check Equipment and Job Site	2
Component Location and Wiring Considerations	2
Connect Power Source and Antenna	2
Radio Test	2
Install Components	2
Connect Infinity Systems	2
Connect Auxiliary System	3
System Start-Up	3
PIN Number	3
RS-232 CONNECTOR	3
UPDATING SYSTEM PROFILE	3
TROUBLESHOOTING	3

SAFETY CONSIDERATIONS

Improper installation, adjustment, alteration, service, maintenance, or use can cause explosion, fire, electrical shock, or other conditions which may cause death, personal injury or property damage. Consult a qualified installer, service agency or your distributor or branch for information or assistance. The qualified installer or agency must use factory-authorized kits or accessories when modifying this product. Refer to the individual instructions packaged with the kits or accessories when installing.

Follow all safety codes. Wear safety glasses, protective clothing, and work gloves. Have a fire extinguisher available. Read these instructions thoroughly and follow all warnings and cautions included in literature and attached to the unit. Consult local building codes and the current edition of the National Electrical Code (NEC) NFPA 70.

In Canada, refer to the current editions of the Canadian Electrical Code CSA C22.1.

Recognize safety information. When you see this symbol  on the unit and in instructions or manuals, be alert to the potential for personal injury. Understand the signal words **DANGER**, **WARNING**, and **CAUTION**. These words are used with the safety-alert symbol. **DANGER** identifies the most serious hazards, which **will** result in severe personal injury or death. **WARNING** signifies hazards, which **could** result in personal injury or death. **CAUTION** is used to identify unsafe practices, which **may** result in minor personal injury or product and property damage. **NOTE** is used to highlight suggestions which **will** result in enhanced installation, reliability, or operation.

INSTALLATION CONSIDERATIONS

Before the actual installation of a System Access Module can begin, determine the mounting location. A radio test must be performed with the System Access Module in the intended mounting location. See Step 4 to perform a radio test. The System Access Module is powered with a 24 VAC transformer which is available to order through RCD (SYSTXNNXFM01). A 120VAC supply must be near the mounting location of the System Access Module. Provisions must be made to secure the transformer to the outlet. The D-wire (24 VAC) from the Infinity system **MUST NOT** be used to power the System Access Module. Use this instruction to guide the actual installation process after the Infinity system(s) have been installed. One System Access Module is capable of handling two Infinity systems.

INTRODUCTION

An Infinity System Access Module allows remote connectivity for up to two Infinity systems within the same building. The Infinity system owner as well as authorized dealer can monitor and control the system via the Internet as well as by telephone. The System Access Module communicates through a two-way radio via the Skytel paging network. To check coverage, please visit:

http://www.skytel.com/coverage/telemetry_coverage.htm for the installation site. The coverage must be listed as “Full Service” for the System Access Module to function properly. Please note that Skytel is continuously expanding their service area so coverage may not be indicated by the web site. The System Access Module can also monitor a dry-contact sensor to provide a warning for the presence of water in the building, or some other use. If the sensor is active, the Infinity system will not be disabled or shut down.

INSTALLATION

Step 1 — Check Equipment and Job Site

INSPECT EQUIPMENT — File claim with shipping company, prior to installation, if shipment is damaged or incomplete.

Step 2 — Component Location and Wiring Considerations

⚠ WARNING

ELECTRICAL SHOCK HAZARD

Failure to follow this warning could result in personal injury, death or possible equipment damage.

Disconnect supply power before routing wire.

NOTE: All wiring must comply with national, state, and local codes.

LOCATING SYSTEM ACCESS MODULE

Since the System Access Module (SAM) uses two-way radio, choose a potential mounting location that is as high and as close to outside walls or windows as possible to attempt to maximize radio coverage. The coverage is dependent on where the Skytel transceivers are located. If one location does not work, try the opposite side to get the device in closer directional proximity. Temporarily mount the System Access module in the intended permanent mounting location until the radio test has passed 100%.

The System Access Module is approved for indoor use only and should never be installed with any of its components exposed to the elements. The System Access Module may be installed in any area where the temperature remains between -4°F and 158°F (-4°C and 70°C) and there is no condensation. The cover must be installed to prevent damage from other sources. Do not locate where it will be accessible to children. The SAM should be mounted in the vertical position. Remember that wiring access and Skytel reception are the most important considerations.

Select a location near the Infinity furnace or fan coil where wiring from the User Interface, each Remote Room Sensor or Smart Sensor, each damper actuator, and the equipment itself can come together easily.

⚠ CAUTION

ELECTRICAL OPERATION HAZARD

Failure to follow this caution may result in equipment damage or improper operation.

To prevent possible damage to the System access Module, do not mount on plenum, duct work, or flush against furnace.

WIRING CONSIDERATIONS — Ordinary thermostat wire is ideal when wiring the System Access Module (shielded cable is not necessary). Use 22 AWG or larger for normal wiring. Lengths over 100 ft. should use 20 AWG or larger wire.

Step 3 — Connect Power Source and Antenna

Screw the antenna to the radio connector. See Fig. 2 for antenna attachment location.

A 24 VAC transformer is required to power the System Access Module. The transformer is available to order through RCD (SYSTXNNXFM01). **DO NOT** connect the D-wire (24 VAC hot) from the Infinity system.

The transformer is heavy. Make sure it is secured to the power outlet with an appropriate screw through the base on the transformer.

Step 4 — Radio Test

The purpose of this test is to verify effective 2-way communications at the installation site. The test must pass 100% before the installation of the SAM can continue.

Press and hold the RADIO TEST button for at least 5 seconds. A flashing Yellow LED will indicate the test is in progress. A flashing Yellow and Green LED means the transmission is complete and the System Access Module is waiting for a reply. A constant Green LED means the radio test has passed. The radio will perform three message tests, so this sequence will occur three times. If the System Access Module has errors during the process, the test could take up to 15 minutes.

If the Red LED is lit solid, then the System Access Module failed to send the message. Try a new mounting location for the System Access Module.

If the Yellow LED is lit solid, then the System Access Module sent its message but did not receive a reply. The Carrier server may be down or the received signal is weak. Try a new mounting location for the System Access Module.

Aborting Test – There is no method to abort a radio test once it is started, other than to remove power.

The LEDs will maintain their state for 1 hour after the test. Pressing the Radio Test button momentarily will clear the LEDs. Pressing the Radio Test button again for five seconds will repeat the radio test. See Fig. 3 for a description of the radio test and LED sequence.

Step 5 — Install Components

INSTALL SYSTEM ACCESS MODULE — Once the radio test has passed, the System Access Module can be permanently installed. The System Access Module is designed so that wires can enter it from behind, above, or below. Plan wire routing before mounting.

1. Remove cover to access mounting holes.
2. Mount back plate to wall using screws and wall anchors provided.
3. Level back plate and tighten screws.

Step 6 — Connect Infinity Systems

⚠ CAUTION

UNIT OPERATION HAZARD

Failure to follow this caution may result in improper unit operation.

Improper wiring of the ABC connector will cause the System Access Module to operate improperly. Check to make sure all wiring is correct before proceeding with the installation or turning on power.

Connect the A, B, and C wires from the Infinity System to terminals labeled A1, B1, and C1. Connect the second Infinity System (if present) to the terminals labeled A2, B2, and C2.

ABC bus wiring only requires a three wire connection; however, it is good practice to run thermostat cable greater than three wires in the event of a damaged or broken wire during the installation.

It is recommended that the following color code be used when wiring each ABC connector:

A — Green Data A

B — Yellow Data B

C — White 24VAC (Com)

NOTE: The D-wire (red - 24 VAC hot) from the Infinity system is not connected to the System Access Module.

It is not mandatory that the above color code be used, but each ABC connector in the system MUST be wired consistently.

Step 7 — Connect Auxiliary Sensor (optional)

The System Access Module will support a dry contact sensor for use with water detection or some other use as seen fit. Connect one side of the contacts to connector AUXC (common) and the other side to connector AUX (input). The sensor input can provide up to 20mA at 5 volts d.c. If the sensor input is active, it will not shut down or affect operation of the HVAC system(s). A pop-up message will appear on the user interface indicating the auxiliary sensor is active. The home owner will also be notified via e-mail and/or phone if so chosen on the Internet web interface.

Step 8 — System Start-Up

After a successful radio test has occurred, power may be applied to the Infinity System(s). The user interface of the Infinity System will automatically find the System Access Module at power on. System installation screens will automatically appear and will display the Equipment Summary screen when finished. The equipment Summary screen will display REMOTE ACCESS near the bottom of the screen.

If REMOTE ACCESS is not displayed, check connections to the ABC wires as well as ensure the Yellow LED is lit on the System Access Module (this ensures the module has power). The green LED will be lit next to each ABC connection if the user interface has established communication.

Step 9 — PIN Number and Serial Number

The PIN and Serial number of the System Access Module are used by the system owner to register their system with Carrier. Remove the sticker containing the PIN number from the radio and install at the front of the Owner's Guide. Also, write down the SAM serial number in the Home Owner's Guide. The serial number can be found on the SAM packaging, at the bottom of the large SAM circuit board or in the user interface Service Menu. If PIN number is lost or missing, it can be found by entering the Service Menu of the User Interface (10 second press of the Advance button) and

looking at the Model/Serial Numbers screen. The PIN will be listed with the System Access Module model and serial numbers.

RS-232 CONNECTOR

An RS-232 port has been provided for connection to home automation equipment. Consult your home automation supplier for support.

UPDATING SYSTEM PROFILE

The Infinity System will automatically send system information to Carrier's computer servers within one hour after the system has been successfully installed. Access to the system via the Internet or telephone will not be available until this occurs. The system can be forced to send its information through the following process if Internet and telephone access is required immediately. Press and hold the RADIO TEST button for 15 seconds. When the button is first pressed, the red LED will turn on. Five seconds into the press, the yellow LED will turn on. 15 seconds into the press, the green COM1 LED will turn on. Release the button when the green LED turns on. The red LED will flash when messages are being sent. The red and yellow LEDs will flash when the SAM is waiting for message replies. Upon successful profiling, both green LEDs will be lit. If profiling is not successful, the red LED will be lit solid. The entire profiling process can take up to 15 minutes per Infinity System. If two systems are connected to one SAM, then the profiling process can take up to 30 minutes.

If the Infinity system ABC wiring is moved from connector 1 to connector 2 (or vice versa), or Infinity equipment has changed, the System Access Module must update Carrier's servers with the new information. This will happen automatically within one hour, or can be manually forced with the process described above.

TROUBLESHOOTING

FAULT INDICATORS — Under normal operation, the Yellow and Green LED will be on continuously (solid). If the System Access Module does not receive communications with the Infinity system, the Green LED will not be on. If there are faults present, the Yellow LED indicator will blink a two digit status code. The first digit will blink at a fast rate, the second at a slow rate.

STATUS CODE	DESCRIPTION
45	Board Failure
61	Radio out of range (no coverage for five minutes)
62	Loss of communication with the radio
63	Radio not registered with the local network (unregistered for five minutes)
64	Auxiliary sensor active




Fig. 2 - System Access Module Control Board

A04224




Fig. 3 - Radio Test Process and LED Sequence

A05073

