Module:mega-mcu100/0.3 Connectors_EFI_ECUs_Con_825213-1 35 35 34 34 33 33 32 32 32 31 31 31 30 30 29 28 28 27 27 26 26 25 24 24 23 23 22 22 21 20 20 19 19 SPI3_SCK_(PC10) SPI3_MISO_(PC11) SPI3_MOSI_(PC12) SPI3_CS_(PA15) E17
E16
OUT_INJ1_(PD3)
OUT_INJ2_(PA9)
OUT_INJ3_(PD11)
E14
VE13
VE12
VE11
OUT_INJ6_(PAB)
OUT_INJ6_(PAB)
OUT_INJ8_(PD12)
OUT_INJ8_(PD12) CANH W11 W12 E18 E19 OUT_PWM1_(PD13) OUT_PWM2_(PC6) OUT_PWM3_(PC7) OUT_PWM4_(PC8) OUT_PWM6_(PD14) F40x does not have UART8_RX_(PE0) N18 × N19 × N19 UART2_RX_(PD6) N14 N13 S14 S16 S17 IN_CRANK_(PB1) IN_CAM_(PA6) IN_VSS_(PE11) USBP_(PA12) USBM_(PA11) USBID_(PA10) VBUS S18 X S19 IN_TPS_(PA4) IN_PPS_(PA3) S20 IN_IAT_(PC3) IN_CLT_(PC2) S11 IN_025_/_CAN_WAKEUP_(PA0) IN_0252_(PA1) Internal nReset buttons BOOTO N16 S13 | IN_MAP1_(PC0) | IN_MAP2_(PC1) LED_GREEN N14a N14b S15 IN_KNOCK_(PA2) S4 IN_D1_(PE12)
S3 IN_D2_(PE13)
S2 IN_D3_(PE14)
IN_D4_(PE15) V33_SWITCHABLE

Connected V33
N21
N23
V5A_SWITCHABLE
V5A_SWITCHABLE
V5A_SWITCHABLE
V5A_SWITCHABLE
Connected GNDA
Connected GNDA
E2 S22 S5 W13 VREF1 VREF2 V33_REF N20 OUT_PWR_EN_(PE10) E5 | IN_VIGN_(PA5) | VBAT | VCC | GND | Sheet: / File: balefi.kicad_sch Title: Size: A3 Date:
KiCad E.D.A. kicad-cli 7.0.11-7.0.11~ubuntu22.04.1