



Cannot open file C:\Users\vojislav\Documents\Projects\pcb-antenna\Pics\irnas_logo.png **ESP-MONITOR** Module for serial data and current consumption monitoring **CONTENTS:** PAGE1 - CONTENTS PAGE2 - ESP12_CORE PAGE3 - USB_TO_UART PAGE4 - POWER **PAGE5 - CURRENT MONITOR Version Revision: 1.0 DESIGN CONSIDERATIONS** DESIGN NOTE: Example text for informational design notes. Irnas www.irnas.eu Title: ESP-MONITOR.PriPCB Example text for critical design notes. Page Contents: PAGE1-CONTENT.SchDoc 1.0 LAYOUT NOTE: Example text for critical layout guidelines. Altıum Number:* Revision.* Date: 05/03/2019 Time: 14:44:12 Sheet* of










CZ1



Board Stack Report