

For the ZTE ZXA10 C600, the SNMP OIDs for reading ONU RX optical power have transitioned from the legacy **1.3.6.1.4.1.3902.1012** subtree to the modern **1.3.6.1.4.1.3902.1082** (zxAccessNode) subtree 1.

Depending on whether you want to measure the signal from the OLT as received by the ONU, or the signal from the ONU as received by the OLT, there are two distinct OIDs:

1. ONU Receive Power (Rx power at ONU Side)

This OID measures the power of the OLT's signal as it reaches the ONU. It is located in the GPON ONU Remote Management table 2, 3.

- **OID:** 1.3.6.1.4.1.3902.1082.500.20.2.1.10 (zxAnGponRmAniRxOptLevel) 3
- **Raw Value Format:** The value is provided in **dBuW** (decibel-microwatts) using a **2s complement** integer with a **0.002 dB resolution** 3.
- **Scale/Formula:** To convert the raw integer to **dBm**, use the following formula:
- **\$dBm = (RawValue $\times$ 0.002) - 30\$**
- *Note: 0xFFFF indicates the value is unknown or the ONU is offline* 3.

2. OLT Receive Power (Rx power of ONU at OLT Side)

This OID measures the optical power of the ONU's signal as it is received by the OLT's PON port. This is often the primary metric used for monitoring signal quality 4.

- **OID:** 1.3.6.1.4.1.3902.1082.500.10.2.11.1.2 (zxAnPonRxOpticalPower) 4
- **Raw Value Format:** The value is a signed integer representing power in **0.001 dBm** increments 4.
- **Scale/Formula:** Divide the raw integer by **1000** to get the value in dBm.
- **\$dBm = RawValue / 1000\$**
- *Example: A raw value of -19500 corresponds to -19.5 dBm* 4.
- *Special values: -80000 indicates no signal, and 65535000 indicates N/A (ONU not in service)* 4.

Subtree Comparison

The subtree 1.3.6.1.4.1.3902.1012.3.50.12 belongs to the legacy **ZTE-GPON-MIB** used by older OLT models 1. Modern ZXA10 series OLTs like the C600 use the .1082 (zxAccessNode) structure for all GPON service and performance management 1, 5.

Would you like to know the OIDs for configuring optical power alarm thresholds (High/Low Rx) for these ONUs?