Nikon Corporation Remote SDK Simplified API, Capabilities and Events

Version.1.0 Revision.1.0

March 23, 2026

Nikon Corporation

1 Introduction

This document explains the Simplified API, capabilities and events which is supported by Remote SDK.

2 Simplified API

2.1 InitializeSDK

This Simplified API is used to initialize the SDK. it will give the device list and module related capabilities.

2.1.1 API signature

```
NKERROR WINAPI InitializeSDK(
        LPMAIDAllocateMemory allocMemory,
        LPMAIDFreeMemory freeMemory,
        LPNkMAIDCSCallback callback,
        LPNkMAIDEnumDevices *ppDeviceList
        LPNkMAIDEnumCapInfo *ppEnumCapInfo
        )
```

2.1.2 Parameters

LPMAIDAllocateMemory allocMemory : This is an input parameter. This parameter is used to send function pointer of memory allocation API.

LPMAIDFreeMemory freeMemory : This is an input parameter. This parameter is used to send function pointer of memory free API.

LPNkMAIDCSCallback callback : This is an input parameter. Used to register callback functions. GUI need to send function pointers for different function, please refer below table.

LPNkMAIDCSCallback Member variable	Description
LPNkMAIDCSCallback.pUIReqProc	A function pointer to the UI request Proc
LPNkMAIDCSCallback.pfnEventProc	A function pointer to the event Proc
LPNkMAIDCSCallback.pProgressProc	A function pointer to the Progress Proc
LPNkMAIDCSCallback.pDataProc	A function pointer to the Data Proc
LPNkMAIDCSCallback.pLiveViewDataProc	A function pointer to the Live view data Proc

LPNkMAIDEnumDevices *ppDeviceList : This is an input/output parameter. GUI will pass the address of LPNkMAIDEnumDevices, If not null, CS Layer will allocate the required memory and copy the device List.

LPNkMAIDEnumDevices

LPNkMAIDEnumDevices Member Variables	Description
LPNkMAIDEnumDevices.ulElements	The total number of devices
LPNkMAIDEnumDevices.ulValue	Current device index
LPNkMAIDEnumDevices.pDeviceData	An object of LPNkMAIDDeviceInfo containg the individual device information.

LPNkMAIDDeviceInfo

LPNkMAIDDeviceInfo Member Variables	Description
LPNkMAIDDeviceInfo.ID	Device Id
LPNkMAIDDeviceInfo.Name	Device Name
LPNkMAIDDeviceInfo.Availability	Device id available for connection or not
LPNkMAIDDeviceInfo.ulConnectedPID	Connected process ID

LPNkMAIDEnumCapInfo *ppEnumCapInfo :This is an input/output parameter. GUI will pass the address of LPNkMAIDEnumCapInfo, If not null, CS Layer will allocate the required memory and copy the module related capabilities.

LPNkMAIDEnumCapInfo

LPNkMAIDEnumCapInfo Member Variables	Description
LPNkMAIDEnumCapInfo.pCapArray	An object of type LPNkMAIDCapInfo containing the capabilities information
LPNkMAIDEnumCapInfo.ulCapCount	Number of capability
LPNkMAIDEnumCapInfo.ulAllocationSize	Memory allocation size

LPNkMAIDCapInfo

LPNkMAIDCapInfo Member Variables	Description
LPNkMAIDCapInfo.ulID	Capability ID
LPNkMAIDCapInfo.ulType	one of eNkMAIDCapabilityType enum
LPNkMAIDCapInfo.ulVisibility	eNkMAIDCapVisibility bits. The module will set the ulVisibility member of the NkMAIDCapInfo structure to indicate what level of visibility a particular capability has.
LPNkMAIDCapInfo.ulOperations	eNkMAIDCapOperations bits. The module will set the ulOperations member of the NkMAIDCapInfo structure to indicate what operations are permitted on a particular capability
LPNkMAIDCapInfo.szDescription	text describing the capability

2.1.3 Return Type

Return Type NKERROR

Result Code

Result Code	Description
kNkMAIDResult_NoError	No error
kNkMAIDResult_UnexpectedError	When an unexpected error is occur
kNkMAIDAPIResult_InvalidArguments	When the incorrect argument is passed

kNkMAIDAPIResult_InvalidState	When the SDK state is not valid that is SDK state other than “SDK Not Loaded”.
kNkMAIDResult_OutOfMemory	When Memory allocation fail inside the SDK

2.2 FreeSDK

This Simplified API is used to Free the SDK.

2.2.1 API signature

```
HRESULT WINAPI FreeSDK()
```

2.2.2 Parameters

None

2.2.3 Return Type

Return Type HRESULT

2.3 ConnectDevice

This Simplified API is used to connect the Camera, Also load the source object capabilities.

2.3.1 API signature

```
NKERROR WINAPI ConnectDevice(
ULONG ulDeviceId,
LPNkMAIDEnumCapInfo *ppEnumCapInfo
)
```

2.3.2 Parameters

ULONG ulDeviceId : Device Id for session opening. It is an input parameter.

LPNkMAIDEnumCapInfo *ppEnumCapInfo : It is an input/output parameter. GUI will pass the address of LPNkMAIDEnumCapInfo, If not null, CS Layer will allocate the required memory and copy all device related capabilities.

LPNkMAIDEnumCapInfo Member Variables	Description
LPNkMAIDEnumCapInfo.pCapArray	It is an object of LPNkMAIDCapInfo structure. SDK fill it with device related capability array.
LPNkMAIDEnumCapInfo.ulCapCount	This member provide the information of the total number of capabilities in capability array.
LPNkMAIDEnumCapInfo.ulAllocationSize	Allocate memory size.

LPNkMAIDCapInfo

For this structure information refer section 3.1 InitializeSDK.

2.3.3 Return Type

Return Type NKERROR

Result Code

Result Code	Description
kNkMAIDResult_NoError	No error
kNkMAIDResult_UnexpectedError	When an unexpected error is occur
kNkMAIDAPIResult_InvalidDeviceID	When the incorrect device id is passed
kNkMAIDAPIResult_InvalidState	When the SDK state is not valid that is SDK state other than “SDK Loaded”.
kNkMAIDResult_OutOfMemory	When Memory allocation fail inside the SDK

2.4 DisconnectDevice

This Simplified API is used to disconnect the Camera. It will Kill live view thread and execution thread. Abort all input command if any. Clear device related capability array and start the execution thread again.

2.4.1 API signature

```
HRESULT WINAPI DisconnectDevice()
```

2.4.2 Parameters

None

2.4.3 Return Type

Return Type HRESULT

2.5 StartLiveView

This Simplified API is used to start remote live view.

2.5.1 API signature

```
NKERROR WINAPI StartLiveView(
LPMAIDAsyncCompletionProc pProc,
NKREF nkRef
)
```

2.5.2 Parameters

LPMAIDAsyncCompletionProc pProc : It is an input/output parameter, To judge Api call is sync or async. If pProc is null means Async."pProc" will be called after completion of Api.

NKREF nkRef : Reference set by GUI. It is an input parameter.

2.5.3 Return Type

Return Type NKERROR

Result Code

Result Code	Description
kNkMAIDResult_NoError	No error
kNkMAIDResult_UnexpectedError	When an unexpected error is occur
kNkMAIDAPIResult_StartLiveViewFailed	When unable to start live view. Some possible scenarios are Unable to get Live view status or live view status is kNkMAIDLiveViewStatus_ON_RemoteLV Unable to get CS Layer reference. Unable to get value of capability kNkMAIDCapability_LiveViewProhibit or value of kNkMAIDCapability_LiveViewProhibit is not equal to 0
kNkMAIDAPIResult_InvalidState	When the SDK state is not valid.
kNkMAIDResult_OutOfMemory	When Memory allocation fail inside the SDK

2.6 StopLiveView

This Simplified API is used to stop remote live view.

2.6.1 API signature

```
NKERROR WINAPI StopLiveView(
LPMAIDAsyncCompletionProc pProc,
NKREF nkRef
)
```

2.6.2 Parameters

LPMAIDAsyncCompletionProc pProc : It is an input/output parameter, To judge Api call is sync or async. If pProc is null means Async."pProc" will be called after completion of Api.

NKREF nkRef : Reference set by GUI. It is an input parameter.

2.6.3 Return Type

Return Type NKERROR

Result Code

Result Code	Description
kNkMAIDResult_NoError	No error
kNkMAIDResult_UnexpectedError	When an unexpected error is occur
kNkMAIDAPIResult_InvalidState	When the SDK state is not valid.

2.7 GetLiveViewStatus

This Simplified API is used to get live view status.

2.7.1 API signature

```
HRESULT WINAPI GetLiveViewStatus(
eNkMAIDLiveViewStatus &LiveViewStatus
)
```

2.7.2 Parameters

eNkMAIDLiveViewStatus &LiveViewStatus : It is an input/output parameter. SDK update the live view status, which is one of the eNkMAIDLiveViewStatus enum

2.7.3 Return Type

Return Type HRESULT

2.8 StartShooting

This Simplified API is used start shooting.

2.8.1 API signature

```
NKERROR WINAPI StartShooting(
MAIDShootingStructure &stShootParam,
LPMAIDAsyncCompletionProc pProc,
NKREF nkRef
)
```

2.8.2 Parameters

MAIDShootingStructure &stShootParam : It is an input parameter. GUI will send information in structure required for shooting. Below are the explanation of each member of MAIDShootingStructure structure**.**

MAIDShootingStructure Member Variables	Description
MAIDShootingStructure.ShootingType	GUI pass shooting type in this member, which is one of the eNkMAIDShootingType enum. eNkMAIDShootingType.kNkSDKShootingTypeSingle = Single shooting eNkMAIDShootingType.kNkSDKShootingTypeContinuous = Continuous Shooting eNkMAIDShootingType.kNkSDKShootingTypeInterval = Interval shooting eNkMAIDShootingType.kNkSDKShootingTypeSelfTimer = Selftimer shooting eNkMAIDShootingType.kNkSDKShootingTypeBULB = Bulb Shooting
MAIDShootingStructure.ulContinuous_Interval_NumShots	GUI will provide number of shots in case of interval shooting or continuous shooting.
MAIDShootingStructure.ulBULBExposureDuration	GUI will provide Bulb exposure time in second when the shooting type is set to bulb.
MAIDShootingStructure.ulShootingStartTimeFromNow	GUI will provide Start time in second when the shooting type is self-timer or interval shooting.
MAIDShootingStructure.ulIntervalTime	GUI will provide the interval time seconds when the shooting type is interval shooting.\
MAIDShootingStructure.bAutoFocus	GUI will provide information either auto focus is true or false.
MAIDShootingStructure.ImageSavePath	GUI will provide the directory path where the image should be save. Default path can also be set by **SetImageVideoSavePath** simplified API refer 3.21

LPMAIDAsyncCompletionProc pProc : It is an input/output parameter, To judge Api call is sync or async. If pProc is null means Async."pProc" will be called after completion of Api.

NKREF nkRef : Reference set by GUI. It is an input parameter.

2.8.3 Return Type

Return Type NKERROR

Result Code

Result Code	Description
kNkMAIDResult_NoError	No error
kNkMAIDResult_UnexpectedError	When an unexpected error is occur
kNkMAIDAPIResult_InvalidState	When the SDK state is not valid.
kNkMAIDAPIResult_InvalidArguments	When the incorrect argument is passed
kNkMAIDAPIResult_InvalidShootingType	When the Shooting type is invalid.
kNkMAIDAPIResult_InvalidShootingMode	When the shooting mode is invalid.
kNkMAIDAPIResult_InvalidBULBExposureTime	When BULBExposureTime is <= minimum time(0).
kNkMAIDAPIResult_InvalidInterval	When interval time in case of interval shooting is 0.
kNkMAIDAPIResult_InvalidShootCount	When Shoot count is less then 2 in case of interval shooting.

2.9 CancelShooting

This Simplified API is used cancel shooting.

2.9.1 API signature

```
NKERROR WINAPI CancelShooting(
LPMAIDAsyncCompletionProc pProc,
NKREF nkRef
)
```

2.9.2 Parameters

LPMAIDAsyncCompletionProc pProc : It is an input/output parameter, To judge Api call is sync or async. If pProc is not null means Async."pProc" will be called after completion of Api.

NKREF nkRef : Reference set by GUI. It is an input parameter.

2.9.3 Return Type

Return Type NKERROR

Result Code

Result Code	Description
kNkMAIDResult_NoError	No error
kNkMAIDResult_UnexpectedError	When an unexpected error is occur

kNkMAIDAPIResult_ShootingCancelFailed	When cancel shooting failed.
kNkMAIDAPIResult_InvalidShootingType	When the Shooting type is invalid.

2.10 GetShootingStatus

This Simplified API is used get shooting status.

2.10.1 API signature

```
HRESULT WINAPI GetShootingStatus(
eNkMAIDShootingStatus &ShootingStatus
)
```

2.10.2 Parameters

eNkMAIDShootingStatus &ShootingStatus : It is an input/output parameter, SDK update the shooting status, which is one of the eNkMAIDShootingStatus enum

2.10.3 Return Type

Return Type HRESULT

2.11 GetRemainingShootCount

This Simplified API is used get remaining shoot count in case of continuous shooting and interval shooting.

2.11.1 API signature

```
HRESULT WINAPI GetRemainingShootCount(
ULONG &RemShootCount
)
```

2.11.2 Parameters

ULONG &RemShootCount : It is an input/output parameter, SDK update the remaining shoot count.

2.11.3 Return Type

Return Type HRESULT

2.12 GetCapability

This Simplified API is used get the capability value.

2.12.1 API signature

```
NKERROR WINAPI GetCapability(
ULONG ulCapabilityId,
eNkSDKGetSettingRequestType eType,
eNkMAIDDataType &ulDataType
```

)

2.12.2 Parameters

ULONG ulCapabilityId : Capability id to get the value.

eNkSDKGetSettingRequestType eType: One of the value of eNkSDKGetSettingRequestType enum.

eNkSDKGetSettingRequestType Member Variables	Description
eNkSDKGetSettingRequestType.kNkSDKGetSettingValue	For getting the current value of the given capability.
eNkSDKGetSettingRequestType.kNkSDKGetSettingSupportedValueArray	For getting all supported values array that can be get or set for the given capability.
eNkSDKGetSettingRequestType.kNkSDKGetSettingDefaultValue	For getting the default value of given capability.

LPVOID &pDataPtr : It is an input/output parameter, SDK allocate the required memory based on the data type of capability and copy the data.

eNkMAIDDataType &ulDataType : It is an input/output parameter, GUI will provide data type of capability.

2.12.3 Return Type

Return Type NKERROR

Result Code

Result Code	Description
kNkMAIDResult_NoError	No error
kNkMAIDResult_UnexpectedError	When an unexpected error is occur
kNkMAIDAPIResult_InvalidArguments	When incorrect argument is passed.
kNkMAIDAPIResult_OperationNotSupported	When the requested operation not supported.
kNkMAIDAPIResult_CapabilityNotSupported	When requested capability not supported.
kNkMAIDResult_UnexpectedDataType	When an unexpected data type found for he given capability.
kNkMAIDAPIResult_InvalidState	When SDK not in valid state for getting capability values.
kNkMAIDResult_OutOfMemory	When memory allocation fail inside the SDK.

Other than above error Some other errors result code can also return based on the specific capability. For that refer that capability description.

2.13 SetCapability

This Simplified API is used set the capability value.

2.13.1 API signature

```
NKERROR WINAPI SetCapability(
ULONG ulCapabilityId,
LPVOID pData,
eNkMAIDDataType ulDataType
```

)

2.13.2 Parameters

ULONG ulCapabilityId : Capability id to set the value.
LPVOID &pDataPtr : It is an input parameter, *pData is being new value of capability.
eNkMAIDDataType &ulDataType : It is an input/output parameter, ulDataType to determine data type of pData.

2.13.3 Return Type

Return Type NKERROR

Result Code

Result Code	Description
kNkMAIDResult_NoError	No error
kNkMAIDResult_UnexpectedError	When an unexpected error is occur
kNkMAIDAPIResult_InvalidArguments	When incorrect argument is passed.
kNkMAIDAPIResult_OperationNotSupported	When the requested operation not supported.
kNkMAIDAPIResult_CapabilityNotSupported	When requested capability not supported.
kNkMAIDResult_UnexpectedDataType	When an unexpected data type found for he given capability.
kNkMAIDAPIResult_InvalidState	When SDK not in valid state for getting capability values.
kNkMAIDResult_OutOfMemory	When memory allocation fail inside the SDK.

Other than above error Some other errors result code can also return based on the specific capability. For that refer that capability description.

2.14 EnumCapabilities

This Simplified API is used get the all capability values and capability count.

2.14.1 API signature

```
NKERROR WINAPI EnumCapabilities(
LPNkMAIDEnumCapInfo &pEnumCapInfo,
LPMAIDAsyncCompletionProc pProc,
NKREF nkRef
)
```

2.14.2 Parameters

LPNkMAIDEnumCapInfo &pEnumCapInfo : pEnumCapInfo to get all the capability information with capability count. SDK will allocate required memory and copy the data.
For LPNkMAIDEnumCapInfo structure member detail please refer **3.1 InitializeSDK**

LPMAIDAsyncCompletionProc pProc : It is an input/output parameter, To judge Api call is sync or async. If pProc is not null means Async."pProc" will be called after completion of Api.

NKREF nkRef : Reference set by GUI. It is an input parameter.

2.14.3 Return Type

Return Type NKERROR

Result Code

Result Code	Description
kNkMAIDResult_NoError	No error
kNkMAIDResult_UnexpectedError	When an unexpected error is occur
kNkMAIDAPIResult_InvalidArguments	When incorrect argument is passed.
kNkMAIDAPIResult_InvalidState	When SDK not in valid state for getting capability values.

2.15 EnumDevices

This Simplified API is used get the device list and availability of the devices..

2.15.1 API signature

```
NKERROR WINAPI EnumDevices(
LPNkMAIDEnumDevices &pEnumDeviceInfo,
LPMAIDAsyncCompletionProc pProc,
NKREF nkRef
)
```

2.15.2 Parameters

LPNkMAIDEnumDevices &pEnumDeviceInfo : pEnumDeviceInfo to get all the device information with device count and availability info. CS Layer will allocate required memory and copy the data. For detail of LPNkMAIDEnumDevices please refer section **3.1 InitializeSDK**

LPMAIDAsyncCompletionProc pProc : It is an input/output parameter, To judge Api call is sync or async. If pProc is not null means Async."pProc" will be called after completion of Api.

NKREF nkRef : Reference set by GUI. It is an input parameter.

2.15.3 Return Type

Return Type NKERROR

Result Code

Result Code	Description
kNkMAIDResult_NoError	No error
kNkMAIDResult_UnexpectedError	When an unexpected error is occur
kNkMAIDAPIResult_InvalidArguments	When incorrect argument is passed.
kNkMAIDAPIResult_InvalidState	When SDK not in valid state for getting capability values.

2.16 GetLoggingLevel

This Simplified API is used get current log level.

2.16.1 API signature

```
HRESULT WINAPI GetLoggingLevel(
eNkMAIDLoggingLevel &LoggingLevel
)
```

2.16.2 Parameters

eNkMAIDLoggingLevel &LoggingLevel : It is an input/output parameter, SDK fill one of the value of eNkMAIDLoggingLevel enum.

2.16.3 Return Type

Return Type HRESULT

2.17 SetLoggingLevel

This Simplified API is used set log level.

2.17.1 API signature

```
NKERROR WINAPI SetLoggingLevel(
eNkMAIDLoggingLevel LoggingLevel
)
```

2.17.2 Parameters

eNkMAIDLoggingLevel LoggingLevel : It is an input parameter, SDK set one of the value of eNkMAIDLoggingLevel enum

2.17.3 Return Type

Return Type HRESULT

Result Code

Result Code	Description
kNkMAIDResult_NoError	No error
kNkMAIDResult_UnexpectedError	When an unexpected error is occur
kNkMAIDResult_ValueOutOfBounds	When incorrect log level is passed.

2.18 StartMovieRecording

This Simplified API is used start movie recording.

2.18.1 API signature

```
NKERROR WINAPI StartMovieRecording(
LPSTR sPath,
LPMAIDAsyncCompletionProc pProc,
```

```
NKREF nkRef
)
```

2.18.2 Parameters

LPSTR sPath : Path to save video file.

LPMAIDAsyncCompletionProc pProc : It is an input/output parameter, To judge Api call is sync or async. If pProc is not null means Async."pProc" will be called after completion of Api.

NKREF nkRef : Reference set by GUI. It is an input parameter.

2.18.3 Return Type

Return Type NKERROR

Result Code

Result Code	Description
kNkMAIDResult_NoError	No error
kNkMAIDResult_UnexpectedError	When an unexpected error is occur
kNkMAIDAPIResult_InvalidArguments	When incorrect argument is passed.
kNkMAIDResult_OutOfMemory	When memory allocation failed inside the SDK.

2.19 StopMovieRecording

This Simplified API is used stop movie recording.

2.19.1 API signature

```
NKERROR WINAPI StopMovieRecording(
LPMAIDAsyncCompletionProc pProc,
NKREF nkRef
)
```

2.19.2 Parameters

LPMAIDAsyncCompletionProc pProc : It is an input/output parameter, To judge Api call is sync or async. If pProc is not null means Async."pProc" will be called after completion of Api.

NKREF nkRef : Reference set by GUI. It is an input parameter.

2.19.3 Return Type

Return Type NKERROR

Result Code

Result Code	Description
kNkMAIDResult_NoError	No error
kNkMAIDResult_UnexpectedError	When an unexpected error is occur
kNkMAIDAPIResult_InvalidArguments	When incorrect argument is passed.

kNkMAIDResult_OutOfMemory	When memory allocation failed inside the SDK.

2.20 SetImageVideoSavePath

This Simplified API is used start operation for some capabilities.

2.20.1 API signature

```
For Windows
W32EXPORT NKERROR WINAPI SetImageVideoSavePath(
const wchar_t *pImageSavePath  ,
const wchar_t *pVideoSavePath
)

For MAC
W32EXPORT NKERROR WINAPI SetImageVideoSavePath(
const char *pImageSavePath,
const char *pVideoSavePath
)
```

2.20.2 Parameters

const wchar_t *pImageSavePath : Folder path to save images. For Mac it is char* instead of wide char.

const wchar_t *pVideoSavePath : Folder path to save video. For Mac it is char* instead of wide char.

2.20.3 Return Type

Return Type NKERROR

Result Code

Result Code	Description
kNkMAIDResult_NoError	No error
kNkMAIDResult_UnexpectedError	When an unexpected error is occur
kNkMAIDAPIResult_InvalidArguments	When incorrect argument is passed.
kNkMAIDResult_OutOfMemory	When memory allocation failed inside the SDK.

2.21 StartOperation

This Simplified API is used start operation for some capabilities.

2.21.1 API signature

```
NKERROR WINAPI StartOperation(
ULONG ulCapabilityId,
LPMAIDAsyncCompletionProc pProc,
NKREF nkRef
)
```

2.21.2 Parameters

ULONG ulCapabilityId : Capability Id to start the operation.

LPMAIDAsyncCompletionProc pProc : It is an input/output parameter, To judge Api call is sync or async. If pProc is not null means Async."pProc" will be called after completion of Api.

NKREF nkRef : Reference set by GUI. It is an input parameter.

2.21.3 Return Type

Return Type NKERROR

Result Code

Result Code	Description
kNkMAIDResult_NoError	No error
kNkMAIDResult_UnexpectedError	When an unexpected error is occur
kNkMAIDAPIResult_InvalidArguments	When incorrect argument is passed.

3 Vendor Unique Capabilities

3.1 Aperture

This will set the value of Aperture.

Capability kNkMAIDCapability_Aperture

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_PackedString

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, , kNkMAIDCapOperation_GetArray

Data String of F value (e.g.) “1.4”, “1.6”, “1.8”,”2”... (Default : Minimum value of setting range)

Capability_MovieAperture is used for during movie live view, during movie file recording. Capability_Aperture is used for taking photos, during live view photography.
When the aperture value is an integer, the decimal point is not included in the string.
When aperture is not set to minimum (FEE), the string of “EE” is set.
When CPU lens is not attached, this capability returns aperture of the Capability_F0Manual setting. If the Capability_F0Manual is set to “N/A”, returns “--”.

If the LensSort is not installed, enumeration cannot be created, so the enumeration count is set to 1 and the enumeration value/DefaultValue/PropertyValue is set to the same value. For models that support an exposure meter coupling lever, this value changes depending on the F0ManualSetting2 and the state of the exposure meter coupling lever.
The value is 1EV except for the maximum aperture. For models that do not support an exposure meter coupling lever or for models where the aperture value cannot be obtained, the value is set to 0. In the case of an aperture value error, the enumeration count is set to 1 and the enumeration value/DefaultValue/PropertyValue is set to 0xFFFF.

PropertyValue is the aperture value multiplied by 100. PropertyValue changes depending on the value of the ExposureEvStep.
The setting range for PropertyValue changes depending on the lens and magnification settings.

The following cases, this Capability is read only.

- When the exposure mode are except “A” and “M”.
- The LensSort is set to "Not Attached."
- When the WarningStatus is "Sequence error", “Bulb warning/Time warning”, "Zoom ring retraction warning”, “Shutter speed incompatible HDR shooting not possible warning”.
- When the AVLockSetting is set to "Yes".
- Aperture value error

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.2 MovieAperture

This will set the value of Aperture during movie live view.

Capability kNkMAIDCapability_MovieAperture

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_PackedString

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data String of F value (e.g.) “1.4”, “1.6”, “1.8”,”2”... (Default : Minimum value of setting range)

It is used for the exposure time of each frame of the movie.

Capability_MovieAperture is used for during movie live view, during movie file recording, during "Live frame grab". Capability_Aperture is used for taking photos, during live view photography.
When the aperture value is an integer, the decimal point is not included in the string.
When CPU lens is not attached, this capability returns aperture of the Capability_F0Manual setting. If the Capability_F0Manual is set to “N/A”, it is returns “--”.
If the LensSort is not installed, an enumeration cannot be created, so the enumeration count is set to 1 and the enumeration value/DefaultValue/PropertyValue is set to the same value.

For models that support an exposure meter coupling lever, this changes depending on the F0ManualSetting2 and the state of the exposure meter coupling lever.
The value is 1EV except for the maximum aperture. For models that do not support an exposure meter coupling lever or for models where the aperture value cannot be obtained, the value is set to 0.

In the case of an aperture value error, the enumeration count is set to 1 and the enumeration value/DefaultValue/PropertyValue is set to 0xFFFF.
If the camera is not in video mode, the value is undefined, so the enumeration count is set to 1 and the enumeration value/DefaultValue/PropertyValue is set to 0.

If the ExposureProgramMode is M or A, the PropertyValue is set to the value of the Fnumber immediately before starting video mode. If the ExposureProgramMode is other than M or A, a value determined by the camera is set.

PropertyValue is the aperture value multiplied by 100.

PropertyValue changes depending on the value of the ExposureEvStep.
The setting range of PropertyValue changes depending on the lens and magnification settings.

The following cases, this Capability is read only.

- When the ExposureProgramMode is other than “Auto” or “Manual”.
- The LensSort is set to "Not Attached."
- When the WarningStatus is "Sequence error" or "Zoom ring retracted warning”.
- When the MovieAVLockSetting is "Yes".
- Aperture value error.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.3 ContrastAF

This will control contrast AF during live view.

Capability kNkMAIDCapability_ContrastAF

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data one of eNkMAIDContrastAF

- 0x10: AF drive operation has ended.
- 0x11: AF operation ended due to out-of-focus condition.
- 0x12: AF operation in progress.
- Other Response Codes: AF operation failed.

This command is an activation command, and a successful completion response indicates that AF drive has started, except in the following AF non-drive conditions. When this command is responded to as successful, the host must issue a DeviceReady command to confirm that operation has ended.
Above is the information that can be obtained with the DeviceReady command when AF drive starts.

The following cases, this Capability is read only.

- WarningStatus is "An incompatible lens is attached" or "A lens with a firmware update failure is attached".

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.4 ContrastAFArea

This will change focus point of contrast AF during remote live view.

Capability kNkMAIDCapability_ContrastAFArea

Object types Source

ulType kNkMAIDCapType_Point

ulOperations kNkMAIDCapOperation_Set

Data

```
typedef struct tagNkMAIDPoint
{
```

```
   SLONG x; ---- - Coordinates of X axis
   SLONG y; ---- - Coordinates of Y axis
} NkMAIDPoint, FAR* LPNkMAIDPoint;
```

This command is valid when remote live view has been entered with the StartLiveView command.

The camera sets the AF area centered on the coordinates specified by Parameter1 and Parameter2. The X axis is set by the Xvalue of Parameter1, and the Y axis is set by the YValue of Parameter2.
The range of XValue and YValue is the entire size of the header information obtained by the GetLiveViewImageEx command, but the range that can be specified is narrowed by half the size of the AF frame. If a value outside the settable range is set, the maximum/minimum value will be reflected.
If the image is enlarged during video recording, only the enlargement position will change without changing the AF area.

The following cases, this Capability is read only.

- When waiting for spot WB acquisition.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.5 MovieWBAutoType

This will set the option when the white balance auto. (Movie Shooting Menu)

Capability kNkMAIDCapability_MovieWBAutoType

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Set, kNkMAIDCapOperation_Get

Data one of eNkMovieWBAutoType
1: Keep the incandescent light
2: Give priority to white
3: Keep the atmosphere

The following cases, this Capability is read only.

- When the exposure mode are setting except P, S, A, and M
- During movie file recording, and the value of Capability_ MovieWBMode is “Same as photo settings”.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.6 HDRMode

This will set the Photo shooting menu, [HDR (High Dynamic Range) - HDR mode]. (Photo shooting menu).

Capability kNkMAIDCapability_HDRMode

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Set, kNkMAIDCapOperation_Get

Data one of eNkMAIDHDRMode
0: Off
1: On (single photo)
2: On(series)

When the Capability_ShootingMode is continuous shooting, the HDR photo will be only the first photo.

The following cases, this Capability is read only.

- When the exposure mode are setting except P, S, A, and M.
- The EnableBracketing is set to "On."
- StillCaptureMode is "High-speed frame capture"
- ToneMode is "HLG"

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.7 LockExposure

This will get lock status of auto exposure.

Capability kNkMAIDCapability_LockExposure

Object types Source

ulType kNkMAIDCapType_Boolean

ulOperations kNkMAIDCapOperation_Get

Data True: Lock False: Unlock

When Set operation is executed on this Capability and kNkMAIDResult_NoError is returned, it indicates that the request of the switching AE lock is accepted but the completion of the switching AE lock is not guaranteed.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.8 ExposureComp

This will set the exposure compensation value.

Capability kNkMAIDCapability_ExposureComp

Object types Source

ulType kNkMAIDCapType_Range

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data

For valid values, please refer to the ExposureBiasCompensation property for each model.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.9 MovieExposureComp

This will set the exposure compensation for movie live view.

Capability kNkMAIDCapability_MovieExposureComp

Object types Source

ulType kNkMAIDCapType_Range

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data

For valid values, please refer to the MovieExposureBiasCompensation property for each model.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.10 ExposureMode

This will select the exposure mode.

Capability kNkMAIDCapability_ExposureMode

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data One of eNkMAIDExposureMode
0: Program mode
1: Aperture priority
2: Speed priority
3: Manual
5: Auto
15: U1(UserMode1)
16: U2(UserMode2)
18: U3(UserMode3)

When CPU lens is not attached, the array data includes only Aperture priority and Manual. If the exposure mode is setting “15: U1(User Mode1)”, “16: U2 (User Mode2)” or “17: U3(User Mode3)”, the exposure mode set in Capability_UserMode1, Capability_UserMode2 or Capability_UserMode3 will be used.

The following cases, this Capability is read only.

- When in PC camera mode.
- When a setting other than PSAM is selected while waiting for spot WB acquisition.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.11 InternalFlashComp

This will set “Frash compensation” in units of 1/6 EV (Photo Shooting Menu).

Capability kNkMAIDCapability_InternalFlashComp

Object types Source

ulType kNkMAIDCapType_Range

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data

For valid values, please refer to the InternalFlashCompensation property for each model.

The StepSize of PropertyValue changes depending on the value of the ExposureEVStep.

ExposureEVStep	StepSize
1/3 step	2
1/2 step	3
1 step	2

In the following cases, this Capability is read only

- When the exposure mode are setting except P, S, A, and M.
- The FlashMode satisfies the conditions for prohibiting its setting.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.12 ISOControl

This will set whether auto sensitivity control is used when you take a picture. (Photo shooting menu)

Capability kNkMAIDCapability_ISOControl

Object types Source

ulType kNkMAIDCapType_Boolean

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data True: used False: not used

The following cases, this Capability is read only.

- When the exposure mode are setting except P, S, A, and M

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.13 MovieISOControl

This will set “Movie ISO sensitivity setting - Auto ISO control (mode M)”. (Movie Shooting Menu).

Capability kNkMAIDCapability_MovieISOControl

Object types Source

ulType kNkMAIDCapType_Boolean

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data True: used False: not used

The following cases, this Capability is read only.

- When the exposure mode is other than P, S, A, M.
- Video recording is in progress and the ExposureProgramMode property is not set to M.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.14 MovieSensitivity

This will set “ISO sensitivity(mode M)” for movie live view. (Movie Shooting Menu)

Capability kNkMAIDCapability_MovieSensitivity

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_PackedString

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data

For valid values, please refer to the MovieExposureIndex property for each model.

The following cases, this Capability is read only.

- When the exposure mode is other than P, S, A, M.
- When video recording is in progress and the ExposureProgramMode is not set to M

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.15 Sensitivity

This will set the sensitivity of camera (Photo shooting menu)

Capability kNkMAIDCapability_Sensitivity

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_PackedString

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data

For valid values, please refer to the ExposureIndexEx property for each model.

During movie live view, the ISO sensitivity is controlled by Capability_MovieSensitivity, not this capability.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.16 LensType

This will get the lens type about CPU lens.

Capability kNkMAIDCapability_LensType

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get

Data One of eNkMAIDLensType

- 0x00000001: D type
- 0x00000010: G type
- 0x00000100: VR
- 0x00001000: DX
- 0x00010000:AF-S
- 0x00100000: Auto distortion control
- 0x00000020: E type
- 0x00000040:STM
- Reserved
- Collapsible lens

If the mount adapter in the LensTypeML is disabled, this property is fixed to 0. Valid PropertyValues are listed Above. If each bit is 0, it is invalid, and if it is 1, it is valid.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.17 LiveViewImageSize

This will set the size for Live View image

Capability kNkMAIDCapability_c

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Set, kNkMAIDCapOperation_Get, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDLiveViewImageSize
1: QVGA
2: VGA
3: XGA

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.18 LiveViewSelector

This will set live view photography or movie live view

Capability kNkMAIDCapability_LiveViewSelector

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Set, kNkMAIDCapOperation_Get, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDLiveViewSelector
0: Still Image Mode
1: Video Mode

The following cases, this Capability is read only.

- ♦ When in PC camera mode

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.19 RemainContinuousShooting

This will get the number of shot that can be recorded on SDRAM or the card in the continuous shooting mode by the command.

Capability kNkMAIDCapability_RemainContinuousShooting

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get

Data 1 [1 frame] to 65535 [65535 frames] (Default: 1 [1 frame])

When shooting via command processing, continuous shooting will be performed up to the number set in this property.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.20 RemainCountInMedia

This will get the number of shot that can be saved in Card in current image quality.

Capability kNkMAIDCapability_RemainCountInMedia

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get

Data 0 - 4294967295 (Default:0)

When a card is not inserted, the value of this capability is 0. The value of this capability is changed by the setting of camera. If the total number is over 4294967295, the upper limit is 4294967295.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.21 SaveMedia

This will set the recording media by shooting, shutter-release button StartShooting API.

Capability kNkMAIDCapability_SaveMedia

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data one of eNkMAIDSaveMedia
0: Card
1: SDRAM
2: Card + SDRAM

Setting change of this capability is taken as prohibition until it receives kNkMAIDEvent_CaptureComplete about SDRAM from the execution of StartShooting API.

The following cases, this Capability is read only.

- When the SpecialShootingMode is ON (interval timer shooting/focus shift shooting)

Result Code

Result Code	Description

NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.22 ShutterSpeed

This will set the shutter speed.

Capability kNkMAIDCapability_ShutterSpeed

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_PackedString

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data Strings of shutter time in second. (e.g.)
”30”, …”1”, “1/1.3”, “1/1.6”, …”1/4000”
“x 1//200”, “x 1/160”, “x 1/125”,… “x 1/60”
(Default : Minimum value of setting range)

Capability_MovieShutterSpeed is used for during movie live view, during movie file recording. Capability_ShutterSpeed is used for taking photos, during live view photography.

When the Capability_ExternalFlashStatus is not “Not Exist”, the maximum shutter speed value is limited to the Capability_FlashSyncTime setting and the array data is changed.

Because some shutter speeds cannot be expressed by this property, use the ShutterSpeed property to obtain the exact shutter speed.

For the shutter speed in movie mode, use the MovieShutterSpeed . Property Details The prohibited setting conditions, enumeration values, and factors that change the enumeration values are the same as those for the ShutterSpeed property, but because the PropertyValue unit is 1/10000, there is a range that is combined.

The handling of the combined range is described below.

PropertyValue	Shutter Speed	
	Get	Set
1	1/5000Faster shutter speed	1/10000 1/8000
2	1/5000	1/4000

	1/4000	
3	1/3200 1/3000	1/3200 1/3000
6	1/1600 1/1500	1/1600 1/1500

* Where multiple settings are listed, the available shutter speeds will be set depending on the camera's condition.

Shutter Speed x 10000 [Unit: 1/10000 seconds]

Special Values Other Than Shutter Speed

PropertyValue	Content
0xFFFFFFFF	Bulb Shooting
0xFFFFFFFD	Time Shooting

*Examples of Property Values for Shutter Speed 1/250 seconds: Property Value = 40 25 seconds: Property Value = 250000

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.23 MovieShutterSpeed

This will set the shutter speed during movie live view

Capability kNkMAIDCapability_MovieShutterSpeed

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_PackedString

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data Strings of shutter time in second. (e.g.)
”1/30”, “1/40”, “1/50”
(Default : Minimum value of setting range)

It is used for the exposure time of each frame of the movie.
Capability_MovieShutterSpeed is used for during movie live view, during movie file recording, during "Live frame grab". Capability_ShutterSpeed is used for taking photos, during live view photography.

The value range of this capability is changed by the setting of Capability_EVInterval, Capability_ExternalFlashStatus, Capability_ExternalFlashSort, Capability_MovieScreenSize.

The slowest shutter speed varies depending on the video frame rate setting. The relationship with each frame rate is as shown in the table below.

Also, if extended shutter speed (S/M mode) is enabled and the video frame rate is set to a value other than 100fps or 120fps, the slowest shutter speed will be 1/4 second regardless of the video frame rate setting.

Video Frame Rate	ExposureEVStep		
	1/3step	1/2step	1step
120fps	1/125	1/125	1/125
100fps	1/100	1/90	1/125
60fps	1/60	1/60	1/60
50fps	1/50	1/60	1/60
30fps	1/30	1/30	1/30
25fps	1/25	1/30	1/30
24fps	1/25	1/30	1/30

Valid Property Values are listed below.

Shutter Speed

Property Value	Content
First 2 Bytes	Shutter Speed Numerator
Last 2 Bytes	Shutter Speed Denominator

*Example of a Property Value for Shutter Speed
1/250 Second: Property Value = 0x000100FA
25 Seconds: Property Value = 0x00190001
The following cases, this Capability is read only.

- When the ExposureProgramMode is other than "S" or "M".
- When the WarningStatus is "Sequence error," "Minimum aperture warning," or "Zoom ring retracted warning".
- When the MovieTVLockSetting is set to "Yes"

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.24 WBFluorescentType

This will set the fluorescent type when the WBMode is “Fluorescent”. (Photo shooting menu)

Capability kNkMAIDCapability_WBFluorescentType

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkWBFluorescentType
3: Cool-white fluorescent
4: Day white fluorescent
5: Daylight fluorescent

The following cases, this Capability is read only.

- When the exposure mode are setting except P, S, A, and M.
- When video is being recorded and MovieWhiteBalance is "same as still image setting".

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.25 WBAutoType

This will set the option when the white balance auto. (Photo shooting menu)

Capability kNkMAIDCapability_WBAutoType

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data one of eNkWBAutoType
0: Keep the atmosphere
1: Keep the warm white
2: Give priority to white

The following cases, this Capability is read only.

- When the exposure mode are setting except P, S, A, and M.
- When video is being recorded and MovieWhiteBalance is "same as still image setting".

Result Code

Result Code	Description

NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.26 WBTuneColorTempEx

This will set the color temperature when the WBMode is “Color Temperature”. (Photo shooting menu).

Capability kNkMAIDCapability_WBTuneColorTempEx

Object types Source

ulType kNkMAIDCapType_Range

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data 2500 to 10000 step=10 (Default: 5000)

The following cases, this Capability is read only.

- When the exposure mode are setting except P, S, A, and M.
- When video is being recorded and MovieWhiteBalance is not "Same as still image setting"

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.27 MovieWBMode

This will set the white balance mode. (Movie Shooting Menu)

Capability kNkMAIDCapability_MovieWBMode

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_PackedString

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data

eWBMode_Auto,
eWBMode_Incandescent,
eWBMode_Fluorescent,
eWBMode_Sunny,
eWBMode_Shade,

eWBMode_Cloudy,
eWBMode_Preset1,
eWBMode_Preset2,
eWBMode_Preset3,
eWBMode_Preset4,
eWBMode_Preset5,
eWBMode_Preset6,
eWBMode_ColorTemp,
eWBMode_Natural,
eWBMode_SamePhoto

The following cases, this Capability is read only.

- When the exposure mode are setting except P, S, A, and M.
- When video is being recorded and MovieWhiteBalance is "Same as still image settings"
- When "Same as still image settings" is set during video recording

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.28 WBMode

This will set the white balance mode. (Shooting Menu)

Capability kNkMAIDCapability_WBMode

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_PackedString

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data
Auto,
Sunny,
Fluorescent,
Bulb,
Flash,
Cloudy,
Sunny Shade,
Color Temperature Setting,
Preset Manual,
Natural Light Auto

The following cases, this Capability is read only.

- When the exposure mode are setting except P, S, A, and M.
- When video is being recorded and MovieWhiteBalance is "same as still image setting".

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.29 MovieWBFluorescentType

This will set the fluorescent type when the WBMode is “Fluorescent”. (Movie shooting menu)

Capability kNkMAIDCapability_MovieWBFluorescentType

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMovieWBFluorescentType
3: Cool-white fluorescent
4: Natural white fluorescent
5: Daylight fluorescent

The following cases, this Capability is read only.

- When the exposure mode are setting except P, S, A, and M.
- When video is being recorded and MovieWhiteBalance is "same as still image setting".

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.30 LockCamera

This will lock camera. When the camera is locked, user can’t operate it directly.

Capability kNkMAIDCapability_LockCamera

Object types Source

ulType kNkMAIDCapType_Boolean

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data The operation using this OperationCode switches between PC camera mode and remote mode.

The camera sets the camera to the mode specified by ModeValue.

Operation Parameter	Detailed	
Parameter1	ModeValue	
	0	Set to PC camera mode
	1	Set to remote mode
Parameter2	None	
Parameter3	None	

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.31 MovieWBTuneColorTempEx

This will set the color temperature when the WBMode is “Color Temperature”. (Movie shooting menu).

Capability kNkMAIDCapability_MovieWBTuneColorTempEx

Object types Source

ulType kNkMAIDCapType_Range

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data 2500 to 10000 step=10 (Default: 5000)

Relationship of setting the coordinates of the camera and white balance correction value is the same as for MovieWBTuneAuto.

The following cases, this Capability is read only.

- When the exposure mode are setting except P, S, A, and M.
- When video is being recorded and MovieWhiteBalance is "same as still image setting".

Result Code

Result Code	Description

NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.32 WBTuneColorAdjust

This will set the white balance adjustment when the WBMode is “Color Temperature”.

(Photo shooting menu)

Capability kNkMAIDCapability_WBTuneColorAdjust

Object types Source

ulType kNkMAIDCapType_Range

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data 0 to 1224 (Default: 612)

The following cases, this Capability is read only.

- When the exposure mode are setting except P, S, A, and M.
- When video recording is in progress and MovieWhiteBalance is not set to "Same as still image setting".

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.33 MovieWBTuneColorAdjust

This will set the white balance adjustment when the WBMode is “Color Temperature”.

(Movie shooting menu).

Capability kNkMAIDCapability_MovieWBTuneColorAdjust

Object types Source

ulType kNkMAIDCapType_Range

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data 0 to 1224 (Default: 612)

Relationship of setting the coordinates of the camera and white balance correction value is the same as for MovieWBTuneAuto.

The following cases, this Capability is read only.

- When the exposure mode are setting except P, S, A, and M.
- When recording a movie and MovieWhiteBalance is set to "same as still image setting"

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.34 LiveViewZoomArea

This will get Movie image.

Capability kNkMAIDCapability_LiveViewZoomArea

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDLiveViewZoomArea

For valid values, please refer to the LiveViewZoomArea property for each model.

The following cases, this Capability is read only.

- When the zoom ratio is changed to anything other than 100% or full screen during video recording.
- When video is being recorded and the MovieFileType is set to "N-RAW 12-bit (NEV)."

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.35 BatteryLevel

This will show the remain of battery by percent.

Capability kNkMAIDCapability_BatteryLevel

Object types Source

ulType kNkMAIDCapType_Integer

ulOperations kNkMAIDCapOperation_Get

Data **1, 20, 40, 60, 80, 100**.

When the battery is low, the camera will only notify you at 1%, 20%, 40%, 60%, 80%, and 100%.

If the battery level is 1% and photography is prohibited, the following settings will be made.

The WarningStatus is set to low battery.

The LiveViewProhibitionCondition is set to low battery.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.36 EnableBracketing

This will set whether bracketing is applied or not.

Capability kNkMAIDCapability_EnableBracketing
Object types Source

ulType kNkMAIDCapType_Boolean

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data True: ON FALSE: OFF

The conditions for releasing bracketing are listed below.

Condition	BracketingType				
	AE Flash	AE	Flash	WB	ADL
Changing the ExposureEVStep	Yes	Yes	Yes	No	No
Change the CompressionSetting to RAW or RAW+JPEG	No	No	No	Yes	No
Changing the SilentMode	No	No	Yes	No	No
Change the StillCaptureMode to "High-speed continuous shooting (Extended)	No	No	Yes	No	No
Change the StillCaptureMode to "High Speed Frame Capture"	Yes	Yes	Yes	Yes	Yes
Change the FlashMode to "Flash Off."	No	No	Yes	No	No

The following Capability is cases, this read only.

- ExposureProgramMode is not PSAM
- HDRMode is "Yes"
- The StillCaptureMode is set to "High-Speed Frame Capture."
- If the BracketingType is "Flash bracketing" and any of the following is satisfied:
  - The SilentMode is "Enabled"
  - The FlashMode is "Flash Off."
  - The StillCaptureMode property is "High-speed continuous shooting (Extended)"
- When the BracketingType property is set to "WB Bracketing" and the CompressionSetting is set to RAW or RAW+JPEG.
- When the BracketingType property is set to "ADL Bracketing" and the ToneMode is set to "HLG".

Result Code

Result Code	Description

NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.37 BracketingOrder

This will set the bracketing order.

Capability kNkMAIDCapability_BracketingOrder

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_PackedString

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data Represents the "Flash/BKT Shooting - BKT Order" option in the custom menu.

Property Value	content
0	[0] → [-] → [+]
1	[-] → [0] → [+]

The following cases, this Capability is read only.

- The ExposureProgramMode is not PSAM.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.38 AEBracketingStep

This will set the exposure increment for AE, SB, AE/SB bracketing.

Capability kNkMAIDCapability_AEBracketingStep

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDAEBracketingStep value.

eNkMAIDAEBracketingStep_1_3EV,
eNkMAIDAEBracketingStep_1_2EV,
eNkMAIDAEBracketingStep_2_3EV,
eNkMAIDAEBracketingStep_1EV,
eNkMAIDAEBracketingStep_4_3EV,
eNkMAIDAEBracketingStep_3_2EV,
eNkMAIDAEBracketingStep_5_3EV,
eNkMAIDAEBracketingStep_2EV,
eNkMAIDAEBracketingStep_3EV,
eNkMAIDAEBracketingStep_7_3EV,
eNkMAIDAEBracketingStep_5_2EV,
eNkMAIDAEBracketingStep_8_3EV

The following cases, this Capability is read only.

- If the BracketingType setting prohibition conditions are met.
- The BracketingType is set to WB bracketing or ADL bracketing.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.39 WBBracketingStep

This will set the white balance increment for WB bracketing.

Capability kNkMAIDCapability_WBBracketingStep

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data This represents the "correction step" of WB bracketing in "Auto bracketing" in the still image shooting menu.

one of eNkMAIDWBBracketingStep
0: 1STEP
1: 2STEP
2: 3STEP

The following cases, this Capability is read only.

- The BracketingType setting prohibition conditions are met.
- The BracketingType is set to anything other than "WB Bracketing."

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.40 BracketingVary

This will set the value of [Auto bracketing] – [Auto bracketing set]

Capability kNkMAIDCapability_BracketingVary

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_PackedString

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data This will set the value of [Auto bracketing] – [Auto bracketing set] (Photo Shooting Menu).

one of eBracketingVary
- 0: AE/Flash bracketing
- 1: AE bracketing
- 2: Flash bracketing
- 3: WB bracketing
- 4: ADL bracketing

The following cases, this Capability is read only.

- The ExposureProgramMode is not set to PSAM.
- The StillCaptureMode is set to "High-Speed Frame Capture."
- The HDRMode is set to "On."

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.41 ADLBracketingType

This will set the bracketing shots when ADL bracketing.

Capability kNkMAIDCapability_ADLBracketingType

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data This indicates the "frame count" for ADL bracketing in the "Auto bracketing" menu of the still image shooting menu.

one of eNkMAIDADLBracketingType
0: BracketingType_2
1: BracketingType_3
2: BracketingType_4
3: BracketingType_5

The following cases, this Capability is read only.

- The BracketingType setting prohibition conditions are met.
- The BracketingType is set to anything other than ADL bracketing.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.42 ADLBracketingStep

This will set ADL bracketing level when two shots ADL bracketing is selected.

Capability kNkMAIDCapability_ADLBracketingStep

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data This indicates the "degree of effectiveness" when taking two shots using ADL bracketing in the "Auto Bracketing" option in the still image shooting menu.

one of eNkMAIDADLBracketingStep
0: Auto
1: Low

2: Normal
3: High
4: Extra High

The following cases, this Capability is read only.

- The BracketingType setting prohibition conditions are met.
- The BracketingType is set to anything other than ADL bracketing.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.43 BracketingCount

This will get the number of shots on AE bracketing or ADL bracketing.

Capability kNkMAIDCapability_BracketingCount

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get

Data Indicates the number of shots for AE bracketing and ADL bracketing.

Property Value	Content
1 ～ 9	AE Bracketing
1 ～ 5	ADL Bracketing

If the EnableBracketing is not set and the BracketingType is set to WB bracketing, the value of PropertyValue is undefined.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability()

3.44 ISOControlSensitivity

Capability kNkMAIDCapability_ISOControlSensitivity

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_PackedString

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_GetArray

Data Indicates the ISO sensitivity controlled by the camera.

For valid values, please refer to the ISOControlSensitivity property for each model.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability()

3.45 Active_D_Lighting

This will set Active D-Lighting.

Capability kNkMAIDCapability_Active_D_Lighting

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data This refers to "Active D-Lighting" in the still image shooting menu

one of eNkMAIDActive_D_Lighting
- 0: High
- 1: Normal
- 2: Low
- 3: Off
- 5: ExtraHigh
- 6: Auto

The following cases, this Capability is read only.
- ♦ If the ExposureProgramMode is not PSAM.
- ♦ If the ToneMode is "HLG"

Result Code

Result Code	Description

NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.46 CaptureAreaCrop

Represents "Image range - Image range settings" in the still image shooting menu.

Capability kNkMAIDCapability_CCDDataMode

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDCCDDataMode

3: FX
4: DX
8: 1:1
9: 16:9

The following cases, this Capability is read only.

- When a DX lens is attached to the camera body.
- When the StillCaptureMode property is set to "High-Speed Frame Capture" and "1:1" or "16:)".

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.47 CompressionLevel

This indicates the "image quality mode" set on the camera.

Capability kNkMAIDCapability_CompressionLevel

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_PackedString

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data **one of the eCompressionLevel value**

eCompressionLevel_Jpeg_Basic = 0,
eCompressionLevel_Jpeg_Basic_HighQuality,
eCompressionLevel_Jpeg_Normal,
eCompressionLevel_Jpeg_Normal_HighQuality,
eCompressionLevel_Jpeg_Fine,
eCompressionLevel_Jpeg_Fine_HighQuality,
eCompressionLevel_Raw,
eCompressionLevel_Raw_Jpeg_Basic,
eCompressionLevel_Raw_Jpeg_Basic_HighQuality,
eCompressionLevel_Raw_Jpeg_Normal,
eCompressionLevel_Raw_Jpeg_Normal_HighQuality,
eCompressionLevel_Raw_Jpeg_Fine,
eCompressionLevel_Raw_Jpeg_Fine_HighQuality

This property represents the camera's control value, not the menu setting value.

If the RAW function is enabled, the value will include RAW.

If a change to this property causes a change in the StorageInfoDataSet, a StorageInfoChanged event will be issued.

If the StillCaptureMode property is set to "High-Speed Frame Capture," the camera will operate in JPEG (NORMAL).

The following cases, this Capability is read only.

- If the StillCaptureMode property is "High-speed frame capture".

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.48 CompressRAWEx

Represents "RAW recording" in the still image shooting menu.

Capability kNkMAIDCapability_CompressRAWEx

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDCompressRAWEx

2: LosslessCompressed
3: Highefficiency_1
4: Highefficiency

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.49 PortraitImpressionBalance

Represents "Portrait Adjustment" in the still image shooting menu.

Capability kNkMAIDCapability_PortraitImpressionBalance

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNKMAIDPortraitImpressionBalance

0: Off
1: Mode1
2: Mode2
3: Mode3

The following cases, this Capability is read only.

- The ToneMode is set to "SDR" and the ActivePicCtrlItem property is set to "Monochrome," or a flexible color is registered in a Creative Picture Control or Custom Picture Control.
- When the ToneMode property is "HLG" and the ActivePicCtrlHlgItem is "Monochrome".

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.50 FlashISOAutoHighLimit

Represents the "ISO sensitivity setting - Automatic sensitivity control - Maximum control sensitivity when using flash" in the still image shooting menu.

Capability	kNkMAIDCapability_FlashISOAutoHighLimit
Object types	Source
ulType	kNkMAIDCapType_Enum kNkMAIDArrayType_PackedString
ulOperations	kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data

For valid values, please refer to the FlashISOAutoHighLimit property for each model.

The following cases, this Capability is read only.

- The ExposureProgramMode is set to anything other than PSAM.
- The ISOAutoControl is set to "No."

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.51 SkinSoftening

This represents the "beautiful skin effect" option in the still image shooting menu.

Capability	kNkMAIDCapability_SkinSoftening
Object types	Source
ulType	kNkMAIDCapType_Enum kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNKMAIDSkinSoftening

0: Off
2: Low
3: Normal
4: High

The following cases, this Capability is read only.

- The StillCaptureMode is set to "High-Speed Frame Capture."
- The HDRMode is set to "On."

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.52 FocalLength

This will get the focal length of the lens.

Capability kNkMAIDCapability_FocalLength

Object types Source

ulType kNkMAIDCapType_Range

ulOperations kNkMAIDCapOperation_Get

Data lfValue (mm)

Indicates the focal length when the CPU's built-in lens is attached.

The PropertyValue setting range varies depending on the lens and magnification settings.

If the LensSort is not installed, PropertyValue is undefined.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability()

3.53 FocusMode

Indicates the "focus mode" set on the camera.

Capability kNkMAIDCapability_FocusMode

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDFocusMode

0: MF
1: AFs
2: AFc
3: Afa
4. AFf

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.54 ToneMode

Represents the "gradation mode" in the still image shooting menu.

Capability kNkMAIDCapability_ToneMode

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data one of eNkMAIDToneMode

0: SDR
2: HLG

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.55 VibrationReduction

Represents the "image stabilization" option in the still image shooting menu.

Capability kNkMAIDCapability_VibrationReduction

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data one of eNkMAIDVibrationReduction

0: Off
1: Normal
2: Sport

The supported Property Values vary depending on the type of lens attached.

The following cases, this Capability is read only.

- If the attached lens has a VR switch.
- The LensSort is not attached and the FmmManualSetting2 is set to "0.0mm."

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.56 Viewmode

This represents the setting for "Shooting/Recording/Display - View Mode Settings (Still Image Level)" in the custom menu.

Capability kNkMAIDCapability_Viewmode

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDViewmode

0: Setting
1: Viewing

Result Code

Result Code	Description

NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.57 MeteringMode

This indicates the "metering mode" set on the camera.

Capability kNkMAIDCapability_MeteringMode

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDMeteringMode

0: Matrix
1: CenterWeighted
2: Spot
4: HighLight

The following cases, this Capability is read only.

- The ExposureProgramMode is not PSAM.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.58 MovieMeteringMode

Represents the "Metering mode" in the video recording menu.

Capability kNkMAIDCapability_MovieMeteringMode

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data one of eNkMAIDMovieMeteringMode

0: Matrix
1: CenterWeighted
2: HighLight

The following cases, this Capability is read only.

- The ExposureProgramMode is not PSAM.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.59 BracketingType

This will set the combination bracketing shots and direction when AE, Flash, AE and Flash, White balance bracketing.

Capability kNkMAIDCapability_BracketingType

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDBracketingType

4: Both_3
5: Both_5
6: Both_7
7: Both_9

The following cases, this Capability is read only.

- The BracketingType setting prohibition conditions are met.
- The BracketingType is set to anything other than "WB Bracketing."

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.60 MovieRecordScreenSize

Represents the "Image size/frame rate" in the video recording menu.

Capability kNkMAIDCapability_MovieScreenSize

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data

Represents the "Image Size/Frame Rate" setting in the video shooting menu.

This property represents the menu setting value, but if the prohibited setting conditions are met, it represents the camera control value. Each bit in the property value has the following meaning.

Bit	Number of bits	content
48-63	16	Horizontal resolution
32-47	16	Vertical resolution
24-31	8	Reserved (fixed at 0)
16-23	8	Frame rate
14-15	2	Scanning method
8-13	6	Special effects
0-7	8	Additional information on special effects

Horizontal resolution / Vertical resolution / Frame rate Assign the resolution and frame rate values as they are.

Scanning method

Value	Content
0	p(progressive)
1	i(interlace)
2 ~ 3	Reserved

Special photography

Value	Content
0	Normal
1	Slow motion
2	Crop
3 ~ 63	Reserved

Special Effects Supplementary Information If no supplementary information is available, this is fixed at 0. For slow motion, the value is 10 times the slow-motion magnification.

Value	Content
40	4x slow
50	5x slow

Valid values are listed below.

Property Value	content	MovieFileType		
		H.264	H.265	N-RAW
0x0FC008DC001E0000	4032×2268 30p	-	-	○
0x0FC008DC00190000	4032×2268 25p	-	-	○
0x0FC008DC00180000	4032×2268 24p	-	-	○
0x0F9008C0001E0000	3984×2240 30p	-	-	○
0x0F9008C000190000	3984×2240 25p	-	-	○
0x0F9008C000180000	3984×2240 24p	-	-	○
0x0F000870003C0000	3840×2160 60p	-	○	-
0x0F00087000320000	3840×2160 50p	-	○	-
0x0F000870001E0000	3840×2160 30p	-	○	-
0x0F00087000190000	3840×2160 25p	-	○	-
0x0F00087000180000	3840×2160 24p	-	○	-
0x0780043800780000	1920×1080 120p	-	○	-
0x0780043800640000	1920×1080 100p	-	○	-
0x07800438003C0000	1920×1080 60p	○	○	-
0x0780043800320000	1920×1080 50p	○	○	-
0x07800438001E0000	1920×1080 30p	○	○	-
0x0780043800190000	1920×1080 25p	○	○	-
0x0780043800180000	1920×1080 24p	○	○	-
0x07800438001E0128	1920×1080 30p 4x slow motion	○	-	-
0x0780043800190128	1920×1080 25p 4x slow motion	○	-	-
0x0780043800180132	1920×1080 24p 5x slow motion	○	-	-

The following cases, this Capability is read only.

- When a DX lens is attached and "1920x1080 120p/100p" or slow motion video is set.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.61 MFDrive

This will adjust focus position during live view.

Capability kNkMAIDCapability_MFDrive

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data The operation according to this OperationCode starts MF driving.

one of eNkMAIDMFDrive
0: InfinityToClosest
1: ClosestToInfinity

The following cases, this Capability is read only.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.62 MovieActive_D_Lighting

This will set “Active D-Lighting”. (Video Recording Menu)

Capability kNkMAIDCapability_MovieActive_D_Lighting

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data This represents the "Active D-Lighting" option in the video recording menu.

one of eNkMAIDMovieActive_D_Lighting
0: Off
1: Low
2: Normal
3: High
4: ExtraHigh

The following cases, this Capability is read only.

- The ExposureProgramMode is not PSAM.
- The MovieFileType is "H.265 10-bit (MOV)" and the MovieH265ToneMode is "N-Log" or "HLG."
- The MovieFileType property is "N-RAW 12-bit (NEV)."

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.63 MovieAfAreaMode

This will set “AF-area mode” of Video Recording Menu.

Capability kNkMAIDCapability_MovieAfAreaMode

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data Represents the "AF area mode" when shooting video.

one of eMovieAfAreaMode
0: Single
1: Auto
2: WideArea_S
3: WideArea_L
7: TargetTracking
12: WideArea_C1
13: WideArea_C2

In the following cases, this property will become single-point AF. If the following conditions are canceled without changing the AF-area mode, the AF-area mode will return to the previous setting.

When the MovieFocusMode is MF.

The following cases, this Capability is read only.

- When the video focus mode is set to manual focus
  *Excluding cases where a CPU lens is not attached or when the focus mode is set to manual focus due to the controls.
- When high-resolution zoom is enabled
  *For the conditions under which high-resolution zoom is enabled, see the HiResZoom.
- When Product Review Mode is Enabled
  For the conditions under which Product Review Mode is enabled, see the MovieFocusMode.

Result Code

Result Code	Description

NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.64 MovieAFSubjectDetection

This will set “AF subject detection options”,(Video Recording Menu)

Capability kNkMAIDCapability_MovieAFSubjectDetection

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data Represents "AF/MF subject detection settings - Subject detection" in the video shooting menu.

one of eNkMAIDMovieAFSubjectDetection
0: None
1: Auto
2: Person
3: Animals
4: Vehicles
5: Birds
6: Airplanes

The following cases, this Capability is read only.

- When Product Review Mode is Enabled For the conditions under which Product Review Mode is enabled, see the MovieFocusMode.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.65 MovieAttenuator

This will set “Attenuator”. (Video Recording Menu)

Capability kNkMAIDCapability_MovieAttenuator

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data Represents the "Attenuator" in the video recording menu.

one of eNkMAIDMovieAttenuator
0: Disable
1: Enable

The following cases, this Capability is read only.

- During video recording, the MovieRecordMicrophoneLevel is set to "No Recording."
- The MovieRecordScreenSize is set to slow motion video.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.66 MovieCCDDataMode

This will set “Image area – Choose image area”. (Video Recording Menu)

Capability kNkMAIDCapability_MovieCCDDataMode

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDMovieCCDDataMode

0: FXFormat
1: DXFormat

The following cases, this Capability is read only.

- When the MovieFileType is set to "N-RAW 12-bit (NEV)".
- When the MovieRecordScreenSize is set to "3840x2160 60p/50p" or "1920x1080 120p/100p" and slow-motion video is used.
- When a DX lens is attached to the camera body

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.67 MovieFileType

This will set "Movie recording file format" in the movie shooting menu.

Capability kNkMAIDCapability_MovieFileType

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDMovieFileType

2: H264_8bit_MP4
3: H265_8bit_MOV
4: H265_10bit_MOV
7: NRaw_12bit_NEV

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.68 MovieFocusMode

This will set the focus mode for movie (Video Recording Menu).

Capability kNkMAIDCapability_MovieFocusMode

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data Indicates the "focus mode" when shooting video.

one of eNkMAIDMovieFocusMode

0: AF-S
1: AF-C
2: AF-F
3: MF

Even if this property is set to AF, if a CPU lens is not attached or the focus mode is set to MF using an operating member, this property will be set to MF.

The following cases, this Capability is read only.

- When Product Review Mode is Enabled.
  Product Review Mode is enabled when the following conditions are met:
  The ProductReviewMode is set to "Enabled" or "Enabled (Custom)" and this property is set to anything other than "MF."

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.69 MovieFocusPointLockc

Represents "Video - Lock Controls - Lock Focus Point" in the custom menu.

Capability kNkMAIDCapability_MovieFocusPointLock

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDMovieFocusPointLock

0: Disable
1: Enable

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.70 MovieH265ToneMode

This will set “Video file type” - “H.265 10-bit(MOV)” - “Tone mode”.

Capability kNkMAIDCapability_MovieH265ToneMode

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDToneMode

0: SDR
1: NLOG
2: HLG

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.71 ContinuousShootingNum

This will set the number of shots in continuous shooting by host.

Capability kNkMAIDCapability_ContinuousShootingNum

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data 1 [1 frame] to 65535 [65535 frames]

When shooting via command processing, continuous shooting will be performed up to the number set in this property. For details on the number of consecutive frames, see Continuous Shooting.

Result Code

Result Code	Description

NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.72 MovieISOAutoHiLimit

This will set the "Movie ISO Sensitivity Setting - Maximum Control Sensitivity" in the video shooting menu.

Capability kNkMAIDCapability_MovieISOAutoHiLimit

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_PackedString

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data

Property Value	content	IsoStep	
		1/3 step	1 step
200	200	○	○
250	250	○	-
320	320	○	-
400	400	○	○
500	500	○	-
640	640	○	-
800	800	○	○
1000	1000	○	-
1250	1250	○	-
1600	1600	○	○
2000	2000	○	-
2500	2500	○	-
3200	3200	○	○
4000	4000	○	-
5000	5000	○	-
6400	6400	○	○
8000	8000	○	-
10000	10000	○	-
12800	12800	○	○
16000	16000	○	-
20000	20000	○	-
25600	25600	○	○
32000	32000	○	-
40000	40000	○	-

51200	51200	○	○
64000	Hi 0.3	○	-
80000	Hi 0.7	○	-
102400	Hi 1.0	○	○
204800	Hi 2.0	○	○

The following cases, this Capability is read only.

- The ExposureProgramMode is not PSAM.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.73 MoviePictureControl

This will set Picture Control in Video Menu.

Capability kNkMAIDCapability_MoviePictureControl

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDMoviePictureControl

1: Standard
2: Neutral
3: Vivid
4: Monochrome
5: Portrait
6: Landscape
7: Flat
8: Auto
9: Flat Monochrome
10: Deep Tone Monochrome
11: Rich Tone Portrait
100: Same as photo
101: Dream
102: Morning
103: Pop
104: Sunday
105: Somber
106: Drama

107: Silence
108: Bleach
109: Melancholic
110: Pure
111: Denim
112: Toy
113: Sepia
114: Blue
115: Red
116: Pink
117: Charcoal
118: Graphite
119: Binary
120: Carbon
201: Custom1
202: Custom2
203: Custom3
204: Custom4
205: Custom5
206: Custom6
207: Custom7
208: Custom8
209: Custom9

The following cases, this Capability is read only.

- The gradation mode is N-Log or HLG (if one of the following conditions is met):
  - The MovieFileType is "H.265 10-bit (MOV)" and The MovieH265ToneMode is "N-Log" or "HLG."

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.74 MoviePortraitImpressionBalance

This will set "Portrait Impression Adjustment" option in the video recording menu.

Capability kNkMAIDCapability_MoviePortraitImpressionBalance

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data

one of eNKMAIDMoviePortraitImpressionBalance
0: OFF
1: Mode1
2: Mode2
3: Mode3

The following cases, this Capability is read only.

- The gradation mode of the video recording file format is "SDR" and The MovieActivePicCtrlItem is "Monochrome," and flexible color is registered in "Creative Picture Control" or "Custom Picture Control."
- The gradation mode of the video recording file format is "SDR," the MovieActivePicCtrlItem property is "Same as still image settings," and the ActivePicCtrlItem is "Monochrome," "Creative Picture Control," or "Custom Picture Control" with flexible color registered.
- When the video recording file format's gradation mode is "N-log"
  *Conditions for the gradation mode to be "N-Log"
  - The MovieFileType is "H.265 10-bit (MOV)" and the MovieH265ToneMode is "N-Log"

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.75 MovieRecordingZone

This will set “ Frequency response”. (Video Recording Menu)

Capability kNkMAIDCapability_MovieRecordingZone

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data one of eNkMAIDMovieRecordingZone

0: Wideband

1: Audioband.

The following cases, this Capability is read only.

- During video recording, the MovieRecordMicrophoneLevel is set to "No Recording."
- The MovieRecordScreenSize is set to slow motion video.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.76 MovieRecMicrophoneValue

This will set the microphone sensitivity when Capability_MovieRecMicrophone is manual sensitivity.

Capability kNkMAIDCapability_MovieRecMicrophoneValue

Object types Source

ulType kNkMAIDCapType_Range

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data Represents the sensitivity of "Audio Input Sensitivity - Manual" in the video recording menu.

The following cases, this Capability is read only.

- The MovieRecordMicrophoneLevel is not set to "Manual."
- The MovieRecordScreenSize is set to slow-motion video.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.77 MovieRecMicrophone

This will set the value of Microphone.

Capability kNkMAIDCapability_MovieRecMicrophone

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data one of eNkMAIDMovRecMicrophone

0: Auto
4: Off

5: Manual

The following cases, this Capability is read only.

- When "No recording" is selected during video recording
- When "No recording" is selected during video recording in "Auto" or "Manual"
- When the MovieRecordScreenSize is set to slow motion video

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.78 MovieSkinSoftening

This will set the "beautiful skin effect" option in the video recording menu.

Capability kNkMAIDCapability_MovieSkinSoftening

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNKMAIDMovieSkinSoftening

0: Off
2: Low
3: Normal
4: High
100: SameAsStill

The following cases, this Capability is read only.

- When the MovieFileType is "H.265 10-bit (MOV)" and the MovieH265ToneMode is "N-Log".
- When the MovieFileType property is "N-RAW 12-bit (NEV)".
- When the MovieRecordScreenSize frame rate is "100p" or higher.

Result Code

Result Code	Description

NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.79 MovieVibrationReduction

This will set "Image Stabilization" setting in the video recording menu.

Capability kNkMAIDCapability_MovieVibrationReduction

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data This indicates

one of eNkMAIDMovieVibrationReduction
0: Off
1: Normal
2: Sport
100: SamePhoto

The following cases, this Capability is read only.

- If the attached lens has a VR switch.
- If the LensSort is not attached and the FmmManualSetting2 is "0.0mm".

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.80 MovieWBPresetName

Capability kNkMAIDCapability_MovieWBPresetName

Object types Source

ulType kNkMAIDCapType_String

kNkMAIDCapType_Array

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data Data NkMAIDArray

This property represents the comment for "White Balance - Preset Manual - d-6" in the video recording menu.

kNkMAIDCapOperation_GetArray runtime, an array of NkMAIDString, Module to set the name of preset white balance data in the order of Preset1 ~ 6 to NkMAIDArray.pData.

PropertyValue is a string of 36 characters (excluding NULL characters). If the string is shorter than 36 characters, it is padded with spaces (0x20). For information on characters that can be entered (ASCII codes).

This property is found in both the still image recording menu and the video recording menu; changing one setting will result in the same setting.

The following cases, this Capability is read only.

- The ExposureProgramMode is not set to PSAM.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.81 MovieWindNoiseReduction

This will set "Wind Noise Reduction" option in the video recording menu.

Capability kNkMAIDCapability_MovieWindNoiseReduction

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data

one of eNkMAIDMovieWindNoiseReduction
0: OFF
1: ON

The following cases, this Capability is read only.

- During video recording, the MovieRecordMicrophoneLevel is set to "No Recording."

- An external microphone is connected.
- When the MovieRecordScreenSize is set to slow motion video.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.82 PictureControl

This will set Picture Control item.

Capability kNkMAIDCapability_PictureControl

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDPictureControl

1: Standard
2: Neutral
3: Vivid
4: Monochrome
5: Portrait
6: Landscape
7: Flat
8: Auto
9: Flat Monochrome
10: Deep Tone Monochrome
11: Rich Tone Portrait
101: Dream
102: Morning
103: Pop
104: Sunday
105: Somber
106: Drama
107: Silence
108: Bleach
109: Melancholic
110: Pure
111: Denim
112: Toy

113: Sepia
114: Blue
115: Red
116: Pink
117: Charcoal
118: Graphite
119: Binary
120: Carbon
201: Custom1
202: Custom2
203: Custom3
204: Custom4
205: Custom5
206: Custom6
207: Custom7
208: Custom8
209: Custom9

The following cases, this Capability is read only.

- When the ToneMode is set to "HLG".

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.83 PictureControlHlg

This will set Picture Control (HLG)" in the still image shooting menu.

Capability	kNkMAIDCapability_PictureControlHlg
Object types	Source
ulType	kNkMAIDCapType_Enum kNkMAIDArrayType_Unsigned
ulOperations	kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray
Data	one of eNkMAIDPictureControlHlg 1: Standard 4: Monochrome 7: Flat

The following cases, this Capability is read only.

- If the ToneMode is "SDR".

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.84 Slot2ImageSaveMode

This will set the Role played by card in Slot 2 of the Photo Shooting Menu

Capability kNkMAIDCapability_Slot2ImageSaveMode

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDSlot2ImageSaveMode

0: Sequential recording
1: Backup recording
2: RAW+JPEG split recording
3: JPEG+JPEG split recording

The following cases, this Capability is read only.

- When the HDRMode is set to "Yes".

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.85 Slot2JpegImageSize

This will set the image size for Slot2 when the value of Capability_Slot2ImageSaveMode is “3: JPEG Slot 1 - JPEG Slot 2

Capability kNkMAIDCapability_Slot2JpegImageSize

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_PackedString

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data

PropertyValue	content
Same as size L of ImageSize property	Size L
Same as size M of ImageSize property	Size M
Same as size S of ImageSize property	Size S

The following cases, this Capability is read only.

- When the HDRMode is set to "Yes".

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.86 SpecialShootingMode

Indicates the shooting status of interval timer shooting and focus shift shooting.

Capability kNkMAIDCapability_SpecialShootingMode

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_GetArray

Data one of eNKMAIDSpecialShootingMode

0: Off
1: Interval
2: FocusShift

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.87 SpotWBChangeArea

The operation by this OperationCode is to change the spot WB area in the spot WB acquisition standby state.

Capability kNkMAIDCapability_SpotWBChangeArea

Object types Source

ulType kNkMAIDCapType_Point

ulOperations kNkMAIDCapOperation_Set

Data

```
typedef struct tagNkMAIDPoint
    {
        SLONG       x;
        SLONG       y;
    } NkMAIDPoint, FAR* LPNkMAIDPoint;
```

This command is valid when the spot WB acquisition standby state has been entered by the StartSpotWb command.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.88 WBPresetName

Capability kNkMAIDCapability_WBPresetName

Object types Source

ulType kNkMAIDCapType_String

kNkMAIDCapType_Array

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data NkMAIDArray

When the client sends to the module kNkMAIDCapOperation_GetArray, the module set string array of the name of white balance preset data to “NkMAIDArray.pData” in order of preset1-6.

PropertyValue must be any string of 36 characters (excluding NULL characters).

If the string is shorter than 36 characters, it will be padded with spaces (0x20).For information on characters (ASCII codes) that can be entered.

This setting property is found in both the still image shooting menu and the video shooting menu and changing either one will result in the same setting.

The following cases, this Capability is read only.

- The ExposureProgramMode is not set to PSAM.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.89 ActiveSlot

Capability kNkMAIDCapability_ActiveSlot

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get

Data Indicates the recording destination slot when the recording destination is a card.

one eNkMAIDActiveSlot
0: NoCard
1: Slot1
2: Slot2
3: Slot1_Slot2

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.90 AFSubjectDetection

Represents the "AF/MF subject detection setting" in the still image shooting menu.

Capability kNkMAIDCapability_AFSubjectDetection

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDAFSubjectDetection

0: None
1: Auto
2: Person
3: Animals
4: Vehicles
5: Bords
6: Airplanes

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.91 ChangeMonitorOffStatus

Indicates the forced off state of the camera monitor. Does not indicate the actual monitor control state.

Capability kNkMAIDCapability_ChangeMonitorOffStatus

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDChangeMonitorOffStatus

0: CancelForcedTurnOff
1: ForcedTurnOff

Result Code

Result Code	Description

NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.92 CountUpMethod

Represents the "Time Code - Count Up Method" in the video recording menu.

Capability kNkMAIDCapability_CountUpMethod

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDCountUpMethod

0: RecordRun
1: FreeRun

The following cases, this Capability is read only.

- When the RecordTimeCodes is set to "No".
- When a time not set warning occurs.
- When the connection to ATOMOS AirGlu BT is set to "ON".

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.93 DropFrame

Represents "Time Code - Drop Frame" in the video recording menu.

Capability kNkMAIDCapability_DropFrame

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDDropFrame

0: OFF

1: ON

The following cases, this Capability is read only.

- When the RecordTimeCodes is set to "No".
- When a time not set warning occurs
- When the connection to ATOMOS AirGlu BT is set to "ON

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.94 ElectronicVR

This indicates the setting of "Electronic Image Stabilization" in the video recording menu.

Capability kNkMAIDCapability_ElectronicVR

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set,

Data one of eNkMAIDElectronicVR

0: OFF
1: ON

The following cases, this Capability is read only.

- The MovieFileType is set to "N-RAW 12-bit (NEV)."
- The MovieRecordScreenSize is set to "1920x1080 120p/100p" and slow-motion video is being used.
- When the HiResZoom is "ON
  *For the conditions under which Hi-Res Zoom is enabled, see the HiResZoom.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.95 ExternalRecordingControl

Represents "External Recording Control (HDMI)" in the video recording menu.

Capability kNkMAIDCapability_ExternalRecordingControl
Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data one of eNkMAIDExternalRecordingControl

0: OFF
1: ON

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.96 FocusPointLock

Represents the "Operation - Lock Operation - Lock Focus Point" custom menu.

Capability kNkMAIDCapability_FocusPointLock

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data

one of eNkMAIDFocusPointLock
0: Disable
1: Enable

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.97 HighlightBrightness

This represents the setting for "Video - Zebra Display - High Luminance Detection Range" in the Custom menu.

Capability kNkMAIDCapability_HighlightBrightness

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data 120 ~ 255 (StepSize 5) [Default Value: 250]

The following cases, this Capability is read only.

- The ExposureProgramMode is not PSAM.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.98 ImageColorSpace

Represents the "Color Space" in the still image shooting menu.

Capability kNkMAIDCapability_ImageColorSpace

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDImageColorSpace

0: sRGB
1: AdobeRGB
100: BT_2100

The following cases, this Capability is read only.

- When the ToneMode value is "HLG".

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.99 ImageSize

Represents the "Image size" in the still image shooting menu.

Capability kNkMAIDCapability_ImageSize

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_PackedString

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data

	PropertyValue			
CaptureAreaCrop	FX	DX	1:1	16:9
Size L	6048x4032	3984x2656	4032x4032	6048x3400
Size M	4528x3024	2976x1992	3024x3024	4528x2544
Size S	3024x2016	1984x1328	2016x2016	3024x1696

The following cases, this Capability is read only.

- When the CompressionSetting is set to "RAW".
- When the StillCaptureMode is set to "High-speed frame capture".

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.100 ISOAutoHiLimit

Represents "ISO sensitivity setting - automatic sensitivity control - maximum control sensitivity" in the still image shooting menu.

Capability kNkMAIDCapability_ISOAutoHiLimit

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDArrayType_PackedString

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data

For valid values, please refer to the ISOAutoHighLimit property for each model.

The following cases, this Capability is read only.

- The ExposureProgramMode is set to anything other than PSAM.
- The ISOAutoControl is set to "No."

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.101 ISOAutoShutterTime

This will set the shutter speed when ISO is controlled automatically. (Photo shooting menu)

Capability kNkMAIDCapability_ISOAutoShutterTime

Object types Source

ulType kNkMAIDCapType_Range

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data

For valid values, please refer to the ISOAutoShutterTime property for each model.

The following cases, this Capability is read only.

- If the ExposureProgramMode is set to other than PSAM.
- If the ISOAutoControl is set to "No".

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.102 LensId

Indicates the CPU lens ID

Capability kNkMAIDCapability_LensId

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get

Data If the LensSort is not set, the PropertyValue value is fixed to 0.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.103 SelectedSlot

It will get the selected slot.

Capability kNkMAIDCapability_SelectedSlot

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get

Data one of eNkMAIDImageColorSpace

0: NoCard
1: NoSpace
2: CardError
3: Slot1

4: Slot2
5: Slot1_Slot2
6: Single
7: NoSpace_Slot1
8: NoSpace_Slot2

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.104 SpotWBMode

This will set the ON / OFF state of waiting to acquire SpotWB.

Capability kNkMAIDCapability_SpotWBMode

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data one of eNkMAIDImageColorSpace

0: OFF
1: ON

When set to 1 (ON) to start the state of waiting to acquire SpotWB, the value of this Capability set to 0 (OFF), then stop.

This command is valid when in video mode and the camera has entered remote live view mode using the StartLiveView command. It enters a standby state for acquisition of the destination specified by the MovieWbPresetDataNo.

However, if the MovieWhiteBalance is set to "Same as still image settings," the destination will be the destination specified by the WbPresetDataNo property.

Cancels the standby state for spot WB acquisition. Returns OK even if the camera is not in the standby state for spot WB acquisition.

The following cases, this Capability is read only.

- When the white balance is not preset manual.
- When in PC camera mode.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.105 RawJpegTransferStatus

This will get whether the image is taken on RAW+JPEG mode.

Capability kNkMAIDCapability_RawJpegTransferStatus

Object types Source

ulType kNkMAIDCapType_ Boolean

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data one of eNkMAIDRawJpegImageStatus

0: Single

1: RAW+JPEG

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.106 IsAlive

This is the objects validity state.

Capability kNkMAIDCapability_IsAlive

Object types Source

ulType kNkMAIDCapType_Boolean

ulOperations kNkMAIDCapOperation_Get

The value of this capability is usually TRUE. It is FALSE if the object is removed by the module or the object's parent is closed by the client.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.107 Name

This is the name of the object.

Capability kNkMAIDCapability_IsAlive

Object types Source

ulType kNkMAIDCapType_String

ulOperations kNkMAIDCapOperation_Get

Unlike the kNkMAIDCapability_Description capability, this capability cannot be set. The module should use that capability if it can store a descriptive name, and it wishes to allow the user to edit that name

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.108 Interface

This is the description of the physical interface being used to communicate with the source.

Capability kNkMAIDCapability_Interface

Object types Source only

ulType kNkMAIDCapType_String

ulOperations kNkMAIDCapOperation_Get

This will allow the user to better identify the source.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.109 DataTypes

This is the data types available from an item or the data types that a source can produce.

Capability kNkMAIDCapability_DataTypes

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get

The value will be a bitwise combination of the eNkMAIDDataObjType values. The value kNkMAIDDataObjType_File should not be used in connection with this capability. This value is to be used only for data delivery.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.110 LensInfo

This will get the focal length and minimum F number.

Capability kNkMAIDCapability_LensInfo

Object types Source only

ulType kNkMAIDCapType_String

ulOperations kNkMAIDCapOperation_Get

Data (e.g.)”35-70/F3.3-4.5D”

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

.

3.111 ShootingLimit

This will set the shooting limit number in continuous shooting.

Capability kNkMAIDCapability_ShootingLimit

Object types Source

ulType kNkMAIDCapType_Range

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set

Data 1 [1 frame] to 200 [200 frames] (Default: 200 [200 frames])

Frames 1 to 50 can be set in 1-frame increments, 50 to 100 in 10-frame increments, and 100 to 200 in 20-frame increments.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

.

3.112 LiveViewProhibit

This will get the status of Live view prohibition.

Capability kNkMAIDCapability_LiveViewProhibit

Object types Source

ulType kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get

Data one of eNkMAIDLiveViewProhibit

This property indicates the conditions under which live view is prohibited. If there are any prohibiting factors in this property, the StartLiveView command must not be issued. If you issue the StartLiveView command to start live view while there are prohibiting factors, the operation is not guaranteed.

PropertyValue is a bit assignment and can take the following values: (1: Enabled, 0: Disabled)

Bit	Content
Bit29～ Bit31	Reserved
Bit28	Lens Factor ・Version update notification warning when

	mount adapter is
Bit18～ Bit27	Reserved
Bit17	Live View cannot be entered due to temperature rise
Bit16	Reserved
Bit15	Shooting processing in progress *Until shooting is complete
Bit9～Bit14	Reserved
Bit8	Low battery
Bit3～Bit7	Reserved
Bit2	Sequence error
Bit0～Bit1	Reserved

Live view cannot be started if PropertyValue is anything other than 0.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

3.113 ShootingMode

This will set the shooting mode.

Capability kNkMAIDCapability_ShootingMode

Object types Source

ulType kNkMAIDCapType_Enum

kNkMAIDCapType_Unsigned

ulOperations kNkMAIDCapOperation_Get, kNkMAIDCapOperation_Set, kNkMAIDCapOperation_GetArray

Data one of eNkMAIDShootingMode

For valid values, please refer to the StillCaptureMode property for each model.

Result Code

Result Code	Description
NKERROR	One of the NKERROR value we received in GetCapability() / SetCapability()

4 Event

4.1 RemoveChild

This event will be issued when the child is removedd under an object.

Event kNkMAIDEvent_RemoveChild
Object types Module, Source, Item
Data parameter Removed child ID

4.2 CapChange

This event will be issued when the information of Capability is changed.

Event kNkMAIDEvent_CapChange
Object types Module, Source, Item
Data parameter Capability ID

In the following cases, this event will be issued. ・ When the information of structure "NkMAIDCapInfo" of capability was changed. ・ When the enum configuration of Capability with type of kNkMAIDCapType_Array has been changed.

4.3 CapChangeValueOnly

This event will be issued when the current value of Capability is changed.

Event kNkMAIDEvent_CapChangeValueOnly
Object types Module, Source, Item, Data
Data parameter Capability ID

This event will be issued when only the current value of capability is changed (the array data, ulVisibility, ulOperations is not changed).

4.4 CaptureComplete

This will be issued when the acquisition or deletion of all images of which it takes a picture is completed.

Event kNkMAIDEvent_CaptureComplete
Object types Source
Data parameter 0 : The all SDRAM images are finished to read or deleted.
1: The all images are finished to record in card.

4.5 RecordingInterrupted

This event will be issued the factor of discontinue when the recording of movie was stopped with error occurring.

Event kNkMAIDEvent_RecordingInterrupted
Object types Source
Data parameter pointer to NkMAIDEventParam

The contents of the NkMAIDEventParam structure are as follows.
NkMAIDEventParam.ulEvent = kNkMAIDEvent_RecordingInterrupted;
NkMAIDEventParam.ulElements = 2;
NkMAIDEventParam.ulParam[0] : Error type
1: Some error.
0: Low access speed card error.

NkMAIDEventParam.ulParam[1] : Recording device

0: Recording to card
1: Recording to external device
2: Recording to both card and external device

4.6 CapChangeOperationOnly

Operation value or visibility of Capability has changed.
Event kNkMAIDEvent_CapChangeOperationOnly
Object types Module, Source, Item, Data
Data parameter Capability ID
Events to notify (the number of elements in the array, enumeration value configuration,
value, etc. has not changed) if only Operation or visibility · Invalid attribute of Capability has
changed.

4.7 SBAdded

It is used to inform the flash unit is newly attached to the camera.
Event kNkMAIDEvent_SBAdded
Object types Source
Data parameter pointer to NkMAIDEventParam
The contents of NkMAIDEventParam structure, becomes as follows.
NkMAIDEventParam.ulEvent = kNkMAIDEvent_SBAdded
NkMAIDEventParam.ulElements= 1
NkMAIDEventParam.ulParam[0] = SBHandle

4.8 SBRemoved

It is used to inform the flash unit is detached from the camera.
Event kNkMAIDEvent_SBRemoved
Object types Source
Data parameter pointer to NkMAIDEventParam
The contents of NkMAIDEventParam structure, becomes as follows.
NkMAIDEventParam.ulEvent = kNkMAIDEvent_SBRemoved
NkMAIDEventParam.ulElements= 1
NkMAIDEventParam.ulParam[0] = SBHandle

4.9 SBAttrChanged

It is used to inform the attributes of the flash unit have changed.
This event is not issued when the attributes of the flash have changed by receiving Capability_SBAttrValue command from the host.
Event kNkMAIDEvent_SBAttrChanged
Object types Source
Data parameter pointer to NkMAIDEventParam
The contents of NkMAIDEventParam structure, becomes as follows.
NkMAIDEventParam.ulEvent = kNkMAIDEvent_SBAttrChanged
NkMAIDEventParam.ulElements = 2
NkMAIDEventParam.ulParam[0] = SBHandle
NkMAIDEventParam.ulParam[1] = SBAttrID

4.10 SBGroupAttrChanged

It is used to inform the attribute descriptor for the flash group or the current value has changed. This event is not issued when the attributes of the flash have changed by receiving Capability_SBGroupAttrValue command from the host.

Event kNkMAIDEvent_SBGroupAttrChanged
Object types Source
Data parameter pointer to NkMAIDEventParam

The contents of NkMAIDEventParam structure, becomes as follows.
NkMAIDEventParam.ulEvent = kNkMAIDEvent_SBGroupAttrChanged
NkMAIDEventParam.ulElements = 2
NkMAIDEventParam.ulParam[0] = SBGroupID
NkMAIDEventParam.ulParam[1] = SBGroupAttrID

If the Capability_SBWirelessMode is set to other than “Single flash” and the Capability_SBWirelessMultipleFlashMode is set to “Repeating”, SBGroupID of the master flash is used to inform the changes for the following flash group regardless of the value of Capability_SBUsableGroup. ・kNkMAIDSBGroupAttribute_FlashLevel ・kNkMAIDSBGroupAttribute_RepeatCount ・ kNkMAIDSBGroupAttribute_RepeatInterval

4.11 MovieRecordComplete

This event will be issued the host that the movie recording is successfully completed.

Event kNkMAIDEvent_MovieRecordComplete
Object types Source
Data parameter Recording device
0: Recording to card
1: Recording to external device
2: Recording to both card and external device

This event will be issued when recording movie is completed or the maximum recording time reaching.

4.12 StartMovieRecord

This event will be issued the host that the camera has started movie recording.

Event kNkMAIDEvent_StartMovieRecord
Object types Source
Data parameter Recording device
0: Recording to card
1: Recording to external device
2: Recording to both card and external

This event will be issued the host that the camera has started movie recording by pressing the recording button of the camera. Recording device is specified for parameter.

4.13 ManualSettingLensDataChanged

This event will be issued the host that “Non-CPU lens data” has changed.

Event kNkMAIDEvent_ManualSettingLensDataChanged
Object types Source
Data parameter LensNo. to be changed
0 ~ 19 : No1 ~ No20 LensNo. is specified for parameter

4.14 DeviceInfoChanged

This event will be issued when the Devices information is changed means New device are added or removed.

Event kNkMAIDEvent_DeviceInfoChanged
Object types Module
Data parameter DeviceID

4.15 ImageSaved

This event will be issued when the images saved.

Event kNkMAIDEvent_ImageSaved
Object types Source
Data parameter ImageName

4.16 ImageSavedInCard

This event will be issued when the Images saved in card.

Event kNkMAIDEvent_ImageSavedInCard
Object types Source
Data parameter None

4.17 StoreAdded

This event will be issued when the a new SD card is added.

Event kNkMAIDEvent_StoreAdded
Object types Source
Data parameter None

4.18 StoreRemoved

This event will be issued when the SD card is removed.

Event kNkMAIDEvent_StoreRemoved
Object types Source
Data parameter None

4.19 StorageFull_ImageNotSaved

This event will be issued when the storage is full in PC Drive.

Event kNkMAIDEvent_StorageFull_ImageNotSaved
Object types Source
Data parameter None

4.20 AcquireFailed_ImageNotSaved

This event will be issued when the image acquire is failed.

Event kNkMAIDEvent_AcquireFailed_ImageNotSaved
Object types Source
Data parameter None

4.21 ChangeSaveDestination

This event will be issued when save destination does not exists.

Event kNkMAIDEvent_ChangeSaveDestination
Object types Source
Data parameter None

4.22 AddImageInCard

This event will be issued when image saved in card.

Event kNkMAIDEvent_AddImageInCard
Object types Source
Data parameter Parameter1 is ObjectHandle

4.23 OpenCaptureComplete

This event will be issued when Interval Timer / Focus shift shooting completed.

Event kNkMAIDEvent_OpenCaptureComplete
Object types Source
Data parameter Parameter1 is the TransactionID of the InitiateOpenCaptureV command.
If shooting is initiated from the camera, this will be 0.
Parameter2 EndFactor notifies the cause of termination.

4.24 CaptureSkip

This event notifies when interval timer shooting has been skipped.

Event kNkMAIDEvent_CaptureSkip
Object types Source
Data parameter Parameter1 is SkipCount.

4.25 LiveViewStateChanged

This event notifies when Live View State is Changed.

Event kNkMAIDEvent_LiveViewStateChanged
Object types Source
Data parameter Parameter1 is CameraLiveViewStatus

CameraLiveViewStatus	Param1
0	OFF
1	ON

4.26 HlgQualityAdjustChanged

This event notifies when Live Hlg Quality changed.

Event kNkMAIDEvent_HlgQualityAdjustChanged
Object types Source
Data parameter None

4.27 PortraitImpressionBalanceAdjustChanged

This event notifies when Portrait Impression Balance data set is changed.

Event kNkMAIDEvent_PortraitImpressionBalanceAdjustChanged
Object types Source
Data parameter Parameter1 is ModeNum and Parameter2 is ShootingMode

4.28 FocusShiftShootingStarted

This event notifies Focus shift shooting started.

Event kNkMAIDEvent_FocusShiftShootingStarted
Object types Source
Data parameter None

4.29 FocusShiftShootingStopped

This event notifies Focus shift shooting stopped.

Event kNkMAIDEvent_FocusShiftShootingStopped
Object types Source
Data parameter None

4.30 PixelShiftShootingStarted

This event notifies Pixel Shift Shooting Started.

Event kNkMAIDEvent_PixelShiftShootingStarted
Object types Source
Data parameter None

4.31 PixelShiftShootingStopped

This event notifies Pixel Shift Shooting Stopped.

Event kNkMAIDEvent_PixelShiftShootingStopped
Object types Source
Data parameter None

5 History

5.1 New